


Sunco DL-DK4-WH-2760K Flush Mount Retrofit
Recessed Ceiling Fixture LED Disk Light



Sunco DL-DK4-WH-2760K Flush Mount Retrofit Recessed Ceiling Fixture LED Disk Light User Manual


[Home](#) » [SUNCO](#) » Sunco DL-DK4-WH-2760K Flush Mount Retrofit Recessed Ceiling Fixture LED Disk Light User Manual 

Contents

- [1 Sunco DL-DK4-WH-2760K Flush Mount Retrofit Recessed Ceiling Fixture LED Disk Light](#)
- [2 Product Information](#)
- [3 Product Usage Instructions](#)
- [4 Frequently Asked Questions](#)
- [5 Whats in the Box?](#)
- [6 Before You Start](#)
- [7 Installation Guide \(Surface Mount\)](#)
- [8 Installation Guide \(Retrofit Install\)](#)
- [9 Product Details](#)
- [10 Common Troubleshooting](#)
- [11 Light Distribution Angle](#)
- [12 Customer Support](#)
- [13 Documents / Resources](#)
 - [13.1 References](#)



Sunco DL-DK4-WH-2760K Flush Mount Retrofit Recessed Ceiling Fixture LED Disk Light



Product Information

Specifications

- Product: LED 4 High-Output Selectable Disk Downlight
- SKU: DL_DK4-WH-2760K
- Email: support@sunco.com
- Phone: [844-334-9938](tel:844-334-9938)

Product Usage Instructions

Before You Start

Safety Information:

- Follow all safety instructions to reduce the risk of fire, electric shock, or physical injury.
- Avoid exposing the product to water.
- Do not clean with harsh solvents.
- Comply with all relevant laws and regulations during installation.
- Avoid damaging the enclosure or electrical components during installation.

Quickstart Guide

1. **Step 1:** Remove the lens by twisting clockwise.
2. **Step 2:** Connect supply & junction wires.
3. **Step 3:** Attach fixture to junction box.

4. **Step 4:** Twist lens counter clockwise.

Installation Guide (Surface Mount)

1. **STEP 1:** Turn off circuit breaker before installation.
2. **STEP 2:** Remove the lens by twisting clockwise.
3. **STEP 3:**
 1. Connect the supply wires to the junction box wires using nuts provided.
 2. White to White; Black to Black; Ground wire.


Frequently Asked Questions

Q: What dimmers are recommended for this product?

A: Recommended dimmers information is not available in the provided text. Please reach out to support@sunco.com or call [844-334-9938](tel:844-334-9938) for specific dimmer recommendations.

Whats in the Box?

Disk Downlight



Before You Start

Safety Information

To reduce the risk of fire, electric shock, or physical injury:

- Turn off circuit breaker before installing this fixture.
- This product should be installed by a person familiar with the construction and operation of the product the hazards involved. Safety eyeglasses and gloves are recommended.
- Abide by related regional and local laws or regulations.
- Proper grounding is required to ensure safety.
- Do not alter, relocate, or remove wiring during installation.
- Do not make or alter any open holes in wiring enclosure or electrical components during installation.
- Check for shipping damage before installing. If the product is damaged, do not use it.
- Keep fixture away from corrosive substances.
- Suitable for damp locations at temperature ranging from -4°F to 104°F. Not for use where directly exposed to water.
- Clean the fixture regularly to ensure proper operation. Do not clean with harsh solvents.
- Use safety precautions and abide by regional and local laws or regulations.
- This product is not compatible with 3rd party sensors.
- This product is not compatible with photo controls.
- This product is not compatible with occupancy sensors.
- This product is not compatible with timing devices.

WARNING:

Cancer & Reproductive Harm- www.P65Warnings.ca.gov

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:


1. This device may not cause harmful interference.
2. This device must accept any interference that may cause undesired operation. Please review all instructions carefully prior to installation.

Quickstart Guide




Step 1

Remove the lens by twisting clockwise.



Step 2

Connect supply & junction wires.



Step 3

Attach fixture to junction box.



Step 4

Twist lens counter clockwise.

Installation Guide (Surface Mount)

• STEP 1

Turn off circuit breaker before installation.



NOTE: Remove previous fixture. Fixture may be hot so allow time to cool after turning off power.

- **STEP 2**

Remove the lens by twisting clockwise.

- **STEP 3**

- a. Connect the supply wires to the junction box wires using nuts provided.
- b. White to White; Black to Black ; Ground wire.



- **STEP 4**

Note: This step applies exclusively to the Selectable Slims.



- a. Turn on power and test light.
- b. Slide CCT switch to choose from 5 color temperature options, then turn off light & continue install.

- **STEP 5**

- a. Tuck the connected wires inside the junction box.
- b. Attach the fixture to the junction box with long screws attached depending on the junction box size (deep or shallow). NOTE: DO NOT OVER TIGHTEN.

- **STEP 6**

Complete the installation by screwing the lens back into place (counter clockwise).



Installation Guide (Retrofit Install)

• STEP 1

- a. Turn off circuit breaker before installation.




NOTE: Remove previous fixture. Fixture may be hot so allow time to cool after turning off power.

• STEP 2

Securely inlay the spring iron bracket and mounting patch, ensuring stability. Additionally, securely inlay the 6-inch disk & mounting patch to maintain stability.

STEP 3

- a. Connect the Black wire to the "+" position and the White wire to the "-" position.
- b. Connect disk light to the socket in recessed can. Tuck the ground away.



- **STEP 4**

Note: This step applies exclusively to the Selectable Slims.




- a. Turn on power and test light.
 - b. Slide CCT switch to choose from 5 color temperature options, then turn off light and continue install.
- Tuck all wires into the can.

- **STEP 5**

- a. Tuck all wires into the can. Line up trim ring with opening.
- b. Push disk into can until secure. Compression clips will hold disk light in place. Push up spring clips and insert fixture into ceiling.

- **STEP 6**

Turn on circuit breaker and test the light.



Product Details

Recommended Dimmers

Brand	Model
LEVITON	153M-ES
LEVITON	CL-6672
LEVITON	CL-6674
LEVITON	CL-6683
LUTRON	DV-600P
LUTRON	DVCL-153P
LUTRON	MACL-153ME
LUTRON	MACL-153MR

Scan for the full
compatible dimmer list!



Specifications

Voltage	120V	Average Lifetime	35000 hrs
Wattage	10W	Lumens	650LM
Frequency	60Hz	Moisture Rating	Wet
Efficacy	65lm/w	CRI	90
Weight	0.42lbs	Usage	Indoor
Housing Material	ALU+PC	Amps	100mA
Dimmable	Yes	Warranty	7 Years

Common Troubleshooting

We’ve got you covered! Our troubleshooting section is here to shed some light and provide you with easy-to-follow solutions for any problem.

If you still need some assistance, feel free to contact us. Our team of lighting experts are happy to help brighten your day.

Installation

Light isn't turning on.

Double check if fixture is properly connected and circuit breaker hasn't been tripped.

Light unexpectedly fails.

Reach out to customer support.

Dimming

Light not dimming to lowest setting.

Ensure minimum dimmer load requirement is met.

Light not dimming smoothly.

Verify dimmer compatibility with fixture.

Light not compatible with dimmer switch.

Check light-dimmer compatibility.

Flickering

Light is flickering when turning on.

Check that fixture wiring connections are secure.

Light flickering with other lights on the same circuit.

Check that the lights are not overloading the circuit.

Light flickering when turned on.

Verify fixture compatibility.

Light flickering when dimmed.

Verify dimmer switch compatibility.

Buzzing

Fixture buzzing with power outages.

Verify light is connected to surge protector securely.


Fixture buzzing with appliances or electronic devices.

Look for nearby interferences that can cause buzzing. Such as televisions, radios, computers, etc.

Fixture buzzing when dimmed.

Verify dimmer switch compatibility.

Light Distribution Angle




Lighting distribution angle refers to the spread of light emitted from a light source. It is an important factor to consider when selecting a fixture or bulb, as it affects the way it will illuminate an area. There are two main types of lighting distribution angles: A symmetric lighting distribution emits light evenly in all directions, creating a cone-shaped pattern that provides a pool of light. This type of lighting is ideal for general lighting and illuminating large areas. Common applications for symmetric lighting include general area illumination, security lighting, and perimeter lighting. Symmetric lighting is also used to a certain degree in up-lighting. An asymmetric lighting distribution angle, also known as beam angle, creates a pattern that focuses light in a specific direction. This type

of lighting is ideal for task lighting as it reduces glare and light spill in other areas. Common applications include task lighting in spaces such as landscape settings, retail stores, museums, and much more. It is important to note that the lighting distribution angle can also be affected by other factors such as the reflector design of the light source, the type of lens used, and the distance between the light source and the surface being illuminated.

Customer Support

Warranty Policy

This product is covered by our industry leading 7 year warranty.
It gets even better – scan the QR code for 2 extra years of protection!



30 Day Return Policy

At Sunco, we value our customers and stand by the quality and performance of our products.
If you are not completely satisfied with your purchase, we accept returns within 30 days of your purchase date.


Customer Service

Our Los Angeles team of lighting experts is here to assist you with all your needs! Contact us at:
Email: support@sunco.com Call or Text: [844-334-9938](tel:844-334-9938)

support@sunco.com [844-334-9938](tel:844-334-9938)



Documents / Resources

	<p>Sunco DL-DK4-WH-2760K Flush Mount Retrofit Recessed Ceiling Fixture LED Disk Light [pdf] User Manual</p> <p>DL-DK4-WH-2760K Flush Mount Retrofit Recessed Ceiling Fixture LED Disk Light, DL-DK4-WH-2760K, Flush Mount Retrofit Recessed Ceiling Fixture LED Disk Light, Retrofit Recessed Ceiling Fixture LED Disk Light, Recessed Ceiling Fixture LED Disk Light, Ceiling Fixture LED Disk Light, Fixture LED Disk Light, LED Disk Light, Disk Light, Light</p>
---	--

References

- [🌐 P65Warnings.ca.gov](https://www.p65warnings.ca.gov)
- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.