



# Sunrise TR001 Noise Alarm Clock User Manual


[Home](#) » [Sunrise](#) » Sunrise TR001 Noise Alarm Clock User Manual 

## Sunrise TR001 Noise Alarm Clock User Manual

### Contents

- [1 Get to know your White Noise Alarm](#)
- [2 Set up your White Noise Alarm](#)
- [3 Product Specifications](#)
- [4 Additional Information](#)
- [5 FCC Warning](#)
- [6 Documents / Resources](#)
  - [6.1 References](#)
- [7 Related Posts](#)

## Get to know your White Noise Alarm



Also included: Charging Cable

## Set up your White Noise Alarm

1. Plug the power adapter into White Noise Alarm then power on device.
2. Download the latest version of the "" app from app store.
3. Tap the more icon to add your device. Choose "light" as the device type, then follow the on-screen instructions to add a device. If prompted by the app to scan a barcode, you can scan the 2D barcode on the back page.  
Equipment Operation
4. touch the top of the device to switch lights, long press the top of the device to turn off lights.
5. Press the mode key to switch sounds, and hold down the mode key to disconnect or connect Bluetooth.

## Product Specifications

- **Model Number:** TR001
- **Electrical Rating:** 5.25V MAX 1.0A
- **Built-in Battery:** 3.7V 2500mAh
- **Bluetooth Version:** 5.0 Communication
- **Range:** About 10M
- **Product Size:** 100×100×90mm

## Additional Information

You can find the device Terms of Use, Limited Warranty, instructions for using the Device, Customer Service contract information, and other applicable terms and device information at [www.devicesupport.com](http://www.devicesupport.com)

## FCC Warning

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/ TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:


1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC RF warning statement:

This equipment must be installed and operated in accordance with provided instructions and the antenna(s) used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be located or operating in conjunction with any other antenna or transmitter. End-users and installers must be provide with antenna installation instructions and transmitter operating conditions for satisfying RF exposure compliance.

Documents / Resources

	<a href="#">Sunrise TR001 Noise Alarm Clock</a> [pdf] User Manual TR001, 2A2Q9-TR001, 2A2Q9TR001, TR001 Noise Alarm Clock, Noise Alarm Clock
---	---

References

- [🌐 NameBright - Coming Soon](#)