

SupaWarm SCH2000T 2000 Watt Turbo Convector Heater **Instruction Manual**

Home » SupaWarm » SupaWarm SCH2000T 2000 Watt Turbo Convector Heater Instruction Manual





2000 Watt Turbo **Convector Heater**

Contents

- 1 SCH2000T 2000 Watt Turbo Convector
- **2 PARTS IDENTIFICATION**
- **3 ELECTRICAL SAFETY**
- **4 IMPORTANT SEFTY INSTRUCTION**
- **5 USING YOUR HEATER**
- **6 CONFORMITY WITH DIRECTIVE**
- **7 TECHNICAL DETAILS**
- **8 CLEANING AND STORAGE**
- 9 THANK YOU FOR PURCHASING
- 10 Documents / Resources
 - 10.1 References
- 11 Related Posts

SCH2000T 2000 Watt Turbo Convector Heater

This manual is to be used with the following SupaWarm radiator: SCH2000T IMPORTANT: Read these instructions before use. Please retain for future reference.

INSTRUCTION MANUAL




This product is only suitable for well insulated spaces or occasional use.



PARTS IDENTIFICATION


A. Feet	D. Handle	
B. Thermostat Knob	E. Air Outlet Grid	
C. Power Switch	F. Air Inlet Grid	



Photographs are for illustration purposes only. Actual product may differ slightly.

IMPORTANT NOTE!

Before using the heater, the feet (supplied separately in the carton), must be fitted to the unit. These are to be attached to the base of the heater using the 4 self-tapping screws provided, taking care to ensure that they are located correctly in the bottom ends of the heater side mouldings.



ELECTRICAL SAFETY

RATING

AC 220-240V ~ 50Hz, 1800-2000W.

Ensure that the voltage indicated on the identification plate corresponds with the mains voltage.

Please read these instructions fully before use.

WARNING! This appliance must be earthed.

THE HEATER MUST BE POSITIONED UPRIGHT.

DISPOSAL

IMPORTANT INFORMATION FOR CORRECT DISPOSAL OF THE PRODUCT IN ACCORDANCE WITH EC DIRECTIVE 2002/96/EC.

At the end of its working life, the product must not be disposed of as urban waste. It must be taken to a special local authority differentiated waste collection centre or to a dealer providing this service. Disposing of a household appliance separately avoids possible negative consequences for the environment and health, avoiding inappropriate disposal enables the constituent materials to be recovered to obtain significant savings in energy and resources. As a reminder of the need to dispose of household appliances separately, the product is marked with a crossed-out wheeled dustbin.


IMPORTANT SEFTY INSTRUCTION

PLEASE READ ALL INSTRUCTIONS CAREFULLY BEFORE USING THE PRODUCT. WARNING! In order to avoid overheating, please DO NOT COVER heater during use.

- **DO NOT** use the heater unless the feet are correctly attached.
- Ensure the power supply to the socket into which the heater is plugged is in accordance with the rating label on the heater and that the socket is earthed.
- Keep the power cord away from the hot body of the heater.
- WARNING! Do not use this heater in the immediate surroundings of a bath, shower or swimming pool.
- The heater is not intended for use in bathrooms, laundry areas or similar indoor locations. **NEVER** place the heater where it may fall into a bathtub or other water containers.
- DO NOT use outdoor, for indoor use only.
- **DO NOT** cover or obstruct any of the heat outlet grilles or the air intake openings of the heater.
- **DO NOT** place the heater on deep pile carpets.
- **ALWAYS** ensure that the heater is placed on a firm level Ensure that the heater is not positioned close to curtains or furniture as this could create a fire hazard.
- **DO NOT** position the heater in front of, or immediately below, a wall socket.
- **DO NOT** use the heater in areas where flammable liquids are stored or where flammable fumes may be present.
- ALWAYS unplug the heater when moving it from one location to another.
- **DO NOT** use the heater if the power cord is damaged. If the power cord is damaged it must be replaced by a recognised service agent or other qualified person.
- WARNING! In order to avoid overheating, do not cover the heater. Some parts of this product can become very hot and cause burns. Particular attention has to be given where children and vulnerable people are present.
- Young children should be supervised to ensure that they do not play with the appliance.
- Children of less than 3 years should be kept away from the heater unless continuously supervised.
- Children aged from 3 years and less than 8 years shall only switch on/off the appliance provided that it has been placed or installed in its intended operating position and they have been given supervision or instruction concerning the use of the appliance in a safe way and understand the hazards involved. Children aged from 3 years and less than 8 years shall not plug in, regulate and clean the appliance or perform user maintenance.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- CAUTION! In order to avoid a hazard due to inadvertent resetting of the thermal cut-out this appliance must not be supplied through an external switching device such as a timer or connected to a circuit that is regularly switched on and off by the utility.

USING YOUR HEATER

PLEASE NOTE: It is normal when the heaters are turned on for the first time or when they are turned on after having not been used for a long period of time, the heaters may emit some smell and fumes. This will disappear when the heater has been on a short while.



- Choose a suitable location for the heater into account the safety instructions in this manual.
- Insert the plug of the heater into a suitable socket.
- Turn the thermostat knob fully in a clockwise direction to the maximum setting.
- Turn on the heating elements by means of the rocker switches on the side panel. When the heating elements are on the switches will illuminate. For maximum heat output, both switches should be on.
- When the desired room temperature has been reached, the thermostat knob should be turned slowly anticlockwise until the thermostat is heard to click off and the lights on the element switches are seen to go out.
 After this the heater will keep the air temperature in the room at the set temperature by switching on and off automatically.
- FAN OPERATION: This is operated by means of the switch with the fan symbol along side it. The fan will only operate with the thermostat in the "on" position and can be used when the heating elements are "on" to blow warm air into the room. In warm conditions the fan can be used with the heating elements "off" to blow cool air into the room.

CONFORMITY WITH DIRECTIVE



MUNRO IMPORTERS LTD

Declaration of Conformity
In accordance with Government Guidance



We, the importer: Munro Importers Ltd

First Floor, Unit 1 The Quadrangle The Drift, Nacton Road,

Ipswich Suffolk IP3 90R Declare that the product:

Product code: 493000 SCH2000T

Product description: SupaWarm 2000w Turbo convector heater

Is in conformity with the relevant statutory instruments and their amendments:

Electromagnetic Compatibility Regulations 2016 and EMC Directive 2014/30/EU

Electrical Equipment (Safety) Regulations 2016 and Low Voltage Directive 2014/35/EU

Commission Regulation (EU) 2015/1188 implementing Directive 2009/125/EC of the European Parliament and of the Council with regard to ecodesign requirements for local space heaters

Directive 2011/65/EU on the Restriction of the Use of Certain Hazardous Substances in Electrical and Electronic Equipment (RoHS) with its Amendments (EU) 2015/863

And is manufactured in accordance with the following Standard or standardized documents:

EN IEC 55014-1:2017+A11:2020, EN IEC 55014-2:2015, EN IEC 61000-3-2:2019, EN 61000-3-3:2013/A1:2019 EN 60335-1:2012+AC:2014+A11:2014+A13:2017+A14:2019+A2:2019, EN 60335-2-30:2009+A11:2012, EN 62233:2008 (EC) No 1275/2008 & (EU) No.801/2013, EN 50564:2011 & IEC 62301: 2011, EN 60675:1995+A1:1998+A2:2018+A11:2019 IEC 62321-3-1: 2013, IEC 62321-5: 2013, IEC 62321-4: 2013+AMD1: 2017 CSV, IEC 62321-7-2: 2017, IEC 62321-7-1: 2015 IEC 62321-6: 2015, ISO 17075: 2017, IEC 62321-1: 2013, IEC 62321-2: 2013

All documentation is held on file and is available, on request, for review. Authorized Signatory:

Date: 24.03.2023

Name: Dominic Richardson Position: Product Coordinator Year of Manufacture: 2023

TECHNICAL DETAILS

Model No: SCH2000T

Item	Symbol	Value	Unit	Item	Unit
Heat Output			Type of heat input, for electric storage local space heaters only (select one)		
Nominal heat output	Pnom	1,9	kW	Manual heat charge control, with integrated thermostat	N/A
Minimum heat output (indicat ive)	Pmin	0,0210	kW	Manual heat charge control, with roo m and/or outdoor temperature feedba ck	N/A
Maximum continuous heat o utput Auxiliary Electricity Consumption At nominal hea t output	-	1,9 N/A	kW kW	Electronic heat charge control with ro om and/or outdoor temperature feedb ack	N/A
				Fan assisted heat output Type of heat output/room temperature control (select one) Single stage heat output and no room temperature control	N/A No
At minimum heat output	elm",	N/A	kW		
In standby mode	else	N/A	kW	Two or more manual stages, no room temperature control	No
				With mechanic thermostat room temp erature control	Yes
				With electronic room temperature con trol	No
				Electronic room temperature control p lus day timer	No
				Electronic room temperature control p lus week timer Other options (multiple selections pos sible) Room temperature control, with prese nce detection	No No
				Room temperature control, with open window detection	No
				With distance control option	No
				With adaptive start control	No
				With working time limitation	No
				With black bulb sensor	No

CLEANING AND STORAGE

- Always un-plug the heater from the wall socket and allow it to cool down before cleaning.
- Clean the outside of the heater by wiping with a damp cloth and buff with a dry cloth.
- Do not use any detergents or abrasives and do not allow any water to enter the heater.
- When the heater is not used for long periods of time it should be protected from dust and stored in a clean dry place.

Correct disposal of this product

This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased.

They can take this product for environmental safe recycling

THANK YOU FOR PURCHASING

For a complete range of fires, radiators and heaters please call or visit Supa Brands for further information:

Website: www.supabrands.co.uk

Helpline: 01473 237 997

Part of the extensive Supa Brand Range

PO Box 1042, Ipswich, IP1 9XY

Documents / Resources



<u>SupaWarm SCH2000T 2000 Watt Turbo Convector Heater</u> [pdf] Instruction Manual SCH2000T 2000 Watt Turbo Convector Heater, SCH2000T, 2000 Watt Turbo Convector Heater, Turbo Convector Heater, Heater

References

• S Leading UK Cash and Carry Wholesaler & Trade Supplier - Stax Trade Centres

Manuals+,