



---

[Home](#) » [SwitchBot](#) » **SwitchBot SMS-EN-2506-Q RGBICWW Floor Lamp User Manual** 

## Contents [ [hide](#) ]

- [1 SwitchBot SMS-EN-2506-Q RGBICWW Floor Lamp](#)
- [2 Package Contents](#)
- [3 List of Components](#)
- [4 Preparation](#)
- [5 Setting Up](#)
- [6 Restoring to Factory Settings](#)
- [7 Firmware Upgrades](#)
- [8 Specifications](#)
- [9 Warranty](#)
- [10 Contact & Support](#)
- [11 FAQ](#)
- [12 Documents / Resources](#)
  - [12.1 References](#)

# SwitchBot

## SwitchBot SMS-EN-2506-Q RGBICWW Floor Lamp




Please read this user manual carefully before using your device.

- <https://www.switch-bot.com/pages/switchbot-user-manual>



## Package Contents




RGBICWW Floor  
Lamp × 1



Power Adaptor × 1



Stand Pack × 1



Controller × 1




User Manual × 1



Installation Guide × 1

## List of Components



1. Pole
2. Lamp Base
3. Controller
4. Power Cord
5. Power Adaptor
6. Horizontal Stand
7. End cap (for horizontal placement)

## Preparation

### You will need:

- A smartphone or tablet using Bluetooth 4.2 or later.
- The latest version of our app, downloadable via the Apple App Store or Google Play Store.
- A SwitchBot account, you can register via our app or sign in to your account directly if you already have one.



## iOS and Android system requirements:

- <https://support.switch-bot.com/hc/en-us/articles/12567397397271>



## Setting Up

1. Assemble the Floor Lamp following the quick installation guide.
2. Connect the power adapter to an outlet.
3. Add the lamp to the SwitchBot app.

## Restoring to Factory Settings

- Press and hold the On/Off button and Music Mode button simultaneously for 15 seconds until red, green and blue lights flow through your lamp.
- **Note:** After resetting the device, all settings will resume to default values.

## Firmware Upgrades

- In order to improve user experience, we will regularly release firmware updates to introduce new functions and solve any software defects that may occur during usage.
- When a new firmware version is available, we will send an upgrade notification to your account via our app.
- When upgrading, please make sure your product has sufficient battery or stay powered on and make sure your smartphone is within range to prevent interference.

Please visit our website or scan the QR code below for more information.



## Specifications

- Power: 18 W
- Input: 100-240 V-, 50-60 Hz
- Lumens: 1200 1m
- Color Type: RGBICWW
- Color Temperature: 2700-6500 K
- Operating Temperature: 0 °C to 40 °C (5 °F to 113 °F)
- Operating Humidity: 0 to 90% RH
- Connectivity: 2.4 GHz Wi-Fi+Bluetooth 4.2

## Warranty

We warrant to the original owner of the product that the product will be free from defects in materials and workmanship. Please note that this limited warranty does not cover:

1. Products submitted beyond the original limited warranty period.
2. Products on which repairs or modifications have been attempted.
3. Products subjected to falls, extreme temperatures, water, or other operating conditions outside the product specifications.
4. Damage due to natural disaster (including but not limited to lightning, flood, tornado, earthquake, or hurricane, etc.).
5. Damage due to misuse, abuse, negligence, or casualty (e.g., fire).
6. Other damage that is not attributable to defects in the manufacture of product materials.
7. Products purchased from unauthorized resellers.
8. Consumable parts (including but not limited to batteries).
9. Natural wear of the product.

## Contact & Support

- Feedback: If you have any concerns or problems when using our products, please

send feedback via our app through the Profile > Support page.

- Setup and Troubleshooting: [support.switch-bot.com](https://support.switch-bot.com)
- Support Email: [support@switch-bot.com](mailto:support@switch-bot.com)

## FAQ

What should I do if I can't connect to the app?

- Make sure Bluetooth is turned on.
- Keep your phone close to the light while connecting.


What steps can I take when the Wi-Fi disconnects or fails to connect?

- Check if the light is powered on.
- Complete the Wi-Fi connection step during device setup and avoid skipping it.
- Verify that your Wi-Fi router is set to 2.4GHz. 5GHz is not supported.
- Double-check that you've entered the correct Wi-Fi password during setup.
- Try pairing the light with a different smartphone to confirm your network is working.
- Reduce the distance between the light and your Wi-Fi router to within 127 cm 50 inches and reconnect.

What should I do if I can't connect to Alexa or Google Assistant?

- Ensure that your Wi-Fi connection is stable and functioning properly.
- Go to the settings page of our app and reconnect your Floor Lamp to the third-party platforms.

## Documents / Resources

|   |   |
|---|---|
|  | <a href="#">SwitchBot SMS-EN-2506-Q RGBICWW Floor Lamp [pdf]</a> User Manual<br>SMS-EN-2506-Q RGBICWW Floor Lamp, SMS-EN-2506-Q, RGBICWW Floor Lamp, Floor Lamp, Lamp |
|---|---|

## References

- [User Manual](#)

SwitchBot

Floor Lamp, lamp, RGBICWW Floor Lamp, SMS-EN-2506-Q, SMS-EN-2506-Q RGBICWW Floor Lamp, SwitchBot

---

## Leave a comment

Your email address will not be published. Required fields are marked \*

Comment \*

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

**Post Comment**

**Search:**

e.g. whirlpool wrf535swhz

**Search**

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.

