

SWS AP-BTM-1750IP Bluetooth Adapter



## SWS AP-BTM-1750IP Bluetooth Adapter Instructions

[Home](#) » [SWS](#) » SWS AP-BTM-1750IP Bluetooth Adapter Instructions 

### Contents


- [1 SWS AP-BTM-1750IP Bluetooth Adapter](#)
- [2 Wiring options](#)
- [3 Unit installation](#)
- [4 FCC compliance statement](#)
- [5 Documents / Resources](#)
  - [5.1 References](#)



### SWS AP-BTM-1750IP Bluetooth Adapter



## Wiring options



- **Yellow** — ( + 12V) Power
- **Black** — (-12V) Ground
- **Red** — ( + 12V) Remote in/Switched Power
- **Blue** — Remote Turn on (Output to Amp)
- **RCA** — (3.5mm) Audio output (Amp)
- **Aux In** — 3.5mm Audio input

## Unit installation

1. Connect Yellow ( + 12V) wire to a constant power (battery).
2. Connect Black (-12V) wire to chassis ground.
3. Connect RED to a switched 12V power source or the remote output of the head unit.
4. Connect the Blue wire (remote out) to the amplifier.
5. Connect RCA output to amplifier.

## Pairing your device (required for operation):

1. . Ensure your streaming device has wireless music stream enabled and that power is applied to the AP-BTM-175011! (The blue LED on the AP-BTM-1750/P will blink to indicate it is in pairing mode.)
2. Within your streaming device's wireless music stream setup menu, select "AP-BTM-1750/P" from the list of pairable devices.
3. When successfully connected, the Blue LED on the AP-BTM-1750/P will stop blinking and remain lit.  
A single beep will be heard through the connected audio system.

## FCC compliance statement

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, under Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used by the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. this device may not cause harmful interference, and
2. this device must accept any interference received, including interference that may cause undesired operation.


This device and its antenna(s) must not be co-located or operated in conjunction with any other antenna or transmitter.

### Radiation Exposure Statement

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with a minimum distance of 20cm from your body.

---

## Documents / Resources

	<a href="#">SWS AP-BTM-1750IP Bluetooth Adapter</a> [pdf] Instructions AP-BTM-1750IP, ZNGAP-BTM-1750IP, ZNGAPBTM1750IP, AP-BTM-1750IP Bluetooth Adapter , Bluetooth Adapter, Adapter
---	--

## References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.