


sygonix®  
**3026093 Zigbee  
Temperature and  
Humidity Sensor**



# sygonix 3026093 Zigbee Temperature and Humidity Sensor Instruction Manual

[Home](#) » [Sygonix](#) » sygonix 3026093 Zigbee Temperature and Humidity Sensor Instruction Manual 

## Contents

- [1 sygonix 3026093 Zigbee Temperature and Humidity Sensor](#)
- [2 Specifications](#)
- [3 Product Usage Instructions](#)
- [4 FAQ](#)
- [5 Intended use](#)
- [6 Delivery contents](#)
- [7 Product Overview](#)
- [8 Cleaning and care](#)
- [9 Technical data](#)
- [10 Documents / Resources](#)
  - [10.1 References](#)

sygonix®

**sygonix 3026093 Zigbee Temperature and Humidity Sensor**



## Specifications

- Product Name: Zigbee Temperature and Humidity Sensor
- Item Number: 3026093
- Intended Use: Measure ambient temperature and humidity
- Integration Options:
  - Zigbee gateway (Item no. 3026091)
  - Home Assistant via Zigbee integration
  - Home Assistant via Zigbee2MQTT
- Indoor Use Only: Yes
- Battery: CR2032

## Product Usage Instructions

- Open the package and ensure all contents are available.
- Insert the CR2032 battery into the sensor.
- Use the double-sided adhesive tape to mount the sensor in the desired location.
- Ensure the sensor is placed in an area with good air circulation for accurate readings.
- Follow the instructions specific to your chosen integration method (Zigbee gateway, Home Assistant via Zigbee integration, or Home Assistant via Zigbee2MQTT).
- Avoid placing the sensor under mechanical stress.
- Protect from extreme temperatures, strong impacts, flammable gases, and direct sunlight.
- Avoid exposure to high humidity and moisture.

## Maintenance and Safety

- Handle the sensor carefully to prevent damage.

- Do not attempt to repair or modify the sensor yourself.
- If in doubt about the operation, seek expert advice.

## FAQ

- **Q:** Can the Zigbee Temperature and Humidity Sensor be used outdoors?
- **A:** No, the product is intended for indoor use only. Outdoor use may result in damage.
- **Q:** How do I change the battery in the sensor?
- **A:** To change the battery, carefully open the sensor using the provided pry tool, replace the CR2032 battery, and securely close the sensor back.
- **Q:** What should I do if I encounter issues with the sensor readings?
- **A:** Ensure the sensor is placed correctly in an area with proper airflow. Check the battery level and replace if necessary. If issues persist, contact technical support for assistance.

## Zigbee Temperature and Humidity Sensor

- Item no: 3026093



## Operating Instructions for download

- Use the link [www.conrad.com/downloads](http://www.conrad.com/downloads) (alternatively scan the QR code) to download the complete operating instructions (or new/current versions if available). Follow the instructions on the web page.

## Intended use

The product is a Zigbee temperature and humidity sensor. Use the product to measure ambient temperature and humidity.

The product can be integrated into a network in one of the following ways:

- Zigbee gateway (Item no. 3026091)
- Home Assistant via Zigbee integration
- Home Assistant via Zigbee2MQTT

The product is intended for indoor use only. Do not use it outdoors.

- Contact with moisture must be avoided under all circumstances.
- If you use the product for purposes other than those described, the product may be damaged.
- Improper use can result in short circuits, fires, or other hazards.
- The product complies with the statutory national and European requirements.
- For safety and approval purposes, you must not rebuild and/or modify the product.
- Read the operating instructions carefully and store them in a safe place. Make this product available to third

parties only together with the operating instructions.

- All company names and product names are trademarks of their respective owners. All rights reserved.

## **Delivery contents**

- Temperature and humidity sensor with CR2032 battery
- Strap
- Pry tool
- Double-sided adhesive tape
- Operating instructions

## **Description of symbols**

The following symbols are on the product/appliance or are used in the text:



- The symbol warns of hazards that can lead to personal injury.

## **Safety instructions**

Read the operating instructions carefully and especially observe the safety information. If you do not follow the safety instructions and information on proper handling, we assume no liability for any resulting personal injury or damage to property. Such cases will invalidate the warranty/guarantee.

## **General**

- The product is not a toy. Keep it out of the reach of children and pets.
- Do not leave packaging material lying around carelessly. This may become dangerous playing material for children.
- If you have questions which remain unanswered by this information product, contact our technical support service or other technical personnel.
- Maintenance, modifications and repairs must only be completed by a technician or an authorised repair centre.

## **Handling**

- Handle the product carefully. Jolts, impacts or a fall even from a low height can damage the product.

## **Operating environment**

- Do not place the product under any mechanical stress.
- Protect the appliance from extreme temperatures, strong jolts, flammable gases, steam and solvents.
- Protect the product from high humidity and moisture.
- Protect the product from direct sunlight.

## **Operation**

- Consult an expert when in doubt about the operation, safety or connection of the product.
- If it is no longer possible to operate the product safely, take it out of operation and protect it from any accidental


use. DO NOT attempt to repair the product yourself. Safe operation can no longer be guaranteed if the product:

- is visibly damaged,
- is no longer working properly,
- has been stored for extended periods in poor ambient conditions or
- has been subjected to any serious transport-related stresses.

## Battery

- Correct polarity must be observed while inserting the battery.
- The battery should be removed from the device if it is not used for a long period of time to avoid damage through leaking. Leaking or damaged batteries might cause acid burns when in contact with skin, therefore use suitable protective gloves to handle corrupted batteries.
- Batteries must be kept out of reach of children. Do not leave batteries lying around, as there is risk, that children or pets swallow them.
- Batteries must not be dismantled, short-circuited or thrown into fire. Never recharge nonrechargeable batteries. There is a risk of explosion!

## Product Overview



1. Indicator light
2. Pairing butt


## Indications

Component	State	Indication
Indicator light	Off	The standby mode is activated
Indicator light	Flashes 1x	The sensor sent a reading.
Indicator light	Flashing	The pairing mode is activated

## Installing batteries

### Note

If an insulating strip protrudes from the battery compartment, batteries are installed already. Pull the strip out to establish the power supply.



1. Prepare the required number of batteries of the correct type as stated in the section “Technical data”.
2. Pry off the cover of the product with the supplied pry tool. See A in the above figure.
3. With the plus pole (+) facing up, insert the battery into the battery slot.
4. (If needed) loop the string through the opening in the cover. See B in the above figure.
5. Align the cover as indicated by C in the above figure and then snap-lock the cover.

### Note:

Replace the battery/batteries under the following conditions:

- If the product can no longer be connected to the network.
- If the home network dashboard (example: mobile app) indicates a flat battery/batteries.
- At least once a year.

## Network connection

Connecting the product to the Zigbee gateway (item no. 3026091)

1. Refer to the operating instructions of the Zigbee gateway (3026091) to learn how to connect new devices.
2. Switch the product into pairing mode by pressing and holding the pairing button until the indicator light flashes.

3. Connect the product to the gateway.

### **Adding the product to the Home Assistant**

You can integrate the product into Home Assistant in two ways:

- Using the Zigbee Home Automation integration
- Using Zigbee2MQTT

1. Switch the product into pairing mode by pressing and holding the pairing button until the indicator light flashes.
2. Connect the product to the Home Assistant control system.

### **Cleaning and care**

#### **Important:**

- Do not use aggressive cleaning agents, rubbing alcohol, or other chemical solutions.
- They damage the housing and can cause the product to malfunction.
- Do not immerse the product in water.

1. Clean the product with a dry, fibre-free cloth.

### **Declaration of Conformity (DOC)**

Conrad Electronic SE, Klaus-Conrad-Straße 1, D-92240 Hirschau hereby declares that this product conforms to the 2014/53/EU directive.

- Click on the following link to read the full text of the EU declaration of Conformity:  
[www.conrad.com/downloads](http://www.conrad.com/downloads)
- Enter the product item number in the search box. You can then download the EU declaration of conformity in the available languages.

### **Disposal Product**

This symbol must appear on any electrical and electronic equipment placed on the EU market. This symbol indicates that this device should not be disposed of as unsorted municipal waste at the end of its service life. Owners of WEEE (Waste from Electrical and Electronic Equipment) shall dispose of it separately from unsorted municipal waste. Spent batteries and accumulators, which are not enclosed by the WEEE, as well as lamps that can be removed from the WEEE in a non-destructive manner, must be removed by end users from the WEEE in a non-destructive manner before it is handed over to a collection point.



Distributors of electrical and electronic equipment are legally obliged to provide free takeback of waste. Conrad provides the following return options free of charge (more details on our website):

- in our Conrad offices
- at the Conrad collection points

- at the collection points of public waste management authorities or the collection points set up by manufacturers or distributors within the meaning of the ElektroG

End users are responsible for deleting personal data from the WEEE to be disposed of.

It should be noted that different obligations about the return or recycling of WEEE may apply in countries outside of Germany.

### **(Rechargeable) batteries**

Remove batteries/rechargeable batteries, if any, and dispose of them separately from the product. According to the Battery Directive, end users are legally obliged to return all spent batteries/rechargeable batteries; they must not be disposed of in the normal household waste.

Batteries/rechargeable batteries containing hazardous substances are labelled with this symbol to indicate that disposal of household waste is forbidden. The abbreviations for heavy metals in batteries are Cd = Cadmium, Hg = Mercury, and Pb = Lead (name on (rechargeable) batteries, e.g. below the trash icon on the left).



- Used (rechargeable) batteries can be returned to collection points in your municipality, our stores, or wherever (rechargeable) batteries are sold. You thus fulfill your statutory obligations and contribute to environmental protection.
- Batteries/rechargeable batteries that are disposed of should be protected against short circuits and their exposed terminals should be covered completely with insulating tape before disposal. Even empty batteries/rechargeable batteries can contain residual energy that may cause them to swell, burst, catch fire, or explode in the event of a short circuit.

### **Technical data**

- Battery ..... 1x CR2032
- Temperature measuring range..... -20 to +60 °C
- Standard..... IEEE 802.15.4
- Zigbee integrations..... Zigbee gateway (Item no. 3026091)
  - Home Assistant via Zigbee integration
  - Home Assistant via Zigbee2MQTT
- Wireless frequency ..... 2.405 – 2.480 GHz
- Wireless range ..... max. 90 m (open space)
- Wireless transmission power ..... max. 10 dBm
- Operating temperature ..... -20 to +60 °C
- Operating humidity ..... 0 – 95 % RH (non-condensing)
- Storage temperature ..... -20 to +60 °C
- Storage humidity ..... 0 – 95 % RH (non-condensing)
- Dimensions (W x H x D) (approx.). 35 x 35 x 8 mm
- Weight (approx.) ..... 9 g (including batteries)

This is a publication by Conrad Electronic SE, Klaus-Conrad-Str. 1, D-92240 Hirschau ([www.conrad.com](http://www.conrad.com)).

All rights including translation reserved. Reproduction by any method (e.g. photocopying, microfilming, or the capture in electronic data processing systems) requires prior written approval from the editor. Reprinting, also in




part, is prohibited.

This publication reflects the technical status at the time of printing.

Copyright by Conrad Electronic SE. \*3026093\_V1\_0424\_jh\_mh\_en 27021599046013067 I4/O1 en

## Documents / Resources

	<p><a href="#">sygonix 3026093 Zigbee Temperature and Humidity Sensor</a> [pdf] Instruction Manual SY-6052186, 3026093 Zigbee Temperature and Humidity Sensor, 3026093, Zigbee Temperature and Humidity Sensor, Temperature and Humidity Sensor, Humidity Sensor, Sensor</p>
---	--

## References

- [Conrad Electronic » All parts of success](#)
- [Download center](#)
- [User Manual](#)

### Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.