



Sytech SYPV21A Steam Iron User Manual

[Home](#) » [Sytech](#) » Sytech SYPV21A Steam Iron User Manual 

Contents

- [1 Sytech SYPV21A Steam Iron](#)
- [2 Safety Instructions](#)
- [3 Descriptions of Parts](#)
- [4 Before first use](#)
- [5 Setting the temperature](#)
- [6 Ironing with Steam](#)
- [7 Self Cleaning](#)
- [8 Cleaning & Maintenance](#)
- [9 Storage](#)
- [10 Specifications](#)
- [11 Declaration of Conformity](#)
- [12 Documents / Resources](#)
- [13 Related Posts](#)



Sytech SYPV21A Steam Iron



Welcome


Congratulations on the purchase of your new steam iron SY-PV21. In order to fully benefit from this product please read the following instructions carefully. Store this user manual in a safe place for future references.

Safety Instructions

- Use the iron only for its intended use.
- Make sure that the voltage on the rating label of the iron corresponds to the wall outlet voltage.
- When using the iron for the first time, test it on an old piece of fabric to ensure that the soleplate and boiler are completely clean.
- To protect against the risk of electric shock, do not immerse the iron in water or other liquids.
- The temperature setting must always be turned to “min” before plugging or unplugging from the mains outlet.
- Never pull the cord to disconnect from the mains: instead, grasp the plug and pull to disconnect.
- Do not allow the cord to touch hot surfaces. Allow the iron to cool completely before storing away.
- Always disconnect the iron from the electrical outlet when filling with water or emptying when not in use
- Keep the sole plate smooth at all times, avoid hard contact with a metal object.
- Do not operate the iron with a damaged cord or if the iron has been dropped or damaged. To avoid the risk of electric shock, do not disassemble the iron. Contact Sytech Service Centre. Incorrect re-assembly can cause a risk of electric shock when the iron is used.
- If the supply cord is damaged, contact Sytech Service Centre
- If the iron is not operating normally, disconnect it from the power supply. Contact Sytech Service Center.
- Close supervision is necessary for any appliance being used by or near children. Do not leave the iron unattended when connected to the mains or on an ironing board.
- Children should be supervised to ensure that they do not play with the appliance.

- Burns can occur from touching the hot metal parts, hot water or steam.
- Be extremely careful when you turn a steam iron upside down as there may be hot water in the reservoir.
- Your iron is designed to rest on the heel. Do not leave the iron unattended when switched on. Do not place the iron on an unprotected surface even if it is on its heel rest.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Keep electrical appliances out of reach from Children or infirm persons. Do not let them use the appliances without supervision.

Descriptions of Parts



Before first use

1. Some parts of the iron have been slightly greased and as a result, the iron might smoke slightly when switched 'ON' for the first time. After a short while, this will cease.
2. Before using for the first time, remove any sticker or protective foil from the soleplate with a soft cloth.
3. Keep the soleplate smooth: do not scratch the unit against metal objects (e.g. rack of the ironing board, buttons, zippers)

Setting the temperature

1. Always check to see whether ironing instructions are attached to the article to be ironed (they can be found on

- a label showing a symbol of an iron. The numbers of dots indicate the correct temperature. Refer to the indications on the temperature dial and in the table below). Follow these ironing instructions in all cases.
2. If ironing instructions are missing but you do know the kind of fabric, then see the table below. The table is valid for the actual materials and do not concern any applied finish, gloss etc.
 3. Textile to which some kind of finish has been applied (gloss, wrinkle relief etc.) can best be ironed on lower temperatures.
 4. Sort the fabrics out according to ironing temperature first: wool with wool, cotton with cotton, etc. The iron heats up quicker than it cools down. Therefore, start ironing the clothes that require the lowest temperature, and then progress to higher ones.
 5. Turn the temperature control knob round until it is opposite the setting pointer.

Filling water

1. Make sure the switch is disconnected to the wall outlet before filling water.
2. Set the steam control knob to the "0" position.
3. Pull down the cover of the water filling mouth and fill water until the reservoir is filled up.
4. Never exceed the MAX level as marked on the unit.
5. Check the water level through the transparent tank and make sure it does not surpass the max level.

Note: Tap water can be used for this type of iron. Do not use water additives or substitute water such as scented water. This can damage the steam iron.

Dry Ironing

1. Position the steam iron vertically.
2. Plug in the switch
3. Set the temperature control dial to "MIN" position
4. Preheat the iron until the indicator light turns off
5. Start the dry ironing

Ironing with Steam

1. Position the iron vertically and turn the Temperature Control Dial to the steam position.
 2. Plug the Cord into the electrical outlet.
 3. Set the Temperature Control Dial to the steam position. Steam Ironing is only possible when at higher temperature settings indicated with the 'MAX' mark; otherwise, the water will leak from the soleplate.
 4. Preheat the iron until the indicator light goes out. The light will turn off when the indicated setting reaches the correct temperature.
 5. Turn the Variable Steam Control Knob to the required setting for different types of fabric.
- Now steam ironing can begin.
 - Ensure that there is enough water in the water reservoir at all times
 - Rest the iron on its heel when not using
 - Press the steam burst button to emit an intense burst of steam from the soleplate.
 - In order to avoid water leaking from the soleplate, do not press the steam button for too long

How to use the burst of steam

The burst of steam feature provides additional steam for removing thick wrinkles. It may be used during steam or dry ironing.

- Press the Power Steam button to release the burst of steam.
- Pressing the button several times may be necessary to activate the system.
- Wait a few seconds for the steam to penetrate the fabric before pressing the button again for more steam.

Note: For optimum steam quality, do not apply more than three successive shots after the indicator light goes off.

Spraying

Before using the spray feature, check the fabric label for ironing instructions as some fabrics may be easily damaged with moisture.

Press the spray button and water will be sprayed out from the spraying nozzle. Make sure there is water in the reservoir at all times.

Self Cleaning

Your iron will give the best ironing results and last longest if you apply the Self Cleaning once a month, or more depending upon the usage.

1. Fill the water tank until it is half-full.
2. Position the iron on its rear heel.
3. Select the temperature control dial to 'MAX'.
4. Plug the iron.
5. Allow the iron to heat up until the indicator light first goes out.
6. Unplug the iron from the electrical outlet.
7. Keep the iron horizontally over the sink.
8. Set the variable steam knob at maximum position. Boiling water and steam will now emit from the holes in the soleplate.
9. Move the iron forwards and backwards while this happens; go on letting steam and water escape until the water tank is virtually empty.
10. Turn the variable steam knob to '0' position.
11. Plug in the iron
12. Set the temperature dial to the 'MAX' position, let the iron heat up again, the remainder of the water inside the steam chamber will now vaporize and leave the iron through the soleplate.

Anti-Drip

The appliance is fitted with an anti-drip device to enhance steaming and prevent drips of water from the soleplate

Anti-Calc

The appliance is fitted with an anti-calc device to reduce the lime-scale build up in the water tank and extend the product life.

To prolong the efficiency of this system, follow the below steps:

- Unplug the iron and allow it to cool down
- Fill the water cup $\frac{3}{4}$ and add a teaspoon of salt water and then fill the water tank
Keep the salted water inside for about 15 minutes, shaking the iron from time to time and Then empty it.
- Repeat the same above process by filling the tank with salt water. Shake it occasionally and after 15 minutes, empty the tank.
- Fill in the water tank with fresh water this time and rinse it after 5 minutes.

Cleaning & Maintenance

- Set the steam control to the lowest position and remove the plug from the wall socket allowing for the unit to cool down completely
- Once it has cooled down, wipe the soleplate with a damp cloth and a non-abrasive (liquid) cleaning agent.
- To keep the soleplate smooth, avoid contact with hard metal objects. Never use a scouring pad, vinegar or other chemicals to clean the soleplate.
- Clean the upper part of the iron with a damp cloth.
- Regularly rinse the water tank with water. Empty the water tank after you have rinsed it.

Storage

- Set the steam control position to the lowest position and remove the plug from the wall socket allowing the unit to cool down completely.
- Pour out any remaining water left in the water tank.
- Wind up the mains cord.
- Store the iron on its heel (Vertically) and in a safe and dry place.

Specifications

Professional Steam Iron

Ceramic Soleplate

Anti drip, Anti calc and Self clean functions Overheating safety protection Temperature and vapour regulator

360° rotating cable

Cool touch rubber handle

Burst of steam: 10-20g/m

Water tank capacity: 320ml

Power: 2200W

Voltage: 220-240V– 50Hz

Sole plate dimensions: 23,2 x 11,8 x 0.4 cm Unit dimensions: 15 x 11,5 x 29,5 cm Weight: 1,06 Kg.

Included: water measuring cup



Environment

This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

Declaration of Conformity

Manufacturer name: Satyatrade S. L.

Address: Pol. Ind. La Raya. C/ Guadalquivir, 2.

Camarma de Esteruelas, 28816 Madrid

Tel: 902 430 967

Fax: 91 8864285

NIF: B83254763

Manufacturing country: China

Description: Steam Iron

Sytech® SY-PV21 complies with the following directives.

EMC Standards: Directive 2014/30/EU


LVD Standards: Directive 2014/35/EU

RoHS Standards: Directive 2011/65/EU Restriction of Hazardous Substances.

Signed: Ajeet Nebhwani Utamchandani

Sole Administrator

Documents / Resources

	<p>Sytech SYPV21A Steam Iron [pdf] User Manual SYPV21A, Steam Iron</p>
---	--

Manuals+.