




T NICER T1 Bluetooth Intercom User Guide

[Home](#) » [T NICER](#) » T NICER T1 Bluetooth Intercom User Guide 












T1 Quick operation guide
























































Contents

- [1 T1 Bluetooth Intercom](#)
- [2 Description for installation](#)
- [3 Documents / Resources](#)
- [4 Related Posts](#)


T1 Bluetooth Intercom

	Function	Current state	Operate	Voice prompt
	Power on			Ai ride with you
	Power off			Thanks for using, bye
	Charging			
	Power to detect	/		Voice prompt of battery power
				
	Bluetooth pairing			Matching state
	Answering calls			/
	Hang up			/
	Refuse calls			/
	Redial of last number			/
	Turn up call volume			du
	Turn down call volume			du
	Voice assistant			/


		           	du
The function of clearing memory	Clear Bluetooth pairing	  	Clear Bluetooth pairing
	Clear Mesh networking records	  	Clear Mesh networking records
	Enter the network intercom state	 	Matching state
	Start the Bluetooth intercom network	 	Search
	Open intercom Close intercom	 	/
	Turn up intercom volume	 	/
	Turn down intercom volume	 	/
		 	
	Open Mesh		Open Mesh
	Close the Mesh		Close the Mesh
	Start Mesh networking		Start Mesh networking MESH networking is successful
	Turn up the intercom volume		du

	Turn down the intercom volume	  	
		  	du
Multichannel mixing	MESH intercom network	      	
	MESH intercom network	    	
		  	


Description for installation




1 Install the main unit into the base




2 Attach the double-sided adhesive pad to the base




3 Glue the base to the helmet




Use clamp




1 Paste the rubber pad on the base, and then mount the host into the base



2 Load the fixture into the base



3 Load the fixture into the helmet



Follow the official WeChat account for more information

 CityGo WeChat	 Airide WeChat	 Airide Trill
 This APP (Apple)	 This APP (Android)	 Install the demonstration
https://apps.apple.com/cn/app/id1541566662	https://www.pgyer.com/C8L3	https://mp.weixin.qq.com/s/cBU_GuI5D3BELO35W6SvTA



Factory address: Fuyuan Industrial City, Hangcheng Street, Baoan District, Shenzhen, China
Contact: 0755-21508589

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: changes or modifications not expressly approved by the party responsible for compliance could void the

user’s authority to operate the equipment The device has been evaluated to meet general RF exposure requirements the device can be used in portable exposure conditions without restriction

Documents / Resources

	<p>T NICER T1 Bluetooth Intercom [pdf] User Guide</p> <p>T1, 2A8OA-T1, 2A8OAT1, T1 Bluetooth Intercom, T1 Intercom, Bluetooth Intercom, Intercom, H elmet Bluetooth, Helmet Intercom, Helmet Bluetooth Intercom</p>
--	---

Manuals+.