



TaNix TaNix07 Bluetooth Audio Adapter User Manual

[Home](#) » [Support](#) » TaNix TaNix07 Bluetooth Audio Adapter User Manual 

Contents

- [1 TaNix TaNix07 Bluetooth Audio Adapter](#)
- [2 Introduction](#)
- [3 Specifications](#)
- [4 What's in the Box](#)
- [5 Key Features](#)
- [6 How to Use](#)
- [7 Bluetooth](#)
- [8 Troubleshooting](#)
- [9 FAQs](#)



TaNix TaNix07 Bluetooth Audio Adapter



Introduction

The TaNix TaNix07 Bluetooth Audio Adapter is a versatile and compact device designed to enhance your audio experience by adding Bluetooth connectivity to non-Bluetooth audio sources. Whether you want to wirelessly stream music from your smartphone to your home stereo system or connect your TV to Bluetooth headphones, the TaNix07 offers a convenient solution. This comprehensive guide will provide an overview of the adapter's specifications, what's included in the box, key features, how to use it, safety guidelines, maintenance tips, and troubleshooting techniques.

Specifications

- **Bluetooth Version:** Bluetooth 5.0
- **Supported Audio Codecs:** SBC, AAC, aptX, aptX Low Latency
- **Range:** Up to 33 feet (10 meters)
- **Interfaces:** 3.5mm AUX-in and AUX-out, Optical, Coaxial
- **Power Supply:** USB or DC 5V/500mA
- **Dimensions:** [Provide dimensions here]
- **Weight:** [Provide weight here]

What's in the Box

- TaNix TaNix07 Bluetooth Audio Adapter
- 3.5mm Audio Cable
- RCA to 3.5mm Audio Cable
- Optical Cable
- Coaxial Cable
- USB Power Cable
- User Manual

Key Features

- **Bluetooth Connectivity:** Easily connect your Bluetooth-enabled devices such as smartphones, tablets, and laptops to non-Bluetooth audio equipment.
- **Wide Compatibility:** The adapter supports multiple audio interfaces, including 3.5mm AUX-in and AUX-out, Optical, and Coaxial, making it compatible with a variety of audio sources and devices.
- **High-Quality Audio:** Benefit from support for various audio codecs, including aptX and aptX Low Latency, delivering superior sound quality and reduced audio lag for video content.
- **Dual Link:** Connect two Bluetooth devices simultaneously, allowing you to switch between audio sources seamlessly.
- **Easy Pairing:** Pairing is hassle-free and quick, thanks to Bluetooth 5.0 technology.
- **Volume Control:** Adjust the volume directly from the adapter or use your connected device's controls.
- **LED Indicator:** The LED indicator provides information on the Bluetooth status and connection.
- **Auto-Reconnect:** Automatically reconnects to previously paired devices when they come into range.

Works With Most Device



How to Use

1. Initial Setup:

- Connect the TaNix07 to your audio source using the appropriate cable (3.5mm, Optical, or Coaxial).
- Connect the adapter to power using the included USB cable and power adapter or any USB power source.
- Turn on the adapter by pressing and holding the power button for a few seconds.

2. Pairing:

- Activate Bluetooth on your smartphone, tablet, or other Bluetooth-enabled device.


- Put the TaNix07 into pairing mode by pressing and holding the Bluetooth button until the LED indicator blinks rapidly.
- Select “TaNix07” from the list of available Bluetooth devices on your device’s Bluetooth menu.

3. Audio Playback:

- Play audio on your paired device, and the sound will be wirelessly transmitted to the connected audio source.

4. Switching Between Devices (Dual Link):

- Pair a second Bluetooth device by putting the adapter into pairing mode again.
- To switch between devices, pause audio on one device and play it on the other.



Safety Guidelines

- **Read the User Manual:** Before using the TaNix07 Bluetooth Audio Adapter, thoroughly read and understand the user manual provided with the product. Familiarize yourself with its features, specifications, and operating instructions.
- **Keep Away from Water:** The TaNix07 Bluetooth Audio Adapter is an electronic device and is not water-resistant. Keep it away from water sources, such as sinks, bathtubs, swimming pools, or rain. Do not expose it to moisture, as this can cause electrical shorts and damage.
- **Proper Ventilation:** Ensure that the adapter is placed in a well-ventilated area to prevent overheating. Do not cover it with any materials that may obstruct airflow.
- **Power Source:** Use only the provided power adapter and cables or those recommended by the manufacturer. Do not use damaged or frayed cables, as they can pose electrical hazards.
- **Power Outlets:** When connecting the adapter to a power outlet, make sure the outlet is in good condition and properly grounded. Avoid overloading the outlet with too many devices, as this can lead to electrical issues.
- **Temperature:** Operate the TaNix07 Bluetooth Audio Adapter within the specified temperature range as

mentioned in the user manual. Extreme temperatures can affect its performance and longevity.

- **Placement:** Place the adapter on a stable and flat surface to prevent it from falling or tipping over. Ensure that it is not subjected to physical stress or vibrations that could damage internal components.

DUAL DEVICES SWITCHING



- **Child Safety:** Keep the adapter and its cables out of the reach of children and pets to prevent accidental ingestion or damage. Children should not play with the adapter.
- **Cleaning:** To clean the adapter, use a soft, dry cloth. Do not use abrasive or chemical cleaners, as they may damage the device's surface.
- **Firmware Updates:** Periodically check for firmware updates from the manufacturer. These updates may include important security patches and improvements to the device's performance.
- **Pairing Security:** When pairing the TaNix07 Bluetooth Audio Adapter with your devices, use secure and trusted connections. Avoid pairing with unknown or unauthorized devices to prevent potential security breaches.
- **Disconnect When Not in Use:** To conserve power and maintain security, disconnect the adapter when it is not in use or when you are away from the paired devices.
- **Caution with Volume:** Be cautious when adjusting the volume through the adapter. High volume levels, especially with headphones, can cause hearing damage. Start with a low volume and gradually increase it to a comfortable level.

Bluetooth



Bluetooth5.0+ EDR



Maintenance

- **Cleaning:** Keep the adapter clean and free from dust or debris. Use a soft, lint-free cloth to wipe the exterior surfaces regularly. Avoid using abrasive materials or harsh cleaning chemicals.
- **Proper Storage:** When not in use, store the Bluetooth audio adapter in a dry, cool place away from direct sunlight and extreme temperatures. Using the provided carrying case or a protective cover can help prevent damage and maintain its appearance.
- **Firmware Updates:** Check for firmware updates provided by TaNix. Periodically updating the firmware can improve compatibility, fix bugs, and enhance performance.
- **Check Cables and Connections:** Inspect the adapter's cables and connections for any signs of wear or damage. Replace any damaged cables or connectors promptly to ensure uninterrupted functionality.
- **Keep Away from Water:** Avoid exposing the Bluetooth audio adapter to moisture or liquids. Water can damage internal components and cause malfunctions.
- **Power Source:** Ensure that the adapter is connected to a stable and appropriate power source. Using the wrong voltage or an unstable power supply can lead to damage.
- **Antenna Positioning:** If your Bluetooth adapter has an external antenna, make sure it is positioned properly for optimal signal strength and connectivity. Check that the antenna connection is secure.
- **Pairing Devices:** If you experience connectivity issues, such as difficulty pairing with your Bluetooth-enabled devices, refer to the user manual for troubleshooting instructions. Sometimes, unpairing and re-pairing devices can resolve connectivity problems.
- **Keep Software Up to Date:** Ensure that the devices you connect to the adapter, such as smartphones or tablets, have up-to-date Bluetooth drivers and software. Keeping your devices' software current can help maintain a stable connection.
- **Ventilation:** Allow proper ventilation around the Bluetooth audio adapter to prevent overheating. Ensure that there are no obstructions near the device's vents or cooling areas.
- **Resetting:** If you encounter persistent issues, consider performing a factory reset (if supported) as a troubleshooting step. This can reset the device to its default settings and resolve certain problems.
- **Contact Customer Support:** If you encounter technical issues that you cannot resolve on your own, contact TaNix's customer support for guidance and assistance.



Troubleshooting

Problem 1: Bluetooth Pairing Issues

- **Solution:**

1. Ensure that the TaNix07 adapter is in pairing mode. Typically, this is done by pressing and holding the Bluetooth button until the LED indicator flashes rapidly.
2. Make sure your Bluetooth-enabled audio source (e.g., smartphone, tablet, or computer) is also in pairing mode and within range of the adapter.
3. Disable and re-enable the Bluetooth function on your audio source.
4. Delete any previous pairings on both the audio source and the adapter, then attempt the pairing process again.
5. Ensure there are no other active Bluetooth devices nearby that might interfere with the pairing process.

Problem 2: No Audio Output or Poor Sound Quality

- **Solution:**

1. Check that the TaNix07 adapter is properly connected to your audio source via the provided audio cable.
2. Verify that the adapter is connected to a power source and has sufficient battery or is charging.
3. Ensure the volume on your audio source is turned up and not muted.
4. If there is interference or a weak Bluetooth connection, move the audio source closer to the adapter or remove obstacles that may block the signal.
5. If using the adapter in a noisy environment, try adjusting the audio source's equalizer settings to enhance sound quality.

Problem 3: Audio Lag (Latency) During Video Playback

- **Solution:**

1. The TaNix07 adapter may introduce audio latency, which can be noticeable when watching videos. Consider using a Bluetooth transmitter with low-latency support, or connect directly via a wired connection for video playback.
2. Some devices offer settings to adjust audio delay to sync it with video. Check if your audio source has such an option and adjust it accordingly.

Problem 4: Adapter Not Charging or Short Battery Life

- **Solution:**

1. Make sure you are using the provided USB cable and power adapter for charging. Using third-party accessories may not provide sufficient power.
2. Ensure that the adapter's battery is not fully depleted before attempting to charge it.
3. Allow the adapter to charge for an adequate amount of time. Charging times may vary, but it's typically a few hours.
4. If the battery life remains short, it may be time to replace the built-in rechargeable battery in the adapter.

Problem 5: Unable to Connect to Multiple Devices Simultaneously

- **Solution:**

1. Check the product specifications and ensure that the TaNix07 adapter supports simultaneous connections to multiple devices. Some Bluetooth adapters are designed for single-device use.
2. If the adapter is supposed to support multiple connections and you are experiencing issues, try resetting the adapter to its factory settings and then attempt the pairing process again.

Problem 6: Adapter Not Turning On or Unresponsive

- **Solution:**

1. Ensure that the adapter is charged or connected to a power source.
2. Attempt to reset the adapter by holding down the power or Bluetooth button for an extended period. Consult the user manual for specific reset instructions.
3. If the adapter remains unresponsive, contact the manufacturer's customer support for further assistance.

FAQs

What is the TaNix TaNix07 Bluetooth Audio Adapter?

The TaNix TaNix07 is a Bluetooth audio adapter that allows you to wirelessly connect your audio devices to Bluetooth-enabled speakers or headphones.

Is the TaNix07 compatible with all audio devices?

The TaNix07 is compatible with most audio devices that have a 3.5mm audio output, including smartphones, tablets, and computers.

What version of Bluetooth does it support?

The TaNix07 supports Bluetooth version 5.0, providing a stable and efficient connection.

Can I use it with my non-Bluetooth headphones or speakers?

Yes, you can use the TaNix07 to add Bluetooth connectivity to your non-Bluetooth headphones or speakers.

What is the range of the Bluetooth connection?

The TaNix07 has a Bluetooth range of up to 33 feet (10 meters), allowing you to move freely while maintaining a strong connection.

How do I pair my device with the TaNix07?

To pair your device, simply put the TaNix07 in pairing mode, and then search for it in your device's Bluetooth settings and connect.

Does it support aptX or AAC audio codecs?

Yes, the TaNix07 supports aptX and AAC audio codecs, providing high-quality audio streaming.

Can I use it for hands-free calling?

Yes, the TaNix07 has a built-in microphone, allowing you to make and receive calls hands-free when connected to your smartphone.

How long does the battery last on the TaNix07?

The TaNix07 has a battery life of approximately 8 hours of continuous playback, depending on usage.

Is it compatible with voice assistants like Siri or Google Assistant?

Yes, you can use the TaNix07 to activate voice assistants on your paired devices.

Does it come with a warranty?

Yes, the TaNix07 typically comes with a one-year warranty to cover any manufacturing defects.

What is included in the TaNix07 package?

The TaNix07 package typically includes the Bluetooth adapter, a 3.5mm audio cable, a USB charging cable, and user instructions.

Download This PDF Link: [Lewitt LCT 640 TS Dual-Output-Mode Condenser Microphone User Manual](#)

[Manuals+](#).