



TAP Black-R Clarinet and Saxophone Sensor Instructions

[Home](#) » [TAP](#) » TAP Black-R Clarinet and Saxophone Sensor Instructions 

TAP Black-R Clarinet and Saxophone Sensor Instructions



Contents

- [1 FEATURES – INSTRUCTIONS](#)
- [2 INSTALLATION](#)
- [3 Documents / Resources](#)
- [4 Related Posts](#)

FEATURES – INSTRUCTIONS

TAP clarinet (and saxophone) sensor (mic) is handmade pre adjusted. It is made to be noise-free and able to match all Amps and consoles, with build-in output jack (3.5mm).

Perfectly balanced, with a natural undistorted clarinet sound. The sensor has a big dynamic range on high frequencies. The mic does not pick up the “clicking” noise, produced by the instrument’s key due to its internal noise isolation. Black- R comes with volume control. Also the sensor has humidity isolation. Don’t forget to put on the rubber ring(s) before screwing the sensor to avoid air leak.

INSTALLATION




Drill hole 5.2mm on the barrel. Make the threading with {M6} hand tap cutting tool. Finish the edges of the hole with rasp. Screw the Adapter into the threading. Put the rubber ring on the Mic-sensor. Screw with care the Mic-sensor into the adaptor. Twist the cable on the barrel for protection.

Maintenance: Always keep the sensor on the top direct on your eyes. Unscrew the sensor and wipe with soft paper. Never miss to unscrew sensor from the clarinet when not in use.

Warning : Never use hard tools or items on sensor surface. The installation recommended to be done by a technician.



Documents / Resources

	<p>TAP Black-R Clarinet and Saxophone Sensor [pdf] Instructions Black-R, Black-R Clarinet and Saxophone Sensor, Clarinet and Saxophone Sensor, Saxophone Sensor</p>
---	---