



TECHLIGHT 220 Lumen Solar Rechargeable Wall Light with PIR Sensor User Manual

[Home](#) » [TECHLIGHT](#) » TECHLIGHT 220 Lumen Solar Rechargeable Wall Light with PIR Sensor User Manual 

TECHLIGHT 220 Lumen Solar Rechargeable Wall Light with PIR Sensor User Manual



Contents

- [1 Specification](#)
- [2 Features](#)
- [3 Installation](#)
- [4 Notice:](#)
- [5 Warning:](#)
- [6 Working Modes](#)
- [7 Documents / Resources](#)
- [8 Related Posts](#)

Specification

Power	1.5W
Lumens	220LM
LEDs	SMD2835*14PCS (Front 12PCS+Back2PCS)
LI-ion Battery	90
Beam Angle	1200mAh/3.7v
Solar Panel	0.7W,poly-crystalline silicon
Detection Angle/ Area	120/<6m
IP Degree	IP65 Waterproof
Lifepan	35,000hrs
Installation Hieght	<4m

Features

- Easy & quick installation Light on/off
- No operational cost Automatically
- PIR sensor 6m detection range
- IP65 waterproof 2 modes
- Light on/off Automatically

- 6m detection range
- 2 modes

Distributed by:

TechBrands by Electus Distribution Pty. Ltd.
 320 Victoria Rd, Rydalmere NSW 2116 Australia
 Ph: 1300 738 555
 Intl: +61 2 8832 3200
 Fax: 1300 738 500 www.techbrands.com

Installation



1. Please use the card to measure hole position correctly and drill 2 holes of 6mm diameter.
2. Fix 2 expansion plugs into the holes.
3. Fix a screw to the lower expansion plug, insert the notch onto the screw.
4. Straighten the whole lamp and fasten the upper screw.
5. Press the button to adjust to required working mode.


Notice:

1. This is a solar powered lamp, install in location where it can receive enough sunshine.
2. Lighting time depends on sunshine duration and weather. This is a solar powered lamp, install in location where it can receive enough sunshine.
3. Lamp lights up automatically at dusk.
4. Built-in intelligent IC with over-charge, over-discharge and over-voltage protection.

Warning:

1. The lamp is equipped with an internal lithium battery, which is not replaceable. Please do not dispose of it with household garbage.
2. Non-professionals please do not disassemble the lamp.

Working Modes



Press the Button to adjust working mode:

Press 1st time for Mode A.

Press 2nd time for Mode B.

Press 3rd time for off.

Mode A:




Automatically turns on to full brightness (220lm) when motion is detected in the range 6m, and then turns to weak brightness (front light on and back light on) in 10 seconds if no motion.

Mode B:



Automatically turns on to full brightness (220lm) when motion is detected in the range 6m and then turns to weak brightness (front light off and back light on) in 10 seconds if no motion.

Documents / Resources

	TECHLIGHT 220 Lumen Solar Rechargeable Wall Light with PIR Sensor [pdf] User Manual TECHLIGHT, SL-3512, Solar Rechargeable Wall Light, PIR Sensor
---	--