



2BB8X-PRECHECKER Tel RFID Reader for PR Pre-Checker PR Management System Instruction Manual

[Home](#) » [TEL](#) » 2BB8X-PRECHECKER Tel RFID Reader for PR Pre-Checker PR Management System Instruction Manual 

TEL



13.56MHz PR Management System PrecheckerManual

Contents

- [1 Warnings](#)
- [2 Device Features](#)
- [3 Specifications](#)
- [4 User Manual](#)
- [5 Documents / Resources](#)

Warnings

1. Avoid dropping from height or yielding impact.
It may cause serious damage to the device.
2. Professional servicing only.

It may cause injury and/or malfunction to the unit.

3. Remove the charger during lightning storms.

It may cause lightning strike and/or fire.

4. Do not use in high temperatures, humidity or around explosive atmospheres.

It may effect the high-frequency device.

5. Do not dismantle or yield impact.

It may lead to shock or short-circuiting.


6. Do not remove the antenna during operation.

It may lead to poor performance. Please remove after powering down.

7. Do not throw away in fire or take apart the device.

It may lead to fire or explosion.

Device Features



Specifications

Power Supply	5V operation
Supply Current	120mA @5V
Dimensions	77 x 120 x 22 mm
RfFrequency	13.56MHz
RF Data Rate	26kbps ISO-15693
Reading Range	20mm

User Manual

1. Put up the PR Bottle to the PreChecker for recognition.
2. Buzzer will go off when there are no problem with the PR Bottle TAG.
3. Remove PR Bottle.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE: THE GRANTEE IS NOT RESPONSIBLE FOR ANY CHANGES OR MODIFICATIONS NOT EXPRESSLY APPROVED BY THE PARTY RESPONSIBLE FOR COMPLIANCE. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO PERATE THE EQUIPMENT.

The user manual for an intentional or unintentional radiator shall caution the user that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

RF Radiation Exposure Statement:


This equipment complies with FCC/ISED radiation exposure limits set forth for an uncontrolled environment and meets the FCC radio frequency (RF) Exposure Guidelines and RSS-102 of the ISED radio frequency (RF) Exposure rules as this

equipment has very low levels of RF energy.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Documents / Resources

	<p><u>TEL 2BB8X-PRECHECKER Tel RFID Reader for PR Pre-Checker PR Management System</u></p> <p>[pdf] Instruction Manual</p> <p>2BB8X-PRECHECKER, 2BB8XPRECHECKER, 2BB8X-PRECHECKER Tel RFID Reader for PR Pre-Checker PR Management System, Tel RFID Reader for PR Pre-Checker PR Management System, RFID Reader for PR Pre-Checker PR Management System, Reader for PR Pre-Checker PR Management System, PR Pre-Checker PR Management System, Pre-Checker PR Management System, PR Management System, Management System, System</p>
---	--