



THINKWARE IGN-3F Dash Camera Installation Kit Instruction Manual

[Home](#) » [THINKWARE](#) » THINKWARE IGN-3F Dash Camera Installation Kit Instruction Manual 

THINKWARE

ThinkWare DashCam
Installation Sheet

Contents

- [1 IGN-3F Dash Camera Installation Kit](#)
- [2 Documents / Resources](#)
 - [2.1 References](#)

IGN-3F Dash Camera Installation Kit

Tools Required:

7mm Nut Driver or Socket with Ratchet
8mm Nut Driver or Socket with Ratchet
10mm Nut Driver or Socket with Ratchet
Plastic dash panel removal tool
Drill with Phillips bit
Alcohol Pads.

Kit Contents:

1. HWK-TW01-HAR – OBD II Plug-n-Play Thinkware Harness
2. Forward Facing Camera
3. Rear facing camera
4. Connection cable from front to rear camera
5. IGN-3F Ignition Module
6. Windshield mount for front facing camera

7. Micro SD memory card with adapter
8. 2 x 14" Wire Ties
9. 2 x #8 Self Tapping Stinger Head Screws



Read and understand these instructions first before proceeding with the installation of the ThinkWare Dash Cam.

Fig. A



1. Locate the OBD II connector in the vehicle and release it from the mounting surface. This may require the removal of two 7 or 8mm nuts from the studs securing it to the under dash (Fig. A) or by depressing the two side clips, with a plastic dash trim tool, securing it behind the drop down plastic cover (Fig. B).

Fig. B



2. Connect the male end of the included Plug-n-Play HWKTW01-HAR to the vehicles factory OBD II connector (Fig. A).

Fig. A



3. Secure the OBD II connector and the harness together using one of the included wire ties and cut off any excess wire tie that is not needed (Fig. B).

Fig. B



4. For the Nut and Bolt style mounting system: Place the left ear of the connector over the left factory stud and replace and tighten the 8mm nut removed in step 1. Secure the right ear of the connector to the under dash using the included self tapping screw (Fig. C).

Fig. C



For the clip in style mounting system: Feed the body of the harness into the dash opening and secure connector to the dash using the included self tapping screws (Fig. D).

Fig. D



5. Remove the A-Pillar trim panel; this may require the removal of 2 x 10mm bolts. Route the Thinkware power cable over to the driver side of the vehicle, up the A-Pillar (Fig. E) and across the front of the headliner (Fig. F & G) so that it exits the headliner at the factory notch above the rearview mirror.

NOTE: When routing cables near the side curtain airbag, be sure to route them in a way that will not impact the airbags' ability to deploy in the event of an accident.

Fig. E



Fig. F



Fig. G



6. Clean and dry the mounting location with an alcohol pad prior to mounting camera. Slide the camera into the mount and secure it to the windshield using the pre-installed adhesive pad on the mount (Fig. A). Be sure to mount the dash cam behind the rear view mirror in a manner to not obstruct the view of the driver while positioning the camera lens as close to the center of the vehicle and as level as possible. Connecting to the dash cam using the Thinkware smartphone app may be necessary to fine tune the up and down adjustment so that the picture is adequate.

Fig. A



7. Bundle and secure all left over cable (Fig. B).

Fig. B



For vehicles with combustion engines ONLY.

8. a. With the vehicle's ignition in the OFF position, connect the IGN-3F to the 10-Pin Molex connector located on the HWK-TW01-HAR (Fig. C).


Fig. C



For vehicles with electric motors ONLY.

- b. Locate the closest switched power Accessory Power Receptacle (Cig Plug) and gain access to the harness on the back side. Connect the provided power receptacle "T" harness in-line with the factory harness and the receptacle (Fig. D). Route the 10 pin Molex side of the "T" harness to the OBDII area and connect it to the mating 10 Pin Molex connector installed previously.


Fig. D



Steps 9 & 10 are for vehicles with combustion engines only.

9. With the vehicle's ignition in the OFF position and the IGN-3F plugged in, the LED should be emitting a slow consistent flash.

The LED will change from a flashing state to being ON solid once you start the vehicle. When the LED is ON solid, a phantom ignition signal will be sent to the dash cam to turn it on and will remain on during the event of a start/stop sequence. The LED and dash cam will turn off 2 minutes and 30 seconds after the vehicle is shut down.



10. Using the included wire tie, secure the module and the factory OBD II junction under the dash or kick panel in a way that will not impact the airbags' ability to deploy in the event of an accident.
11. Ensure that any and all of the vehicles trim that may have been removed during the previous installation steps is reinstalled.

These next steps are only needed when installing the rear facing camera.

12. Using the techniques mentioned earlier, tuck and route the cable in the headliner from the front camera to the mounting position of the rear camera. The cable will have a label stating which side should be routed to the front of the vehicle. See Fig. A – D for clarification.

NOTE: When routing cables near the side curtain airbag, be sure to route them in a way that will not impact the

airbags' ability to deploy in the event of an accident.

Fig. A



Fig. B



Fig. C



Fig. D



13. Clean and dry mounting location with an alcohol pad prior to mounting camera. Mount the camera on the rear window using the supplied adhesive on the camera. Keep in mind to not mount camera in a location that will interfere with rear view mirror visibility. Connecting to the dash cam using the Thinkware smartphone app may be necessary to verify that the picture is right side up and the entire rear of vehicle is in the frame. See Fig. E and F for clarification.

Fig. E



Fig. F



14. Ensure that any and all of the vehicles trim that may have been removed during the previous installation steps is reinstalled.

For assistance, please contact Echomaster at
gmsupport@echomaster.com
or call [866-766-2267](tel:866-766-2267)

	<p>THINKWARE IGN-3F Dash Camera Installation Kit [pdf] Instruction Manual IGN-3F Dash Camera Installation Kit, IGN-3F, Dash Camera Installation Kit, Camera Installation Kit, Kit</p>
----------------------------------------------------------------------------------	--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.