


## time HG8145V5 Router



# time HG8145V5 Router User Guide

[Home](#) » [TIME](#) » time HG8145V5 Router User Guide 

### Contents

- [1 time HG8145V5 Router](#)
- [2 Product Information](#)
- [3 Product Usage Instructions](#)
- [4 HOW TO NAVIGATE THE WiFi SETTINGS ON YOUR HUAWEI DEVICES](#)
- [5 Documents / Resources](#)
  - [5.1 References](#)
- [6 Related Posts](#)



## time HG8145V5 Router



### Product Information

## Specifications

- Product Model: HUAWEI HG8145V5 and WA8021V5
- WiFi Settings Guide included

## Product Usage Instructions

### Turn On/Off WiFi

#### Via the Self Care portal

To turn on/off WiFi via the Self Care portal:

1. Scroll down to the Internet Connection section on your Self Care dashboard.
2. Locate the Turn On/Off WiFi button and toggle it on to enable your WiFi network.
3. To disable WiFi, toggle off the button. Note that all devices will be disconnected when WiFi is turned off.

#### Via the Time Internet app

To turn on/off WiFi via the Time Internet app:

1. From the Control Hub screen, tap on WiFi Configuration > WiFi Settings.
2. Toggle on the Turn On/Off WiFi button to enable your WiFi network.
3. To disable WiFi, toggle off the button. All connected devices will be disconnected.

### Change WiFi Name and Password

To change WiFi name and password:

1. Via the Time Internet app:
  - Tap on WiFi Configuration > Connected WiFi.
  - Enter your new SSID and password, then tap Save to update. Note that devices connected to the old SSID/password will be disconnected.
2. Via web browser (WA8021V5):
  - Enter the default IP address (192.168.100.1) in your browser.
  - Log in using default username and the last 4 digits of your wireless key as password.
  - Go to My WiFi and configure SSID/password for WLAN.

### Hide WiFi Network

To hide WiFi network via Time Internet app:

1. Tap on WiFi Configuration > WiFi Settings > Hide WiFi.
2. Toggle on the Hide WiFi button to make your network undiscoverable to unconnected devices.
3. To make it discoverable again, toggle off the Hide WiFi button.

### WiFi Scheduling

To set up WiFi scheduling via Time Internet app:

1. Tap on WiFi Configuration > WiFi Settings > WiFi Scheduling.

2. Toggle on the WiFi Scheduling button and set start/end times for your WiFi accessibility.
3. To keep WiFi on at all times, toggle off the WiFi Scheduling button.

## FAQ

- **Q: Can I change the WiFi name and password of both HUAWEI HG8145V5 and WA8021V5 devices?**

A: Yes, you can change the WiFi name and password for both devices following the provided instructions.

- **Q: What happens if I disable the entire WiFi network?**

A: Disabling the entire WiFi network will disconnect all connected devices, and the network will not be accessible until re-enabled.


## WIFI SETTINGS GUIDE HUAWEI HG8145V5 AND WA8021V5

### HOW TO NAVIGATE THE WIFI SETTINGS ON YOUR HUAWEI DEVICES


#### Turn On/Off Your WiFi

A. Via the Self Care portal

1. On your Self Care dashboard, scroll down until you see the Internet Connection section. Look for the Turn On/Off WiFi button and toggle on to enable your WiFi. Your network is discoverable to all and devices can connect to it.




2. On your Self Care dashboard, scroll down until you see the Internet Connection section. Look for the Turn On/Off WiFi button and toggle on to enable your WiFi. Your network is discoverable to all and devices can connect to it.




## Via the Time Internet app


1. From the Control Hub screen, tap on WiFi Configuration > WiFi Settings.



2. Toggle on the Turn On/Off WiFi button to enable your WiFi. Your network is discoverable to all and devices can connect to it.




3. Toggle off the button to disable your entire WiFi network. All devices will be disconnected and your network cannot be accessed. This action is not recommended.



## Change WiFi Name and Password



### A. Via the Time Internet app

1. From the Control Hub screen, tap on WiFi Configuration > Connected WiFi.



2. Key in your new WiFi network name (SSID) and password. Tap Save to update.

\*Please note that once you have saved your changes, the devices connected to your old SSID and password will be disconnected and you will have to connect again with the new credentials.



## B. Via web browser (HG8145V5)

1. Enter the default IP address (192.168.100.1) in your web browser.
2. Log in to your router's configuration page by using your default username and
3. TIME followed by the last 4 digits of your wireless key (e.g. TIME1234) as your password.
4. Go to Home Page. Make your changes under WiFi Setting.

Configure the SSID and password for 2.4Ghz and 5Ghz WLAN respectively. By default, the SSID and password for both bands are the same. If they use the same SSID and password, then band steering is enabled. This means that your device can automatically roam between 2.4Ghz and 5Ghz seamlessly.

The screenshot shows the 'Wi-Fi Setting' page of a Huawei HG8145V5 router. The page has a sidebar with 'Home Page', 'One-Click Diagnosis', 'System Information', and 'Advanced'. The main content area shows 'Wi-Fi configuration' with 'Internet' and 'Wi-Fi configuration' icons. Below, there are two sections for 'Wi-Fi Setting'. The first section is for '2.4G Network' with 'Enable 2.4G Network' checked. The 'Wi-Fi Name' is 'HUAWEI-2.4G-854e' and the 'Password' is '\*\*\*\*\*'. The second section is for '5G Network' with 'Enable 5G Network' checked. The 'Wi-Fi Name' is 'HUAWEI-5G-854e' and the 'Password' is '\*\*\*\*\*'. Both sections have a 'Hide (8-63 characters or 64 hexadecimal characters)' checkbox checked. A red box highlights the 'Wi-Fi Name' and 'Password' fields for both networks, with a callout pointing to them that says 'Key in new SSID & password'. At the bottom, there are 'Save' and 'Cancel' buttons.

## C. Via web browser (WA8021V5)

1. Enter the default IP address (192.168.100.1) in your web browser.
2. Log in to your router's configuration page by using your default username and TIME followed by the last 4 digits of your wireless key (e.g. TIME1234) as your password.
3. Go to My WiFi.
4. Configure the SSID and password for WLAN respectively and click Apply.



Dual-band Combination ☒

If the 2.4 GHz and 5G Wi-Fi frequency bands are used together, the device automatically selects a faster Wi-Fi frequency band. If this switch is turned off, the Wi-Fi frequency band can be set manually

Wi-Fi ☒

Wi-Fi Name


Encrypt

Wi-Fi Password

Wi-Fi Power Mode

## Hide WiFi Network (via Time Internet app)

1. On the Control Hub screen, tap on WiFi Configuration > WiFi Settings Hide WiFi.




2. Toggle on the Hide WiFi button to make your network undiscoverable to any device(s) not connected to your

WiFi.





3. To make your network discoverable again, just toggle off the Hide WiFi button.



### WiFi Scheduling (via Time Internet app)

1. On the Control Hub screen, tap on WiFi Configuration > WiFi Settings WiFi Scheduling.



2. Toggle on the WiFi Scheduling button to set a start and end time (24-hour format) for your WiFi to be turned on and accessible. For example, if you set your start time at 07:00 and end time at 23:00, that means that during the hours in between, your WiFi is turned on and devices can connect to it. After the scheduled time ends at 23:00, your WiFi will turn off and all devices will be disconnected from the network.

×

START AT

0659

07:00

0801

CONFIRM

×

CLOSE AT

2259


23:00

0001

CONFIRM

3. Toggle off the WiFi Scheduling button to keep your WiFi turned on at all times.

Documents / Resources

	<a href="#">time HG8145V5 Router</a> [pdf] User Guide HG8145V5, HG8145V5 Router, Router
---	--

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.