Home » Support » A3 PPPoE DHCP static IP settings

A3 PPPoE DHCP static IP settings

Contents 1 A3 PPPoE DHCP static IP settings 2 DOWNLOAD **3 Related Posts** A3 PPPoE DHCP static IP settings

It is suitable for: A3 Application introduction: Solution about how to configure multiple SSID for TOTOLINK products. Solution about how to configure Internet mode with PPPoE ,Static IP and DHCP for TOTOLINK products STEP-1: Connect your computer to the router by cable, enter http://192.168.0.1 5bd69a320af41.png STEP-2.1: User Name and Password are required, by default both are admin in lowercase letter. Meanwhile you should fill in the vertification code .then Click Login. 5bd69a3cc4bf0.png **STEP-2.2:** Then click the Advance setup bottom 5bd69a87959e4.png

STEP-3.1.1: Easy Setup DHCP setting

Please go to Inernet Setup page, and check which you have selected. Selecting DHCP IP as Connection Type .Then Click Apply.

5bd69dca9a4be.png

STEP-3.1.2: Advanced Setup DHCP setting Please go to Advance Setup ->Network ->Internet Setup page, and check which you have selected .Then return to STEP-3.1.1. 5bd69fd8e1a73.png STEP-3.2.1: Easy Setup PPPOE setting Please go to Inernet Setup page, and check which you have selected. Selecting PPPoE as Connection Type .Then Click Apply. 5bd6a1c55c2ba.png STEP-3.2.2: Advanced Setup PPPOE setting Please go to Advance Setup ->Network ->Internet Setup page, and check which you have selected .Then return to STEP-3.2.1. 5bd6a203e8e76.png STEP-3.3.1: Easy Setup Static IP setting Please go to Inernet Setup page, and check which you have selected. Selecting Static IP as Connection Type .Then Click Apply. 5bd6a251972b1.png STEP-3.3.2: Advanced Setup Static IP setting Please go to Advance Setup ->Network ->Internet Setup page, and check which you have selected .Then return to STEP-3.3.1.

5bd6a2746b05c.png

DOWNLOAD

A3 PPPoE DHCP static IP settings – [Download PDF]

Manuals+,