tp-link EAP653 Ceiling Mount WiFi 6 Access Point Installation Guide

Contents

EAP653 Ceiling Mount WiFi 6 Access Point

Installation Guide
Access Point

Network Topology
A typical network topology for APs is shown below.
Note: Images may differ from your actual products.

Some APs can be configured and monitored centrally via a controller or the control software. For details, refer to the product specifications and the manual for the relevant product, controller, or control software.
You can get the controller or control software from **https://www.tp-link.com** or contact the sales staff.

Hardware Installation

APs can be connected or mounted in various ways to

meet diverse needs. For installation instructions, refer to the Quick Installation Guide included in the product package.

Safety Information

- Do not attempt to disassemble, repair, or modify the device. If you need service, please contact us.
- Do not use the device where wireless devices are not allowed.
  For indoor APs:
- Keep the device away from water, fire, humidity or hot environments.
  For outdoor APs:
- Keep the device away from fire or hot environments. DO NOT immerse in water or any other liquid.
- Adapter should be used indoors where the ambient temperature is lower than or equal to 40°C.

For APs powered with adapters:

- Do not use damaged charger or USB cable to charge the device.
- Do not use any other chargers than those recommended.
- Adapter shall be installed near the equipment and shall be easily accessible.

For APs with power cords:

- The plug on the power supply cord is used as the disconnect device, the socket-outlet shall be easily accessible.
- Plug the product into the wall outlets with earthing connection through the power supply cord.
  For APs with plugs:
- The socket-outlet shall be installed near the equipment and shall be easily accessible.
- (For the 3-pin-plug version) Plug the product into the wall outlets with earthing connection through the plug.
  Please read and follow the above safety information when operating the device. We cannot guarantee that no accidents or damage will occur due to improper use of device. Please use this product with care and operate at your own risk.

For Class A APs, APs without adapters, or Wall Plate APs supporting only PoE power supply:
TP-Link hereby declares that the device is in compliance with the essential requirements and other relevant provisions of directives (EU)2015/863, 2014/53/EU, and 2011/65/EU.
The original EU declaration of conformity may be found at

https://www.tp-link.com/support/ce/

For other APs:
TP-Link hereby declares that the device is in compliance with the essential requirements and other relevant provisions of directives (EU)2015/863, 2014/53/EU, 2009/125/EC and 2011/65/EU.
The original EU declaration of conformity may be found at
https://www.tp-link.com/support/ce/

For technical support, the user guide and other information, please visit https://www.tp-link.com/support/?type=smb, or simply scan the QR code.
© 2024 TP-Link 7106511238 REV1.0.0

Documents / Resources

tp-link Installation Guide Access Point	**tp-link EAP653 Ceiling Mount WiFi 6 Access Point** [pdf] Installation Guide EAP653, EAP653 Ceiling Mount WiFi 6 Access Point, Ceiling Mount WiFi 6 Access Point, Mount WiFi 6 Access Point, WiFi 6 Access Point, Access Point, Point

References

- **Support | TP-Link**
- **Support | TP-Link**
- **Support | TP-Link**
- **Support | TP-Link**
- **Support | TP-Link**
- **Support | TP-Link**
- **Support | TP-Link**
- **Support | TP-Link**
- **Support | TP-Link**
- **Support | TP-Link**
- **Support | TP-Link**
- **Support | TP-Link**
- **TP-Link Product Support - Wireless Networking Equipment Support**
- **User Manual**