

TRAN LED Q-CAP Flexible Fixtures WALA Installation Guide

[Home](#) » [TRAN LED](#) » TRAN LED Q-CAP Flexible Fixtures WALA Installation Guide 

TRAN LED Q-CAP Flexible Fixtures WALA



Contents

[1 VHB MOUNTING](#)

[1.1 WHITE SNUG CLIP](#)

[1.2 INCLUDED HARDWARE](#)

[2 Mounting Feed](#)

[3 Mounting Feed](#)


[4 Documents / Resources](#)

[4.1 References](#)


[5 Related Posts](#)

VHB MOUNTING


1. Remove the backing from the adhesive and apply firm pressure to secondary backing.




2. Peel off the bonding surface.




3. Adhere to mounting surface



NOTE: White snug clip should be placed every 12"




INCLUDED HARDWARE




#4x5/8" Flat head screw

1. Mount white snug clip with provided flat head screw.



2. Align fixture to white snug clips matching distances.

2.




3. Press fixture into white snug clips.

3.




PVC MOUNT CLIP: Connects two seamless fixtures, with or without wire exit


WALA-PPS-2




Mounting Feed



Press both fixtures into PPS clip.




Snap fixture into mounted PPS channel
When wire will exit into conduit do not install bracket




LOW PROFILE PVC MOUNT CLIP: Connects two seamless fixtures, with or without wire exit


WALA-PPS-LP-2




Mounting Feed



Snap in 2" channel




Press in fixtures




PVC MOUNTCHANNEL: Support for the fixture


ALA-PPS-96 & WALA-PPS-FT




INCLUDED HARDWARE



PPS - BRACKET:
Sold in full length of 96"
or custom length (FT)




#6 Flat head screw



1. The PPS-BRACKET can be field cuttable and cut to whatever length your application requires. The PPS-BRACKET can be installed as a full length of 96", multiple smaller pieces, or end to end for longer seamless



runs.

1.




2. Using pre-drilled pilot holes screw the #6 flat head screws to mount the PPS-BRACKET (1 screw every 16").
NOTE : For drywall applications mount directly into a stud.

2.




3. Using pre-drilled pilot holes, use the #6 flat head screws to mount the PPS-BRACKET.

3.




4. The PPS-96 or PPS-FT can be field cuttable and cut to whatever length your application requires. The PPS-96 or PPS-FT can be installed as a full length of 96", multiple smaller pieces, or end to end for longer seamless runs.

4.




5. To mount, pinch the upper half of the PPS-96 or PPS-FT while you pivot it around one side of the PPS-BRACKET and push-in until you hear it snap into place. The PPS-96 or PPS-FT flexes around the PPS-BRACKET to create a solid, and secure snap on connection.

5.




LOW PROFILE PVC MOUNT CHANNEL: Support for the fixture

WALA-PPS-LP-96 & WALA-PPS-LP-FT




– 96" (PPS-96) or custom length (PPS-FT)


INCLUDED HARDWARE




#6 Flat head screw




1. The PPS-LP-96 or PPS-LP-FT can be field cuttable and cut to whatever length your application requires. The PPS-96 or PPS-FT can be installed as a full length of 96", multiple smaller pieces, or end to end for longer seamless runs.




2. Drill holes (1 hole/screw every 16") into the PPS-LP.




3. Using pre-drilled holes, use the #6 flat head screws to mount the PPS-LP. **NOTE** : For drywall applications mount directly into a stud.



4. Snap fixture into PPS-LP



	<p>TRAN LED Q-CAP Flexible Fixtures WALA [pdf] Installation Guide</p> <p>Q-CAP Flexible Fixtures WALA, Q-CAP Flexible Fixtures, Flexible Fixtures, Q-CAP, Q-CAP Fixtures, Fixtures, WALA</p>
--	---

References

- [🌐 Your Name as Your Email | Hover Realnames](#)
- [🔌 LED Lighting Systems, Linear LED Lights, LED transformers | Q-Tran](#)