




Triple M 9PEWP  
Window  
Protector



## Triple M 9PEWP Window Protector Installation Guide


[Home](#) » [Triple M](#) » Triple M 9PEWP Window Protector Installation Guide 

### Contents

- [1 Triple M 9PEWP Window Protector](#)
- [2 Product Usage Instructions](#)
- [3 Installation Steps](#)
- [4 INSTALLATION INSTRUCTIONS](#)
- [5 Kit Contents](#)
- [6 SECTION 1—Installation](#)
- [7 Documents / Resources](#)
  - [7.1 References](#)
- [8 Related Posts](#)



Triple M 9PEWP Window Protector



## Specifications

- Product Name: 9PEWP Window Protector
- Material: Steel Wire Mesh or Aluminium Mesh
- Installation Time: 0 Hours 15 Minutes
- Document Issue: 1, Date: 25/06/2024

## Product Usage Instructions

### Kit Contents

Before starting the installation, ensure that you have all the necessary components:

- 1 Window Protector – Welded Steel or Alloy Mesh
- 4 M6x40 Counter-sunk Philips Head Screws
- 4 M6 Nyloc Nuts

### Tools Required

Make sure you have the following tools ready:

- Cordless Drill
- 6.5mm Drill Bit
- 10mm Socket
- 10mm Spanner
- Ratchet
- Philips Head Screw Driver

## Installation Steps

### 1. Step 1: Positioning

Position the window protector to ensure at least 25mm clearance from the headboard while covering as much of the rear window as possible.

If your vehicle has a Third Brake Light, ensure the top of the protector sits 25mm below the bottom of the lamp

to avoid blocking it.

## 2. Step 2: Fastening


Mark hole locations on the headboard uprights and drill 6.5mm holes. Use M6x40 counter-sunk screws and M6 nyloc nuts for steel wire mesh protectors, and M6x40 bolts for aluminum mesh protectors.

## FAQ

### Q: Do I need to use power tools for installation?

A: Yes, the installation requires the use of power tools for drilling and fastening.

## INSTALLATION INSTRUCTIONS




Installation of this accessory requires the use of power tools. Check that all work practices comply with safety standards, wear appropriate clothing and use personal protection equipment.

Please read these instructions carefully before installation, paying special attention to all Notice, Caution & Warning notes. Failure to do so may result in damaged parts or injury to the installer or customer.


## Kit Contents

NOTE: CHECK KIT CONTENTS BEFORE COMMENCING FITMENT AND REPORT ANY DISCREPANCIES

Item	Description	Qty
<b>Steel Wire Mesh Window Protector</b>		
1	Window Protector – Welded Steel	1
2	M6x40 Counter-sunk Philips Head Screw	4
3	M6 Nyloc Nut	4



Item	Description	Qty
<b>Aluminum Mesh Window Protector</b>		
1	Window Protector – Alloy Mesh	1
2	M6x40 Hex Bolt	4
3	M6 Nyloc Nut	4



**Tools Required**

TOOLS REQUIRED	
Cordless Drill	6.5mm Drill Bit
10mm Socket	10mm Spanner
Ratchet	Philips Head Screw Driver

### Fastener Torque Table


Fastener size	Class	Torque
M6	8.8	9 Nm

## SECTION 1—Installation

### 1. STEP 1


Position window protector to allow minimum 25mm clearance from the headboard whilst still covering as much of the rear window as possible.

NOTE: If Vehicle has Third Brake Light



If the vehicle is fitted with a CHMSL (Center High Mounted Stop Lamp) ensure the top of the window protector sits 25mm below the bottom of the lamp. The brake light must not be blocked by the window protector.


Mark the hole locations on the headboard uprights and drill 6.5mm holes.




### 2. STEP 2

Fasten the window protector to the head-board uprights upright using M6x40 counter sunk screws and M6 nyloc nuts.

For alloy mesh window protectors use M6x40 bolts and M6 nyloc nuts.



## Documents / Resources



[Triple M 9PEWP Window Protector](#) [pdf] Installation Guide  
9PEWP Window Protector, 9PEWP, Window Protector, Protector

## References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.