



TURNIGY Twin Strobe light Unit Instructions

[Home](#) » [TURNIGY](#) » TURNIGY Twin Strobe light Unit Instructions 



Twin Strobe light Unit Instructions Manual

Contents

- [1 Features:](#)
- [2 Product Content:](#)
- [3 Instruction For Remote:](#)
- [4 Specifications:](#)
- [5 FCC Statement](#)
- [6 Documents / Resources](#)
- [7 Related Posts](#)

Features:

1. 24 high intensity LED with wide optic lenses for maximum intensity.
2. Self-contained LED unit; no external flasher required.
3. 13 selectable flash patterns with Mode Memory Function.
4. Includes directional flash patterns. (Left, Right, and Center Out)
5. Last pattern memory recall.
6. Rainproof. (Not submersible)
7. Angle adjustable mounting brackets.
7. 1/4" mounting grooves on the back for slide bolt mounting.
8. 13 feet (4 meters) extension cable for mounting on compact and large vehicles.
9. Wireless Remote Control, working Distance: 6-10 meters

Product Content:

- 1 x Strobe Light Unit
- 1 x Wireless Remote Control

2 x Mounting Brackets
Accessories

Instruction For Remote:

A: Turn On
B: Turn Off
C: Change Flash Patterns
D: Automatically Random Flash Models



Specifications:

Dimension: 27" W x 2.5" H x 2.5" D
Input Current @ 12V: 100mA – 1.6A
1 Year Warranty

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by the manufacturer could void your authority to operate this equipment.


This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received,

including interference that may cause undesired operation.

RF Exposure Information

The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure conditions without restriction.

Documents / Resources

	TURNIGY Twin Strobe light Unit [pdf] Instructions 29D6, 2A58Z-29D6, 2A58Z29D6, Twin Strobe light Unit
---	--

[Manuals+](#)