



# UBIQUITI U6PLR UniFi + plus Long Range Access Point User Manual

[Home](#) » [UBIQUITI](#) » UBIQUITI U6PLR UniFi + plus Long Range Access Point User Manual 



## Contents

- [1 U6PLR UniFi + plus Long Range Access Point](#)
- [2 Documents / Resources](#)
  - [2.1 References](#)
- [3 Related Posts](#)

## U6PLR UniFi + plus Long Range Access Point

**FCC ID:** SWX-U6PLR

**IC ID:** 6545A-U6PLR

Ubiquiti Inc. will be incorporating the E-Label procedures per FCC KDB 784748-D02. The information below is what will be included in the E-Labeling.

E-label and warning statements can be found in the device/controller GUI under Device > Settings > About.

Detailed compliance information including Declaration of Conformity is available at the following internet address:

[ui.com/compliance](http://ui.com/compliance)

## FCC

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions.

This device may not cause harmful interference, and This device must accept any interference received, including

interference that may cause undesired operation.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**ISED Canada**  
**CAN ICES-3 (A) / NMB-3 (A)**

This device complies with ISED Canada license-exempt RSS standard(s). Operation is subject to the following two conditions:

1. This device may not cause interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

**RF Exposure Warning**

The antennas used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be located or operating in conjunction with any other antenna or transmitter.



**Documents / Resources**

	<a href="#"><b>UBIQUITI U6PLR UniFi + plus Long Range Access Point</b> [pdf] User Manual SWX-U6PLR, SWXU6PLR, u6plr, U6PLR UniFi plus Long Range Access Point, U6PLR, U6PLR Long Range Access Point, UniFi plus Long Range Access Point, Long Range Access P oint, Long Range</a>
--	---

**References**

- [Ubiquiti - Compliance](#)
- [Ubiquiti - Compliance](#)