



UNI-T UT-P32 Differential Probe Active Probe Instruction Manual

[Home](#) » [UNI-T](#) » UNI-T UT-P32 Differential Probe Active Probe Instruction Manual 

Contents

- [1 UNI-T UT-P32 Differential Probe Active Probe](#)
- [2 Features](#)
- [3 Specifications](#)
- [4 Operating environmental conditions](#)
- [5 Operating procedure](#)
- [6 Maintenance](#)
 - [6.1 Cleaning](#)
 - [6.2 Warranty](#)
 - [6.3 Repair](#)
- [7 Documents / Resources](#)
- [8 Related Posts](#)

UNI-T®

UNI-T UT-P32 Differential Probe Active Probe



Features

The UT-P32 differential probe provides a safety means for measuring differential voltage to all models of oscilloscopes. It can convert the high differential voltage($\leq 3000\text{Vp-p}$) into a low voltage($\leq 7\text{V}$)and display on the oscilloscope. Its bandwidth is up to 50MHz,which is ideal for big power testing, development and maintain. The UT-P32 is designed to operate with the 1M Ω impedance oscilloscopes. When combine with the 50 Ω load , the attenuation will be 2 times.

UT-P32 is recommend to use with our own manufactured PL-10 to expand the measuring with the electricity meter to observe more accurate measurement. The accuracy of oscilloscope is 1%and the DMM is less than 1%)

Specifications

1. **Bandwidth:** DC-50MHz
2. **Attenuation:** X1000,X100
3. **Accuracy:** +/-1%
4. **Input voltage range**(DC+AC PEAK TO PEAK)
 $\leq 3000\text{V}$ for x1000,(about 1000V RMS and 1500V DC) $\leq 300\text{V}$ for x100,(about 100V RMS and 150V DC)
5. **Permitted max input voltage:**
Max differential voltage: 3000V(DC+AC PEAK to PEAK)
Max voltage between each input terminal and ground: 5KV RMS
6. **Input Impedance:**
Differential: 8M Ω /1pF
Between terminal and ground:4M Ω /2pF
7. **Output voltage:** $\leq 7\text{V}$
8. **Output impedance:** 50 Ω
9. **Rise time:**
 7ns
10. **Rejection rate on common mode:**
 60Hz: 80dB;100Hz: 60dB;1MHz: 50dB
11. **Power Supply:** Only External 6V DC power supply.

12. **Consumption:** 150mA max (0.9 Watt)

Operating environmental conditions

	Reference	Use	Storage
Temperature	+20°C...+30°C	0°C....+50°C	-30°C.....+70°C
Relative Humidity	≤70%RH	10%...85%RH	10%...90%RH

1. **Dimensions and weight** 69x26x165mm; 500g

2. Electrical safety to IEC 1010-1

Dual insulation

Installation category III

Degree of Pollution 2

Related voltage or max line-earth 5KV RMS CE EN50081-1 and 50082-1

Operating procedure

- Connect the probe to the oscilloscope with the insulated BNC/BNC lead.
- Adjust the vertical zero adjustment of the oscilloscope if necessary.
- Select the attenuation ratio* and the vertical deviation of the oscilloscope in accordance with the conversion table below.
- **NB:** The POWER light must come on.

Attenuation ratio	X1000	X100
Voltage Input Range (DC+AC Peak to PEAK)	3000V	300V

[N.B]

The real vertical deviation in V/div is equal to the attenuation factor multiplied by the range of vertical deviation selected on the oscilloscope. It will be doubled in the case of use of a 50 Ω load.

Maintenance

For maintenance, only use specified spare parts. The manufacturer can not be held responsible for any accident arising following a repair made other than its after sales service or approved repairs.

Cleaning

This probe does not require any particular cleaning. If necessary, clean the case with a cloth slightly moistened with the soapy water.

Warranty


Unless notified to the contrary, our instruments are guaranteed against any manufacturing defect or material defect. They do not bear the specification known as the safety specification.

Our guarantee, which may not under any circumstances exceed the amount of the invoiced price, goes on further than the repair of our faulty equipment, carriage paid to our workshops.

Repair

Maintenance, repairs under or out of guarantee. Please return the product to the manufacturer.

Documents / Resources

	<p><u>UNI-T UT-P32 Differential Probe Active Probe</u> [pdf] Instruction Manual UT-P32, Differential Probe Active Probe, UT-P32 Differential Probe Active Probe, Probe Active Probe, Active Probe, Probe</p>
---	--

Manuals+,