

UniPOS 7000M Addressable Modular System Panel Owner's Manual

Home » Unipos » UniPOS 7000M Addressable Modular System Panel Owner's Manual



UniPOS 7000M Addressable Modular System Panel Owner's Manual

The Addressable Modular System Panel 7000M is designed to satisfy a professional solution enhancing:

- Installation procedure with set-up flexibility
- · 2-10 loop capability
- · Supplied with 2 loops as standard
- Add up to 4 more loop module cards to increase panel capacity to a maximum of 10 loops
- Certified to EN54-2/4/13

Product is also available with a printer - Part Number: 7000M-P





Contents

- **1 Technical Features**
- 2 Documents /

Resources

- 2.1 References
- **3 Related Posts**

Technical Features

Number of Loop Addressable Devices per Loop	up to 210 pcs
Number of Loop Addressable Devices per Panel	up to 2,100 pcs
Number of Loop Modules per Panel	up to 5 (total 10 loops)
Number of Loop Modules per System	up to 64
Number of BIO Modules	up to 5 per panel
Number of Addressable Devices per System	up to 13,440 p c s
Detection Zone	contain up to 32 loop detectors, fire inputs or/a nd manual call points
Detection Zones per Panel / System	up to 1,023 / 30 per loop
Configurable Week Schedule (Day / Night Mode)	sensitivity and logic change to detectors, delay s change in alarm zones
Protection Zones per Panel / System	up to 1,023 / 30 per loop
Protection Zones peí Panel / System	up to 1,023 / 30 per loop
Protection Zones per Panel / System	redundant CAN network supports up to 16 pan els and up to 13,440 detectors
Maximum Number of Addressable and Conventional Fire Alar m Devices	up to 35 per loop, up to 350 per panel connect ed to the loops – conventional and addressabl e devices (sounders)
Dependencies on more than one alarm signal	CI Mode B (detecting fire by two zones activation) CI Mode C (detecting fire with inspection time)
Alarm Counter	up to 9,999 (can be deleted by script at level a ccess 4)
Event Log (archive)	10,000 events

Configurable Output to Fire Protection Equipment (addressable out put device)	LED indication for activation
	input for the reception of a confirmatory si gnal from fire protection equipment, indica ted by means of separate indicator
Other Features	alarm zones and protection zones can be activated from any detection Zones (one detection zone cannot activate two alarm zones)
	configurable sounder melodies in alarm a nd prealarm state (Warning-state) for ever y Alarm zone.
	output to fire alarm devices
	alarm confirmation input from fire alarm ro uting equipment
	fault monitoring fire protection equipment (in/out)
	delay to outputs, day / night mode
	fault signals from points
	total loss of power supply
	output to fault warning routing equipment
	disablement of addressable points

1 Efr. Nikola Paskalev Str, Mladost 1 Sofia 1748, Bulgaria **Telephone:** +359 2 97 439 2

Email: sales@unipos-bg.com
Website: www.unipos-bg.com



Documents / Resources



<u>UniPOS 7000M Addressable Modular System Panel</u> [pdf] Owner's Manual 7000M, 7000M Addressable Modular System Panel, Addressable Modular System Panel, Modular System Panel, Panel

References

- M Prada, Jimmy Choo, Gucci, Lanvin, Dolce & Gabbana Bergdorf Goodman
- User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.