



# uniview 0211C5L1 Smart Interactive Display User Guide

[Home](#) » [uniview](#) » uniview 0211C5L1 Smart Interactive Display User Guide 

## uniview 0211C5L1 Smart Interactive Display User Guide



## Contents

- [1 Safety Instructions](#)
- [2 Packing List](#)
- [3 Product Overview](#)
  - [3.1 Appearance](#)
  - [3.2 Interfaces/Buttons](#)
  - [3.3 Wireless Module](#)
  - [3.4 Remote control](#)
- [4 Installation](#)
  - [4.1 Installation with Brackets](#)
  - [4.2 Cable Connection](#)
- [5 Startup](#)
- [6 GUI Introduction](#)
  - [6.1 Features](#)
- [7 Troubleshooting](#)
- [8 Disclaimer and Safety Warnings](#)
- [9 Regulatory Compliance](#)
- [10 Documents / Resources](#)
  - [10.1 References](#)
- [11 Related Posts](#)

## Safety Instructions

The device must be installed, serviced and maintained by a trained professional with necessary safety knowledge and skills. Before installation, be sure to carefully read and implement the safety instructions specified in this manual.

- The device shall use an 100V to 240V AC, 50Hz/60Hz power supply. Non-compliant power supplies may cause device failure.
- The power supply of the display system shall be in phase with that of the image controller and PC, but not in phase with high-power devices (such as high-power air conditioner).
- All the grounding devices must be securely grounded, and the grounding wire of all the devices must be connected to an equipotential socket. The ground bus shall use multi-core copper wires. The ground bus must not be short circuited with the neutral wire of the power grid and must not be connected to the same socket with other devices. All the grounding points must be connected to the same grounding bar, and the voltage difference between devices must be zero. The operating temperature for the device is 0°C to 50°C. Operation out of this range may cause device failure. The operating humidity is 10% to 90%. Use a dehumidifier if necessary.
- Take effective measures to protect the power cord from being tramped or pressed.
- Keep the device away from fire and water.
- Do not open the cabinet as there are high voltage components inside.
- Handle with care during transportation and installation. Do not knock, squeeze or carve the device with hard objects. User shall assume total responsibility for damages caused by improper user operations.
- Use the device in a clean environment. The dust concentration shall meet the office environment requirements.
- Installing or moving the device shall be done by more than two people. Avoid placing the device on uneven surfaces to prevent personal injury and device damage from tip-over.
- Unplug the power cord before leaving this device unused for long periods. Do not turn on and off frequently. Wait at least 3 minutes before turning on/off again.

- Do not insert objects of any kind into the device via the vent or input/output ports. It may cause short circuit, device failure, or electric shock.
- When the device is moved from a cold environment to a warm environment, condensation may occur inside the device. Please wait for a while for the condensation to fully dissipate before powering on the device.

**Packing List**

The package contents may vary with device model.

No.	Name	Qty	Unit
1	Smart interactive display	1	PCS
2	Wireless module	1	PCS
3	Power cable	1	PCS
4	Touch pen	2	PCS
5	Remote control	1	PCS
6	Wall mount bracket	1	Set
7	Product documents	1	Set

**Product Overview**

The appearance and interfaces may vary with device model.

**Appearance**

Figure 3-1 **FrontView**






Figure 3-2 **Rear View**



Interfaces/Buttons

Figure 3-3 Front Interfaces



IR IN/Photosensitive sensor

Figure 3-4 Front Buttons




Figure 3-5 Side Interfaces




Figure 3-6 Bottom Interfaces









Figure 3-7 Power Interface



Interfaces/Buttons	Description
IR IN/Photosensitive sensor	IR IN: Infrared receiver for receiving infrared signals from the remote control. Photosensitive sensor: Used to adjust the screen brightness automatically based on the ambient light intensity.
RESET	OPS reset button, when the device runs in Windows, press the button to restore the Windows settings to factory defaults.
USB	USB interface, connects to a USB device such as USB flash drive (used to receive upgrade packages and files), keyboard and mouse (used to control the device).
HDMI	HDMI input interface, connects to a video source device for video signal input.
TOUCH OUT	Touch output interface, connects to the same video source device with video input interfaces, such as PC, for touch control to the video source device.
TYPE-C	Type-C interface, supports video input, data transmission, TOUCH output, fast charging, etc.
OPS	OPS switch button, when an OPS module is installed on this device and the device is using other signal sources, press the button to switch to Windows system; if no OPS module is installed, the screen shows no signal.
	Input source, press to switch signal input sources.
Fn	Custom button (reserved).
	Power button, when the device is powered on but not started, press the button to start the device; when the device is operating, press the button to select the power status. You can check the device status through the indicator. <ul style="list-style-type: none"> <li>• <b>Red:</b> The device is powered on but not started.</li> <li>• <b>White:</b> The device is starting/running normally.</li> <li>• <b>Off:</b> The device is powered off.</li> </ul>
	Used to adjust the volume.
	Used to configure the device, such as network.
DP	DP input interface, connects to a video source device for video signal input.
HDMI OUT	HDMI video output interface, connects to a display device for video signal output.
TF CARD	TF card slot for storage expansion.


COAX/OPT	Audio output interface, connects to an audio playing device for audio signal output.
RS232	RS232 serial port, connects to an RS232 device such as PC for control signal input.
AV IN	AV input interface, connects to a video source device for video signal input.
AV OUT	AV output interface, connects to a display device for video signal output.
EAR OUT	Audio output interface, connects to an audio playing device such as earphone for audio signal output.
MIC IN	Audio input interface, connects to an audio collection device such as microphone for audio signal input.
LAN IN	Gigabit Ethernet port, connects to a LAN device such as switch for Ethernet access. This interface supports network penetration. Android and Windows can share the same network.
LAN OUT	Gigabit Ethernet port, connects to a PC to provide Ethernet access. NOTE! This interface is available only when the LAN IN interface is connected to Ethernet.
VGA IN	VGA input interface, connects to a video source device for video signal input.
PC AUDIO	Audio input interface, connects to the same video source device with VGA IN and YPBPR interfaces for audio signal input.
YPBPR	YPBPR input interface, connects to a video source device for video signal input.
Power interface	100V to 240V AC, 50Hz/60Hz power input.
Power switch	Power on/off the device.

### Wireless Module

The wireless module is divided into two parts: Wi-Fi module and Bluetooth module. If you need to connect to wireless networks, hotspots, or Bluetooth devices, please install a wireless module first.

- **Wi-Fi module:** Wi-Fi 6 + Wi-Fi 5, Wi-Fi 6 for uplink routing, Wi-Fi 5 for hotspot, supports 2.4G/5G.
- **Bluetooth module:** Integrated with Wi-Fi 6 module, built-in antenna, supports Bluetooth 5.2 protocol.

**Figure 3-8 Wireless module**



Insert the wireless module into the wireless module slot at the bottom of the device. The wireless module is hot-plug gable.

#### Remote control

Button	Description
	Turn on/off the device.CAUTION!After you turn off the device using the remote control, the device remains powered on, please pay attention to fire and electricity prevention.
Signal	Switch signal sources.
	Play/set ID (reserved). <ul style="list-style-type: none"> <li>Start/pause playback.</li> <li>Set screen ID.</li> </ul>
	Stop playback (reserved).
	Mute.
Color temperature	Adjust the color temperature of the screen (reserved).
Volume +/-	Adjust the volume.
	<ul style="list-style-type: none"> <li>Choose up/down/left/right.</li> <li>Change values.</li> </ul>
OK	Confirm the selection.
Menu	Open the settings screen.
Exit	Exit the current screen.
Still	Pause/resume playback (reserved).
Display	Display the signal source and resolution (reserved).
0~9	Numeric buttons.
Plan	Select the plan (reserved).
Screen	Select the screen you want to control (reserved).

## Installation

### Installation with Brackets

The device supports wall installation and floor installation, and you can use the included wall mount bracket to fix the device to the wall, or purchase our mobile stands. See the corresponding documents for details.

### Cable Connection

See **Interfaces/Buttons** for details.

### Startup

For first use, connect the device to power using the power cable, turn the power switch on, and press the power button. After startup, complete the initial configuration of the device according to the startup wizard.












#### NOTE!

You can set the boot mode under **Settings > General > Boot Mode**.

### GUI Introduction



Icon	Description
	Hide the navigation bar.
	View tutorial videos, operation guides, and FAQs.
	Return to the previous screen.
	Return to the home screen.
	View running apps and switch between them.
	Switch signal sources.
	Set network, display, sound, etc.
	Select the power status.
	Various small tools, such as annotation and volume adjustment.

**Features**

High-precision touch, smooth writing



Wireless screen mirroring, easy sharing



Fast file transfer, one-key to transfer files



Minimalist interaction design, easy to use



More exciting features for you to explore...

## Troubleshooting

If	Then
The power indicator lights in red and cannot change to green.	<ul style="list-style-type: none"><li>• Check if the voltage and grounding of the power cable plug are normal.</li><li>• Press the power button on the display/remote control to turn on the display.</li></ul>
The display cannot be turned on; there is no image on the screen and no sound coming from the display; the power indicator is not lit.	<ul style="list-style-type: none"><li>• Check if the voltage and grounding of the power cable plug are normal.</li><li>• Check if the rocker switch is switched to position “1”.</li><li>• Check if the power button on the display/remote control is normal.</li></ul>

Some buttons do not work.	Check if the buttons cannot pop up due to excessive force. Check if there is dust accumulated in the gap of the buttons.
The display cannot recognize the connected PC.	<ul style="list-style-type: none"> <li>• Try another USB interface.   Replace the USB touch cable.</li> <li>• Reinstall the system.</li> </ul>
There is no sound coming from the display.	Turn up the sound volume. If there is still no sound, please operate as follows: Check if the speaker is normal. Insert a USB flash drive with songs into the USB interface, and play a song to test if there is sound output. If there is sound, the speaker is normal, and you need to reinstall the system. If there is no sound, the speaker or the board may have problems.
There is noise coming from the external speaker.	<ul style="list-style-type: none"> <li>• Check if there is electromagnetic interference.</li> <li>• Plug in headphones and listen if there is noise. If there is no noise, you need to replace a speaker.</li> </ul>
The Wi-Fi signal is weak.	<ul style="list-style-type: none"> <li>• Check if the wireless router works properly.</li> <li>• Make sure there is no obstacle around the Wi-Fi antenna.</li> </ul>
The device cannot connect to a Wi-Fi.	<ul style="list-style-type: none"> <li>• Check if the wireless router works properly.</li> <li>• Check if it is necessary to obtain an IP address automatically.</li> </ul>

The display cannot connect to a wired network.	Check if the wired network and the network cable is normal. For Win7, go to Control Panel > Network and Internet > Network and Sharing Center > Change adapter settings, right-click a local area connection, click Properties, select Internet Protocol Version 4 (TCP/IPv4), double-click the protocol, enable Obtain an IP address automatically and Obtain DNS server address automatically. For Win10, go to Settings > Network & Internet > Network and Sharing Center > Change adapter settings, right-click a local area connection, click Properties, select Internet Protocol Version 4 (TCP/IPv4), double-click the protocol, enable Obtain an IP address automatically and Obtain DNS server address automatically.
There is water mist between the display screen and the tempered glass screen protector.	This problem is caused by the temperature difference between the inside and outside of the glass. The water mist generally disappears after the display is powered on and does not affect the normal operation of the device.
There are lines or ripples in images.	<ul style="list-style-type: none"> <li>• Check if there is interference near the device. Keep the device away from interference or insert the power plug into another socket.</li> <li>• Check if the video cables are of high quality.</li> </ul>
You cannot operate the device, for example, it gets stuck or crashes.	Disconnect the power supply, wait one minute and then restart the device.
You have a delayed touch response or no touch response when using the display.	Check if too many programs are running. Stop the programs that cause high memory usage or restart the device.
The OPS computer cannot be turned on normally; there is no image on the screen and no response to touch.	Unplug the OPS computer and plug in again.

## Disclaimer and Safety Warnings

### Copyright Statement

©2023 Zhejiang Uniview Technologies Co., Ltd. All rights reserved.

No part of this manual may be copied, reproduced, translated or distributed in any form or by any means without prior consent in writing from Zhejiang Uniview Technologies Co., Ltd (referred to as Uniview or us hereafter).

The product described in this manual may contain proprietary software owned by Uniview and its possible licensors. Unless permitted by Uniview and its licensors, no one is allowed to copy, distribute, modify, abstract,

decompile, disassemble, decrypt, reverse engineer, rent, transfer, or sublicense the software in any form by any means.

## Trademark Acknowledgements



are trademarks or registered trademarks of Uniview.

The terms HDMI, HDMI High-Definition Multimedia Interface, HDMI trade dress and the HDMI Logos are trademarks or registered trademarks of HDMI Licensing Administrator, Inc.

All other trademarks, products, services and companies in this manual or the product described in this manual are the property of their respective owners.

## Export Compliance Statement

Uniview complies with applicable export control laws and regulations worldwide, including that of the People's Republic of China and the United States, and abides by relevant regulations relating to the export, re-export and transfer of hardware, software and technology. Regarding the product described in this manual, Uniview asks you to fully understand and strictly abide by the applicable export laws and regulations worldwide.

## EU Authorised Representative

UNV Technology EUROPE B.V. Room 2945, 3rd Floor, Randstad 21-05 G, 1314 BD, Almere, Netherlands.

## Privacy Protection Reminder

Uniview complies with appropriate privacy protection laws and is committed to protecting user privacy. You may want to read our full privacy policy at our website and get to know the ways we process your personal information. Please be aware, using the product described in this manual may involve the collection of personal information such as face, fingerprint, license plate number, email, phone number, GPS. Please abide by your local laws and regulations while using the product.

## About This Manual

- This manual is intended for multiple product models, and the photos, illustrations, descriptions, etc, in this manual may be different from the actual appearances, functions, features, etc, of the product.
- This manual is intended for multiple software versions, and the illustrations and descriptions in this manual may be different from the actual GUI and functions of the software.
- Despite our best efforts, technical or typographical errors may exist in this manual. Uniview cannot be held responsible for any such errors and reserves the right to change the manual without prior notice.
- Users are fully responsible for the damages and losses that arise due to improper operation.
- Uniview reserves the right to change any information in this manual without any prior notice or indication. Due to such reasons as product version upgrade or regulatory requirement of relevant regions, this manual will be periodically updated.

## Disclaimer of Liability

- To the extent allowed by applicable law, in no event will Uniview be liable for any special, incidental, indirect, consequential damages, nor for any loss of profits, data, and documents.
- The product described in this manual is provided on an "as is" basis. Unless required by applicable law, this manual is only for informational purpose, and all statements, information, and recommendations in this manual are presented without warranty of any kind, expressed or implied, including, but not limited to, merchantability,

satisfaction with quality, fitness for a particular purpose, and noninfringement.

- Users must assume total responsibility and all risks for connecting the product to the Internet, including, but not limited to, network attack, hacking, and virus. Uniview strongly recommends that users take all necessary measures to enhance the protection of network, device, data and personal information. Uniview disclaims any liability related thereto but will readily provide necessary security related support.
- To the extent not prohibited by applicable law, in no event will Uniview and its employees, licensors, subsidiary, affiliates be liable for results arising out of using or inability to use the product or service, including, not limited to, loss of profits and any other commercial damages or losses, loss of data, procurement of substitute goods or services; property damage, personal injury, business interruption, loss of business information, or any special, direct, indirect, incidental, consequential, pecuniary, coverage, exemplary, subsidiary losses, however caused and on any theory of liability, whether in contract, strict liability or tort (including negligence or otherwise) in any way out of the use of the product, even if Uniview has been advised of the possibility of such damages (other than as may be required by applicable law in cases involving personal injury, incidental or subsidiary damage).
- To the extent allowed by applicable law, in no event shall Uniview's total liability to you for all damages for the product described in this manual (other than as may be required by applicable law in cases involving personal injury) exceed the amount of money that you have paid for the product.

## Network Security

**Please take all necessary measures to enhance network security for your device.**

**The following are necessary measures for the network security of your device:**

- **Change default password and set strong password:** You are strongly recommended to change the default password after your first login and set a strong password of at least nine characters including all three elements: digits, letters and special characters.
- **Keep firmware up to date:** It is recommended that your device is always upgraded to the latest version for the latest functions and better security. Visit Uniview's official website or contact your local dealer for the latest firmware

**The following are recommendations for enhancing network security of your device:**

- **Change password regularly:** Change your device password on a regular basis and keep the password safe. Make sure only the authorized user can log in to the device.
- **Enable HTTPS/SSL:** Use SSL certificate to encrypt HTTP communications and ensure data security.
- **Enable IP address filtering:** Allow access only from the specified IP addresses.
- **Minimum port mapping:** Configure your router or firewall to open a minimum set of ports to the WAN and keep only the necessary port mappings. Never set the device as the DMZ host or configure a full cone NAT.
- **Disable the automatic login and save password features:** If multiple users have access to your computer, it is recommended that you disable these features to prevent unauthorized access.
- **Choose username and password discretely:** Avoid using the username and password of your social media, bank, email account, etc, as the username and password of your device, in case your social media, bank and email account information is leaked.
- **Restrict user permissions:** If more than one user needs access to your system, make sure each user is

granted only the necessary permissions.

- **Disable UPnP:** When UPnP is enabled, the router will automatically map internal ports, and the system will automatically forward port data, which results in the risks of data leakage. Therefore, it is recommended to disable UPnP if HTTP and TCP port mapping have been enabled manually on your router.
- **SNMP:** Disable SNMP if you do not use it. If you do use it, then SNMPv3 is recommended.
- **Multicast:** Multicast is intended to transmit video to multiple devices. If you do not use this function, it is recommended you disable multicast on your network.
- **Check logs:** Check your device logs regularly to detect unauthorized access or abnormal operations.
- **Physical protection:** Keep the device in a locked room or cabinet to prevent unauthorized physical access.
- **Isolate video surveillance network:** Isolating your video surveillance network with other service networks helps prevent unauthorized access to devices in your security system from other service networks.

### Learn More

You may also obtain security information under Security Response Center at Uniview's official website.

### Safety Warnings

The device must be installed, serviced and maintained by a trained professional with necessary safety knowledge and skills. Before you start using the device, please read through this guide carefully and make sure all applicable requirements are met to avoid danger and loss of property.

### Storage, Transportation, and Use

- Store or use the device in a proper environment that meets environmental requirements, including and not limited to, temperature, humidity, dust, corrosive gases, electromagnetic radiation, etc.
- Make sure the device is securely installed or placed on a flat surface to prevent falling.
- Unless otherwise specified, do not stack devices.
- Ensure good ventilation in the operating environment. Do not cover the vents on the device. Allow adequate space for ventilation.
- Protect the device from liquid of any kind.
- Make sure the power supply provides a stable voltage that meets the power requirements of the device. Make sure the power supply's output power exceeds the total maximum power of all the connected devices.
- Verify that the device is properly installed before connecting it to power.
- Do not remove the seal from the device body without consulting Uniview first. Do not attempt to service the product yourself. Contact a trained professional for maintenance.
- Always disconnect the device from power before attempting to move the device.
- Take proper waterproof measures in accordance with requirements before using the device outdoors.

### Power Requirements

- Install and use the device in strict accordance with your local electrical safety regulations.
- Use a UL certified power supply that meets LPS requirements if an adapter is used.
- Use the recommended cordset (power cord) in accordance with the specified ratings.
- Only use the power adapter supplied with your device.
- Use a mains socket outlet with a protective earthing (grounding) connection.
- Ground your device properly if the device is intended to be grounded.

## Battery Use Caution

- **When battery is used, avoid:**

- Extremely high or low temperature and air pressure during use, storage and transportation.
- Battery replacement.
- Use the battery properly. Improper use of the battery such as the following may cause risks of fire, explosion or leakage of flammable liquid or gas.
  - Replace battery with an incorrect type.
  - Dispose of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery.
- Dispose of the used battery according to your local regulations or the battery manufacturer's instructions.

## Regulatory Compliance

### FCC Statements

**This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:**

1. this device may not cause harmful interference, and
2. this device must accept any interference received, including interference that may cause undesired operation.

#### Visit

[http://en.uniview.com/Support/Download\\_Center/Product\\_Installation/Declaration/](http://en.uniview.com/Support/Download_Center/Product_Installation/Declaration/) for SDoC.

**Caution:** The user is cautioned that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

### LVD/EMC Directive



This product complies with the European Low Voltage Directive 2014/35/EU and EMC Directive 2014/30/EU.

### WEEE Directive–2012/19/EU



The product this manual refers to is covered by the Waste Electrical & Electronic Equipment (WEEE) Directive and must be disposed of in a responsible manner.

### Battery Directive-2013/56/EU





Battery in the product complies with the European Battery Directive 2013/56/EU. For proper recycling, return the battery to your supplier or to a designated collection point.



---

## Documents / Resources

	<p><a href="#">uniview 0211C5L1 Smart Interactive Display</a> [pdf] User Guide 0211C5L1, 2AL8S-0211C5L1, 2AL8S0211C5L1, 0211C5L1 Smart Interactive Display, Smart Interactive Display, Interactive Display, Display</p>
--	---

## References

- [Univ Suppliers Declaration of Conformity - Uniview - Leader of AIoT Solution](#)
- [User Manual](#)