

VAMAV LATX210 Line Array Speaker User Manual

Home » VAMAV » VAMAV LATX210 Line Array Speaker User Manual



- 1 VAMAV LATX210 Line Array
- **Speaker**
- **2 WHAT IS INCLUDED**
- **3 REAR PANEL INSTRUCTIONS**
- **4 INSTALLATION GUIDELINE**
- **5 SAFETY PRECAUTIONS**
- **6 SPECIFICATIONS**
- **7 TROUBLESHOOTING**
- 8 FAQ
- 9 Documents / Resources
 - 9.1 References




VAMAV LATX210 Line Array Speaker




WHAT IS INCLUDED

- 1 LATX210 Line Array Speaker
- 1 User Manual
- 1 Neutrik PowerCon Power cable
- 1 Warranty Card



REAR PANEL INSTRUCTIONS



- 1. Line Input: A combination 1/4" / XLR input jack used for connecting line-level sources.
- 2. Operating LEDs:
 - POWER LED: Illuminates when the speaker is powered on.
 - SIG LED: Illuminates when an input signal is present.
 - CLIP LED: Illuminates when the signal is clipping. If clipping occurs, the input volume should be reduced to prevent distortion and potential damage.
- 3. Link Output: An output port that allows you to connect and pass the audio signal to another active speaker, enabling you to daisy-chain multiple speakers together.
- 4. Master Volume Controller: A knob that controls the overall output volume of the speaker.
- 5. AC Line Input.
- 6. AC Line Output.
- 7. Fuse: Main fuse housing.
- 8. Power Switch: ON/OFF function.

INSTALLATION GUIDELINE

Professional Installation

Always hire a professional to install the LATX210 line array speaker. Installation by qualified personnel ensures compliance with safety standards and optimal performance of theequipment.

Use of Flybar

We strongly encourage the use of a fly bar approved by VAMAV that is designed specifically for the LATX210 model.

Stacking Limitations

Do not stack more than 10 units of the LATX210 model to prevent the risk of toppling and potential damage or injury. Ensure that the stacking meets manufacturer's recommendedstacking grade and adhere to all stability and safety guidelines.

SAFETY PRECAUTIONS

General Safety

- 1. Do not install or fly this Line Array speaker unless you are qualified and adhere to all relevant safety standards.
- 2. Do not use solvents or cleaners based on petrochemicals to clean the plastic enclosure of the Line Array speaker.
- 3. Do not place objects that emit heat, such as lighting equipment or smoke machines, on the speaker cabinet.
- 4. Do not expose the Line Array speaker to direct rain or standing water to prevent the risk of electrical shorts and other hazards.
- 5. Regularly check the connection points and electrical contacts, including those on the spacer, for signs of wear, corrosion, or damage. Address any issues promptly to maintain optimal functionality and safety.
- 6. Do not handle any of the system's electrical connections with wet hands or while standing in water. Ensure that both your environment and your hands are dry when manipulating the system's components.

Handling Precautions

- 1. Do not stack the speakers unsafely as it may result in them toppling and causing injury or damage.
- 2. Do not use the built-in handles for rigging. They are for transportation purposes only.

Additional Safety Precautions for Auto-Amplified Devices

Electrical Integrity

- Do not install the Line Array speaker without first ensuring that the electrical output matches the speaker's requirements.
- Always disconnect the speaker from the power supply before you start any connections.
- Do not let the power cord become crimped or damaged. Avoid contact with other cables and always handle the power cord by the plug.
- Do not replace the fuse with one of different specifications. Always use a fuse of the same rating and dimensions.

Handling and Installation

- Do not use the speaker's handles to hang it. Use proper rigging equipment for any\ overhead installations.
- Do not lift speakers heavier than 20 kg(45lb) alone. Use team lifting to prevent injuries.
- Do not leave cables unsecured. Manage cables properly to avoid tripping hazards by securing them with tape
 or ties, especially across walkways.

Operational and Environmental Conditions

- Do not cover the Line Array speaker with anything or place it in poorly ventilated areas to avoid overheating and potential fire risk.
- Avoid placing the Line Array speaker in environments with corrosive gases or salty air, which could lead to malfunctions.
- Do not expose your ears to high sound levels for prolonged periods without protection to prevent hearing loss.
- Do not continue to use the Line Array speaker if it produces distorted sound as this may lead to overheating and potentially a fire.

User Information

Please read the user manual thoroughly before connecting or operating your newVAMAV loudspeaker, paying special attention to the sections about operational precautions and wiring.

Do not dispose of this product with household waste. The symbol on the product or its packaging indicates it should be taken to an appropriate collection point for recycling. Proper disposal helps prevent potential environmental damage and health hazards while conserving natural resources. For more detailed information about recycling this product, please contact your local city office, your household waste disposal service, or the shop where you purchased the product.

VAMAV Inc. reserves the right to make changes without prior notice in order to correct any errors and/or omissions. Please always consult the most recent version of the manual at

www.VAMAV.com

SPECIFICATIONS

- RMS Power 800W
- Maximum Power 1600W
- Max SPL 130dB
- Driver Information
 - LF: 2*10" neodymium woofer with 2.5" voice coil
 - HF: 1*3" neodymium voice coil
- Materials Plywood with Polyurea coating
- Voltage 110v-230v
- Amplifier Class D DSP
- With Display No
- Wireless Connectivity No
- Product Dimension(LxWxH) 78.5x45x30 cm / 30.9×17.7×11.8 inches
- Product Weight 28.2 kg / 62.2 lb

TROUBLESHOOTING

Problems	Solutions
	Check Connections: Ensure that the power cord is securely and safely plugged into both the Line Array speaker and the power outlet.
The power won't turn on.	Power Switch: Verify that the power switch is turned on.

Problems	Solutions
	• Level Settings: Check if the input source level knob is turned all the way down. Adjust all volume controls appropriately within the syste m, and ensure that the mixer is receiving a signal by observing the leve I meter.
	Signal Source: Confirm that the signal source is operational.
	Cable Integrity: Inspect all connecting cables for damage and e nsure they are securely connected at both ends. The output level contr ol on the mixer should be high enough to drive the speaker inputs.
No sound is produced.	Mixer Settings: Make sure the mixer is not muted or a processor loop is not engaged. If any of these settings are on, turn the level down before disengaging.
	Volume Levels: Check if the level knobs for relevant channels a nd/or the master level control are set too high.
Distorted sound or noise is present.	External Device Volume: Lower the volume of the connected de vice if it's too high.
	Volume Levels: Confirm that the level knobs for relevant channe ls and/or master level are not set too low.
The sound is not loud enough.	Device Volume: Increase the output volume of the connected d evices if too low.
	Disconnecting Cables: Disconnect the cable from the input jack to check if the hum stops, indicating a possible ground loop issue rathe r than a Line Array speaker fault.
	Use Balanced Connections: Utilize balanced connections acros s your system for optimal noise rejection.
Hum is heard.	Common Grounding: Ensure that all audio equipment is plugged into outlets with a common ground, keeping the distance as short as possible between the common ground and outlets.

WWW.VAMAV.COM

Looking for help? Contact us to get support.

- support@us.vamav.com
- www.vamav.com

FAQ

- Q: Can I stack more than 10 units of LATX210?
 - A: No, stacking more than 10 units can pose a risk of toppling and potential damage or injury.
- Q: Can I clean the Line Array speaker with petrochemical-based cleaners?
 - A: No, it is recommended not to use solvents or cleaners based on petrochemicals to clean the plastic

enclosure.

Documents / Resources



VAMAV LATX210 Line Array Speaker [pdf] User Manual LATX210, LATX210 Line Array Speaker, Line Array Speaker, Array Speaker, Speaker

References

• User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.