

VAXEE OUTSET AX Wireless Mouse User Guide

Home » VAXEE » VAXEE OUTSET AX Wireless Mouse User Guide



Contents

- **1 VAXEE OUTSET AX Wireless**
- Mouse
- 2 Contents of Package
- 3 Setup
- 4 Wired Mode
- **5 Wireless Mode**
- **6 Mouse Features**
- 7 Specifications
- **8 Recommended Usage Environment**
- 9 Charging and Power LED Lights
- **10 Motion Sync Adjustment**
- 11 Displaying Mouse Status
- 12 FCC Approval
- 13 Documents / Resources




VAXEE OUTSET AX Wireless Mouse




Contents of Package


- 1. Mouse
- 2. Wireless Dongle (USB)
- 3. Wireless Dongle Adapter
- 4. Charging and Data Cable



Setup




Wired Mode



Connect the mouse to any USB port on your PC using the charging cable

Wireless Mode

Plug the wireless USB dongle into any USB port on your PC.



Mouse Features



- 1. Left Button
- 2. Right Button
- 3. Middle Button
- 4. Back Button
- 5. Forward Button
- 6. DPI Switch Button
- 7. Report Rate Button
- 8. Click Latency Button
- 9. Power Switch

Specifications

DPI 400 dpi 800 dpi 1600 dpi 3200 dpi

• **DPI Settings:** 400 / 800/1600 / 3200 dpi

• Adjustable USB Report Rate: 125 / 500 / 1000 Hz

Adjustable Click Latency. 2/3 / 4/8 ms
Adjustable Competitive Mode: On / Off

• Adjustable Motion Sync: On / Off


 Battery Life: Consistent motion at 1000Hz – Up to 100hrs in Standard Mode and 55hrs in High Competitive Mode Charging Speed: From 0%-100% in roughly 1hr 50mins
Charging Speed: From 0%-100% in roughly 1hr 50mins

• **Weight:** 73g

Sensor: PAW3395Connector: USBButtons: 9 buttons


• Cable Length: 2 meters (6.6 feet)

Recommended Usage Environment



For optimal wireless performance, use a mouse within 20cm of Wireless Dongle and further than 2m from sources of 2.4GHz interference (such as Wi-Fi routers)

Charging and Power LED Lights



- Connect the USB cable to use it in wired mode
- Charging: Both lights blink in a cycle
- Fully Charged Both lights stay on continuously

LED Lights during Charging

• Hold the Right Button (2) + Middle Button (3) to display the current charge level of the mouse.



Lift-off distance Adjustment




• Hold the Report rate switch button (7)| while the power is off then turn on the power:



Motion Sync Adjustment



• Hold the DPI switch button (6) while the power is off then turn on the power:



DPI light blink in green for 3 times and goes off, means switch the Motion Sync to On.

DPI light blink in blue for 3 times and goes off, means switch the Motion Sync to Off. (Default)

Competitive Mode Adjustment




Hold the Click Latency button (8)| while power is off While holding, turn the power on



- If the number 4 indicator light blinks 3 times and goes off Competitive Mode Off.
 - If the number 2, 4 and 8 indicator lights blink 3 times and go off Competitive Mode On. (Default)

Displaying Mouse Status




- Hold the Forward button + Back button + Middle button (3+4+5)
- Indicator lights on the bottom will show the current status of the mouse.



B Dongle Function

- Ax Wireless provides an A/B dongle switch function
- If you require an additional dongle, please visit the VAXEE website to make your purchase.



• For dongle pairing and switching, please scan the QR code below for the "VAXEE Dongle User Manual".



FCC Approval

This device had been tested in accordance with the procedures and in compliance with Part 15 Subpart B of FCC Rules, and keeps all requirements according to ANSI C63.4 & FCC Part 15 B Regulation and CISPR22 Class B.

FCC 15.21:

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

15.109:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference,
- 2. this device must accept any interference received, including interference that may cause undesired operation.

15.105:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions,

may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RF Exposure Warning: This device contains transmitters and receivers that emit Radio Frequency (RF) energy. The device is designed to comply with the limits for exposure to RF energy set by the Federal Communications Commission (FCC) of the United States, Industry Canada (IC) of Canada, and the regulating entities of other countries.

Documents / Resources

