



# Vekesen D01 Tik Tok Remote Controller Bluetooth Shutter User Manual

[Home](#) » [Vekesen](#) » Vekesen D01 Tik Tok Remote Controller Bluetooth Shutter User Manual 

## Contents

- 1 Vekesen D01 TikTok Remote Controller Bluetooth Shutter
- 2 Packing List
- 3 Use Diagrams
- 4 Power on and Pairing
- 5 Connect a mobile phone
- 6 Key Function
- 7 Low battery alarm
- 8 Charging Diagram
- 9 Automatic shutdown function
- 10 Specification Parameter
- 11 Documents / Resources
  - 11.1 References
- 12 Related Posts

# Vekesen

**Vekesen D01 TikTok Remote Controller Bluetooth Shutter**



## Packing List



Charging box



Controller



Type-C charging cable




Instructions


## Use Diagrams



LED indicator



Type-C charging port




Key indication




Charging port indication

## Power on and Pairing




- In the power off state, press and hold the middle key for one second, the red and blue light flash alternately, the power on and automatically enters the pairing state (or when the phone is disconnected)



## Power off




- In the power-on state, press and hold the middle key for 5 seconds, the red light will be on




## Connect a mobile phone

### Mode 1: Manual Connection




- In the power off state, press and hold the middle key of the controller for one second, the red and blue lights flash alternately. The controller is pairing. At this time, turn on the Bluetooth of the mobile phone and search for the device.
- The Bluetooth menu shows: 001 and click, and complete the Bluetooth connection according to the prompt. If you can't find it please try turning off Bluetooth and turning it on again until the connection is completed

### Mode 2: Automatic Connection




- After power on, the controller automatically connects the last connected mobile phone (ensure that the Bluetooth of the mobile phone is turned on)

## Key Function



## Take Pictures and Record Videos



In photo or video mode on your phone, press the up or down keys for 2 sec to take a photo or start and end recording video. one click the middle key to focus

## Notes:

1. only support the original phone camera to take photos and record videos
2. not support taking photos and video functions when using the Tik Tok apps to watch videos

## Low battery alarm

### 1. Controller


- When the power of the controller is low, the red light flashes slowly to indicate that charging is needed

### 2. Charging box

- When the charging box is low, the blue light flashes slowly to indicate that charging is needed


## Charging Diagram

### Charging box charging



Charging	Fully charged
Red light lighting	The red light goes out

### Controller charging




Charging	Fully charged
Blue light lighting	The blue light goes out


### Automatic shutdown function

1. For normal pairing or pairing enabled by disconnecting from the mobile phone, if the mobile phone is not connected within 5 minutes, it will automatically shut down
2. If there is no operation after pressing the button for 30 minutes, it will shut down automatically

### iPhone / iPad Settings

- iPhone and iPad need to turn on the Assistive touch button before they can be used normally Please see the below picture





**Once you're done  
a dot appears  
on the screen**

**Notes:**

1. Make sure the iOS software of your device is above 14.8
2. If you still can't control the TikTok video after the touch button is turned on Please restart your device

**Specification Parameter**




Controller	
Bluetooth version	Ver.5.0
Frequency (Hz)	<b>2.40GHz~2.48GHz</b>
Bluetooth name	D01
Password	0000
Distance	10 meters
Battery capacity	25mAH
Charging time	About 1.5 hours
Charging box	
Battery capacity	200mAH
Charging time	About 2 hours

- Email support at [4078462@qq.com](mailto:4078462@qq.com)
- (we will reply within 24 hours)



## Documents / Resources

	<p><b><a href="#">Vekesen D01 Tik Tok Remote Controller Bluetooth Shutter</a></b> [pdf] User Manual</p> <p>D01, D01 Tik Tok Remote Controller Bluetooth Shutter, Tik Tok Remote Controller Bluetooth Shutter, Remote Controller Bluetooth Shutter, Controller Bluetooth Shutter, Bluetooth Shutter, Shutter</p>
---	---

## References

- [User Manual](#)

[Manuals+.](#) [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.