



VENTION 2A7Z4-ADC ADC Wireless HDMI Transmitter and Receiver User Manual

[Home](#) » [VENTION](#) » VENTION 2A7Z4-ADC ADC Wireless HDMI Transmitter and Receiver User Manual 

Contents

- [1 VENTION 2A7Z4-ADC ADC Wireless HDMI Transmitter and Receiver](#)
- [2 Specifications](#)
- [3 Product Overview](#)
- [4 Hardware Installation](#)
- [5 Pairing](#)
- [6 FAQ](#)
- [7 FCC Warning](#)
- [8 Contents](#)
- [9 Documents / Resources](#)
- [10 Related Posts](#)

VENTION®

VENTION 2A7Z4-ADC ADC Wireless HDMI Transmitter and Receiver




Specifications

- **Model:** ADC
- **Color:** Black
- **Interface:** USB-C/HDMI
- **Electroplating process:** Gold-Plated
- **Material:** ABS
- **Resolution:** 1080p@60Hz
- **Power supply:** 5V-2A
- **Working capacity:** 16
- **Wireless frequency:** 5GHz
- **Effective range:** 40 m(Max)

Product Overview

Receiver-RX and Transmitter-TX



Hardware Installation

Plug and Play, Makes Set up Easy



1. Connect the HDMI out port of the receiver (X)to the HDMI video output port on your display.


2. Connect the included USB-C cable to the power port (USB-C) on the receiver (RX) and to a nearby USB-C power source or power adapter (5V/2A).
3. Select the corresponding HDMI input source on your display device to ensure that the signal from the HDMI receiver (RX) is displayed correctly on the screen.
4. Connect the HDMI in port on the transmitter (TX) to the HDMI video input. port on your source device. After the indicator flashes about 20 seconds. the video and audio signals from the source device are displayed on the connected display device.

Note: Ensure there is an available USB-C power source or power adapter (5V/2A), at your local and remote locations.

Pairing

The product has been paired out of the factory. In case of pairing failure due to improper operation or other circumstances during use, it is necessary to restore and re pair the device as follows.

Indicator activity	Status
Slow flashing	Disconnected
Fast Flashing	Pairing
Solid on	Connected



1. Please press the receiver function button for more than 3 seconds, and the prompt will pop up on the interface: Connecting... enter pairing mode.
2. Press the transmitter function button for more than 5 seconds, the indicator will flash for pairing. and wait for the transmitter indicator to be solid on, indicating that the connection is successful.

FAQ

1. **Q: How to performed factory default?**
 - The factory default function can be performed as a troubleshooting step.
 - Press and hold the receiver function button for 10 seconds. After a black screen appears and restart. the factory default will be performed.
2. **Q: Can devices without an HDMI interface be used?**

- Yes, you can use the device with an HDMI converter.

3. Q: How to enter privacy mode?

- Tap the transmitter function button to disconnect or reconnect.

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:


- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.


NOTE3: The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

FCC RF Exposure Information and Statement the SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. This Wireless HDMI Transmitter and Receiver had been tested against this SAR limit. This device was tested for typical body-worn operations with the device kept 0mm from the body. To maintain compliance with FCC RF exposure requirements, use accessories that maintain an 0 mm separation distance between the user's body and the device. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.


Contents



Wireless HDMI Transmitter
and Receiver x1



HDMI Extension
Cable (0.2 m) x 1



USB-C Power Cord
(1 m) x 2



User Manual
x1

For more interesting information and events, please follow us on social media platforms:



Facebook



LinkedIn




Instagram

For warranty service or support, please contact Venation team:

Website: www.ventiontech.com Email: vention@ventiontech.com

Documents / Resources

	<p>VENTION 2A7Z4-ADC ADC Wireless HDMI Transmitter and Receiver [pdf] User Manual 2A7Z4-ADC ADC Wireless HDMI Transmitter and Receiver, 2A7Z4-ADC, ADC Wireless HDMI Transmitter and Receiver, HDMI Transmitter and Receiver, Transmitter and Receiver, Receiver</p>
---	---