

Vgate vLinker MC WiFi OBDII Diagnostic Scanner for iOS and **Android User Guide**

Home » Vgate » Vgate vLinker MC WiFi OBDII Diagnostic Scanner for iOS and Android User Guide 1





Vgate vLinker MC WiFi Quick Start **Guide for iOS and Android**



1. How do I know whether my vehicle is OBDII compliant?

1996 or newer model year vehicle sold in the United States. United States legislation requires all cars and light trucks model year (MY) 1996 and newer to be OBD2 compliant.

2001 or newer model year gasoline vehicle sold in the European Union. 2004 or newer model year diesel vehicle sold in the European Union.



(U.S OBDII Certified label)

2. want to know which OBDII protocols are supported by clinker MC WiFi?

- √ SAE J1850 PWM
- √ SAE J1850 VPW
- √ISO 9141-2
- √ ISO 14230-4(slow)
- √ ISO 14230-4(fast)
- √ ISO 15765-4(CAN)
- √ SAE J1939(CAN)
- √ ISO 11898(raw can)
- √ Single Wire CAN(GMLAN)
- √ Medium Speed CAN(MS-CAN)

3. Download & install the APP.

- √ Torque Lite<most popular Lite version is free>
- √ OBD Auto Doctor<Excellent Free app,

Upgrade to Pro in-app>

- √ OBD Fusion<Excellent 3rd party app>
- √ BimmerCode<download from google play of Android>

Allows you to code the control units in your BMW or mini to unlock hidden features and customize your car to your liking.

√ FORScan for Windows<Download from www.for scan.org>and for Android <download from google play> FORScan is a powerful software scanner for Ford, Mazda, Lincoln and Mercury vehicles, designed to work over OBDII protocol and J2534 Pass-Thru compatible adapters.







Auto Doctor



OBD Fusion







NOTE: clinker MC WiFi can support many apps, such as TORQUE Lite/Pro, OBD Fusion, DashCommand, CAR SCANNER ELM OBD2, Carista OBD2, BimmerCode, BimmerLink, JScan, OBD Auto Doctor, LeafSpy, Dr.Prius, TrackAddict, Harry's LapTimer, FORScan Lite, Garage Pro, etc.

Many apps may be added to the compatibility list. The product page will be updated accordingly or contact us regarding app compatibility.

5. Plug clinker MC WiFi into the OBD port.

The OBDII DLC is usually located under the instrument panel (Dash) on the driver's side. If you want to know more about DLC, please visit:

https://en.wikipedia.org/wiki/Data_link_connector_(automotive)






6. Turn ignition to Key On, Engine Off Position.



"POWER" red LED is turn on, and the "Wi-Fi" blue LED starts to blink twice, the "OBD" green LED and "HOST" orange LED blinks once. —LEDs are off? Check vehicle for blown fuses.

7. Torque(Lite) Connection Guide for Android (for example)

Step 1: Insert the adapter into the OBD interface of the car. Turn ignition to Key On, Engine Off Position. Open the Wi-Fi settings and connect "clinker MC".




Note: You need to Click Decline when your phone shows such a prompt, otherwise the connection will fail.


(You can not use a network when connecting to Wi-Fi.)



Press the "Connect" button to wake up the clinker MC WiFi.



Step 2: Choose to Open the app's Settings.



Step 3: Select OBD2 Adapter Settings

Vgate vLinker MC WiFi OBDII Diagnostic Scanner for iOS and Android - app7




ATTENTION:

The company will not bear any loss if the car is damaged without any vehicle maintenance during using the Torque(Lite) APP and Car Scanner APP.

.Step 4: Click Connection.

Step 5: Choose the connection type WiFi.




Step 6: If the communication is successful, you can select the control unit you want...



8. Car Scanner Connection Guide for iOS (for example)

Step 1: Insert the product into the OBD interface of the car. Turn ignition to Key On, Engine Off Position. Enable your phone WLAN, select device name "clinker MC".




IMPORTANT NOTE:

When you configure your phone, in order to get more engine data, you can start your engine.

Step 2: Open Car Scanner APP, Click

Step 3: Click" Connection".




Step 4: Select "Wi-Fi", Device name select "clinker MC".




Step 5: Return to the main page and click "CONNECT". This may take a few minutes.

Step 6: ELM and ECU are successfully connected.



Step 7: If the communication is successful, you can select the control unit you want...



Automatically OBD device wake up and Super Power Saving on clinker series

- √ Allow the user to leave the clinker MC WiFi in OBD Socket without unplugging and plug operation. Super low power consumption<sleep mode> is low to "3mA" level.
- √ Wake up clinker MC WiFi in standby mode by pressing the key.

Need Help?

Please email us at any time: sale@vgate.com.cn We will reply to you within 24 hours of the working day.

Product Upgrade:

Website: http://www.vgatemall.com/downloadcenter

To upgrade the product, please download the upgrade package and user manual of the corresponding model.

Contents

- 1 FCC Warning:
- 2 Documents /

Resources

- 2.1 References
- **3 Related Posts**

FCC Warning:

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator & your body.



Documents / Resources



<u>Vgate vLinker MC WiFi OBDII Diagnostic Scanner for iOS and Android</u> [pdf] User Guide CV296, 2A45F-CV296, 2A45FCV296, vLinker MC WiFi, OBDII Diagnostic Scanner for iOS and Android, vLinker MC WiFi OBDII Diagnostic Scanner for iOS and Android

- What's new
- Vww: Download center-ShenZhen CheBoTong Technology Co., Ltd.

Manuals+,