



Home » Viewsonic » ViewSonic VB-Wifi-IN03 WIFI Module User Manual 🥦

Contents [hide]

- 1 ViewSonic VB-Wifi-IN03 WIFI Module
- 2 Introduction
- 3 Features
- **4 Product Pictures**
- 5 General Requirements
- 6 FCC Statement
- 7 Notice to OEM integrator
- 8 IPEX connector information
- 9 Test procedures and design verifications
- 10 FAQ
- 11 Documents / Resources
 - 11.1 References

ViewSonic

ViewSonic VB-Wifi-IN03 WIFI Module



Introduction


SKI.WB800D80U.5 module is based on AIC8800D80 solution. SKI.WB800D80U.5 is a WiFi6/BT5.4 combo low-power, high-performance and high-integrated dual band wireless communication module which is designed for meeting the customers' needs of small size and low cost. This module supports both WLAN and BT functions. Its WLAN/BT function supports the USB2.0 interface, and its BT function supports the UART interface, and the module meets the requirements of standard protocol IEEE 802.11 a/b/g/n/ac/ax. Such units as power management, power amplifier and low noise amplifier are integrated in the main chip of the module. Its WLAN PHY rate is up to 600.4Mbps@TX. The module can be applied in smart sound boxes, set-top boxes, game machines, printers, IP cameras, tachographs, and other smart equipment. This documentation describes the engineering requirements specification.

Features

December System	IEEE Std. 802.11a/b/g/n/ac/ax	
Reserving System	Bluetooth 2.1+EDR/3.0/4.x/5.2/5.3/5.4	
Chip Solution	AIC8800D80	
Band	2.4GHz/5G	

bandwidth	20/40/80M
Dimensions	19mm×17mm×3.2mm
Antenna	Stamp Hole
Installation Mode	SMD
Low Power Mode	Not Supported

Product Pictures



Top view

General Requirements

No.	Feature	Description
3-1	Operation Voltage	3.3V±0.3
3-2	Current Consumption	800mA
3-3	Ripple	≤120mV
3-4	Operation Temperature	0°C to +40°C
3-5	AntennaType	External antenna

3-6	Interface	USB2.0/UART
3-7	StorageTemperature	-40°C to +85°C

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference, and
- 2. This device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This module has been assessed against the following FCC rule parts: CFR 47 FCC Part 15 C (15.247, DTS and DSS) and CFR 47 FCC Part 15 E (NII). It is applicable to the modular transmitter

This radio transmitter GSS-IN03has been approved by Federal Communications Commission to operate with the antenna types listed below, with the maximum permissible gain indicated. Antenna types not included in this list that have a gain greater than the maximum gain indicated for any type listed are strictly prohibited for use with this device.

The concrete contents to check are the following three points.

- 1. Maximum antenna gains are shown in item 2.7 below.
- 2. Should be installed so that the end user cannot modify the antenna
- 3. Feed line should be designed in 50ohm

Fine-tuning of return loss etc. can be performed using a matching network.

The antenna shall not be accessible for modification or change by the end user. The module complies with FCC Part 15.247 / Part 15.407 and apply for Single module approval. Trace antenna designs: applicable.

Any deviation(s) from the defined parameters of the antenna trace, as described by the instructions, require that the host product manufacturer must notify the module grantee that they wish to change the antenna trace design. In this case, a Class II permissive change application is required to be filed by the grantee, or the host manufacturer can take responsibility through the change in FCC ID (new application) procedure followed by a Class II permissive change application.

- The device must be professionally installed.
- The intended use is generally not for the general public.
- It is generally for industry/commercial use.
- The connector is within the transmitter enclosure and can only be accessed by disassembly of the transmitter that is not normally required.
- The user has no access to the connector.
- Installation must be controlled.
- Installation requires special training.
- This equipment complies with FCC radiation exposure limits set forth for an
 uncontrolled environment. This equipment should be installed and operated with a
 minimum distance of 20cm between the radiator & your body. This transmitter must
 not be co-located or operating in conjunction with any other antenna or transmitter.

The following antennas have been certified for use with this module.
 Only antennas of the same type with equal or lower gain may also be used with this module.

Other types of antennas and/or higher gain antennas may require the additional authorization for operation. The installer should use unique antenna connector and Antenna types not included in this list that have a gain greater than the maximum gain indicated for any type listed are strictly prohibited for use with this device. The manufacturer of module will inform installer to meet with the FCC part 15.203 in the warning part.

Antenna Specification list below:

Antenna Type	Frequency Bands	Max. Antenna Gain (dBi)
Coaxial antenna (BT)	2402-2480MHz	4.06
Coaxial antenna (WiFi)	2412-2462MHz	4.06
Coaxial antenna (WiFi)	5180-5825MHz	3.35

- Please notice that if the FCC identification number is not visible when the module is
 installed inside another device, then the outside of the device into which the module is
 installed must also display a label referring to the enclosed module. This exterior label
 can use wording such as "Contains FCC ID: GSS-IN03"; any similar wording that
 expresses the same meaning may be used.
- Testing of the host product with all the transmitters installed referred to as the composite investigation test- is recommended, to verify that the host product meets all the applicable FCC rules. The radio spectrum is to be investigated with all the transmitters in the final host product functioning to determine that no emissions exceed the highest limit permitted for any one individual transmitter as required by Section 2.947(f). The host manufacturer is responsible to ensure that when their product operates as intended it does not have any emissions present that are out of compliance that were not present when the transmitters were tested individually.

If the modular transmitter has been fully tested by the module grantee on the required

number of channels, modulation types, and modes, it should not be necessary for the host installer to re-test all the available transmitter modes or settings. It is recommended that the host product manufacturer, installing the modular transmitter, perform some investigative measurements to confirm that the resulting composite system does not exceed the spurious emissions limits or band edge limits (e.g., where a different antenna may be causing additional emissions).


The testing should check for emissions that may occur due to the intermixing of emissions with the other transmitters, digital circuitry, or due to physical properties of the host product (enclosure). This investigation is especially important when integrating multiple modular transmitters where the certification is based on testing each of them in a stand-alone configuration.

- Any company of the host device which install this modular should perform the test of radiated & conducted emission and spurious emission etc. according to FCC Part 15C: 15.247 and 15.209 & 15.207, part 15 E 15.407,15B class B requirement, only if the test result comply with FCC part 15C: 15.247 and 15.209 & 15.207, part 15 E 15.407,15B class B requirement. Then the host can be sold legally. The host product manufacturer is responsible for compliance to any other FCC rules that apply to the host not covered by the modular transmitter grant of certification. If the grantee markets their product as being Part 15 Subpart B compliant (when it also contains unintentional-radiator digital circuity), then the grantee shall provide a notice stating that the final host product still requires Part 15 Subpart B compliance testing with the modular transmitter installed.
- The host manufacturer is recommended to use FCC KDB 996369 D04 Module
 Integration Guide recommending as "best practice" RF design engineering testing and
 evaluation in case non-linear interactions generate additional non-compliant limits due
 to module placement to host components or properties.
- This module is stand-alone modular. If the end product will involve the Multiple simultaneously transmitting condition or different operational conditions for a standalone modular transmitter in a host, host manufacturer have to consult with module manufacturer for the installation method in end system.

Notice to OEM integrator


• Must use the device only in host devices that meet the FCC RF exposure category of

- mobile, which means the device is installed and used at distances of at least 20cm from persons.
- This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.
- The end user manual shall include FCC Part 15 compliance statements related to the transmitter as show in this manual(FCC statement).
- Host manufacturer is responsible for compliance of the host system with module installed with all other applicable requirements for the system such as Part 15 B.
- Host manufacturer is strongly recommended to confirm compliance with FCC requirements for the transmitter when the module is installed in the host.
- The use condition limitations extend to professional users, then instructions must state that this information also extends to the host manufacturer's instruction manual.
- Host manufacturer is strongly recommended to confirm compliance with FCC requirements for the transmitter when the module is installed in the host.
- Must have on the host device a label showing Contains FCC ID: GSS-IN03
- FCC ID is not to be placed on the host at the same time and only hosts going into the US can use the FCC ID .
- Trace layout and dimensions including specific designs for each type:
 - 1. Layout of trace design, parts, antenna, connectors, and isolation requirements:



2. Boundary limits of size, thickness, length, width, shape(s), dielectric contain, and impedance must be clearly described for each type of antenna:

PCB Antenna trace antenna Dimension:




Connector 1	IPEX	Male pi n	50Ω	Surface mount	varies
-------------	------	--------------	-----	---------------	--------

Note:

- 1. RF trace between module RF pinout to antenna width is 0.5mmmm.
- 2. RF trace between module and antenna impedance is 50ohm.
- 3. The rotation Angle of the line is 45 degrees.

IPEX connector information

Size(mm):




Appropriate parts of manufacturers and specifications:

Information about devices on RF lines:


Parts list	Parts number	Size	Manufacturer
resistance	/	1/16W,0ohm	varies

If customers completely refer to our antenna design for their own design, the antenna performance should also be the same as ours.

Test procedures and design verifications



Production test procedures for ensuring compliance



FAQ

Q: What should I do if I encounter interference issues?

A: Ensure that the device is not causing harmful interference and adjust positioning if needed. Contact customer support for further assistance.

Q: Can I use my own antenna with the module?

A: Only use approved antenna types with permissible gain as indicated in the

specifications. Using unapproved antennas may violate FCC regulations.

Documents / Resources

ViewSonic VB-Wifi-IN03 WIFI Module [pdf] User Manual

VB-Wifi-IN03, VB-Wifi-IN03 WIFI Module, WIFI Module, Module

References

- User Manual
 - Module, VB-Wifi-IN03, VB-Wifi-IN03 WIFI Module, Viewsonic, WiFi
- Viewsonic module
 - —Previous Post

ViewSonic LSC520WU Laser Projector User Guide

Next Post—

ViewSonic VPC-A31-O1 Enterprise Device Slot In PC Owner's Manual

Manuals+, Privacy Policy | @manuals.plus | YouTube

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.