




VonHaus 3515258 135w Multi Tool with 40pc Accessory Set WM Instruction Manual

[Home](#) » [vonhaus](#) » VonHaus 3515258 135w Multi Tool with 40pc Accessory Set WM Instruction Manual 





VonHaus 3515258 135w Multi Tool with 40pc Accessory Set WM



Contents

- [1 Symbol](#)
- [2 INTENDED USE](#)
- [3 GENERAL PRECAUTION](#)
- [4 WORK AREA SAFETY](#)
- [5 GENERAL POWER TOOL USE AND CARE](#)
- [6 CLEANING & MAINTENANCE](#)
- [7 HAND HELD DIE GRINDERS & SMALL ROTARY TOOL](#)
- [8 TECHNICAL SPECIFICATION](#)
- [9 DECLARATION OF CONFORMITY](#)
 - [9.1 We](#)
 - [9.2 Description](#)
 - [9.3 And the Standards](#)
- [10 COMPONENT LIST](#)
- [11 COMPONENTS](#)
- [12 SANDING DRUMS](#)
- [13 OPERATION](#)
- [14 SPEED ADJUSTMENT](#)
- [15 INSTALLING FLEXI DRIVE](#)
- [16 USING THE STAND](#)
- [17 DISPOSAL INFORMATION](#)
- [18 CUSTOMER SERVICE](#)
- [19 WARRANTY](#)
- [20 COPYRIGHT](#)
- [21 THANK YOU](#)
- [22 Documents / Resources](#)
- [23 Related Posts](#)

Symbol

	Please read all instructions carefully before use and retain for future reference.
	CAUTION Sharp edges.
	Maintain a safe distance from bystanders.
	Protect your hands.
	Protect your eyes.
	Protect your ears.
	Protect your eyes.

PRODUCT DISPOSAL INFORMATION For electrical products sold within the European Community, at the end of the electrical product's useful life, it should not be disposed of with household waste. Please recycle where facilities exist. Contact your local authority for details of collection schemes in your area.

In all circumstances:

Do not dispose of in domestic waste.
Do not incinerate.
Do not abandon in the environment.
Do not dispose of WEEE as unsorted municipal waste.



Please read all instructions carefully before use and retain for future reference.

INTENDED USE

Only operate the power tool/machine for its intended purpose and within the parameters specified in this manual. This power tool/machine is for domestic use only. Do not use outdoors or on wet surfaces. This power tool/machine is not intended for use by persons with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless supervised or given appropriate instruction concerning the product's use by a person responsible for their safety.

GENERAL PRECAUTION

Do not allow to be used as a toy. Children should be supervised to ensure they do not play with the power tool/machine.

If the power tool/machine is not functioning properly, has been dropped, damaged, left outdoors, or immersed in liquid, do not use, contact DOMU Brands Customer Services.

Do not use the power tool/machine if any parts appear to be faulty, missing or damaged.

Ensure all parts are securely attached before use

RISK OF PERSONAL INJURY Avoid body contact with earthed or grounded surfaces such as pipes, radiators, ranges and refrigerators. There is an increased risk of electric shock if your body is earthed or grounded.

Prevent unintentional starting. Ensure the switch is in the off position before connecting to the power source and/or battery pack, picking up or carrying the tool. Carrying power tools with your finger on the switch, or energising power tools that are switched on, invites accidents.

Do not operate power tools in explosive atmospheres such as in the presence of flammable liquids, gases or dust. Power tools create sparks which may ignite the dust or fumes.

Always wear eye protection. Any power tool can throw foreign objects into your eyes and cause permanent eye damage. Always wear safety goggles (not glasses) that comply with ANSI safety standard Z87.1. Every day glasses have only impact resistant lenses.

Do not expose power tools to rain or wet conditions.

Water entering the power tools will increase the risk of electric shock.

Stay alert, watch what you are doing and use common sense when operating a power tool/machine. Do not use a power tool/machine while you are tired or under the influence of drugs, alcohol or medication. A moment of inattention while operating power tool/machine may result in serious personal injury.

Use personal protective equipment. Always wear eye protection. Protective equipment such as dust mask, non-skid safety shoes, hard hat, or hearing protection used for appropriate conditions will reduce personal injuries.

Prevent unintentional starting. Ensure the switch is in the off-position before connecting to power source and/or battery pack, picking up or carrying the tool.

Carrying power tool/machine with your finger on the switch or energizing power tool/machine that have the switch on invites accidents.

Remove any adjusting key or spanner before turning the power tool/machine on. A spanner or a key left attached to a rotating part of the power tool/machine may result in personal injury.

Do not overreach. Keep proper footing and balance at all times. This enables better control of the power tool/machine in unexpected situations.

Dress appropriately. Do not wear loose clothing or jewellery.

Keep your hair, clothing and gloves away from moving parts. Loose clothes, jewellery or long hair can be caught in moving parts.

If devices are provided for the connection of dust extraction and collection facilities, ensure these are connected

and properly used. Use of dust collection can reduce dust-related hazards.

WORK AREA SAFETY

Keep work area clean and well lit.

Cluttered or dark areas invite accidents.

Do not operate power tool/machine in explosive atmospheres, such as in the presence of flammable liquids, gases or dust.

Power tool/machine create sparks which may ignite the dust or fumes.

Keep children and bystanders away while operating a power tool/machine. Distractions can cause you to lose control.

GENERAL POWER TOOL USE AND CARE

the power tool/machine. Use the correct power tool/machine for your application. The correct power tool/machine will do the job better and safer at the rate for which it was designed.

Do not use the power tool/machine if the switch does not turn it on and off. Any power tool/machine that cannot be controlled with the switch is dangerous and must be repaired.

Disconnect the plug from the power source and/or the battery pack from the power tool/machine before making any adjustments, changing accessories, or storing power tool/machine tools. Such preventive safety measures reduce the risk of starting the power tool/machine accidentally. Store idle power tool/machine out of the reach of children and do not allow persons unfamiliar with the power tool/machine or these instructions to operate the power tool/machine.

Power tool/machines are dangerous in the hands of untrained users.

Maintain power tool/machines. Check for misalignment or binding of moving parts, breakage of parts and any other condition that may affect the power tool/machines operation. If damaged, have the power tool/machines repaired before use. Many accidents are caused by poorly maintained power tool/machines.

Keep cutting tools sharp and clean.

Properly maintained cutting tools with sharp cutting edges are less likely to bind and are easier to control.

Use the power tool/machine accessories and tool bits in accordance with these instructions, take into account the working conditions and the work to be performed.

Use of the power tool/machine for operations different from those intended could result in a hazardous situation.

CLEANING & MAINTENANCE

electrical components and or a component that has a plug attached.

Disconnect the plug from the power source before making any adjustments, changing accessories, or storing. Such preventive safety measures reduce the risk of starting the power tool accidentally.

Ensure the motor has fully stopped before cleaning, clearing a blockage, checking, or carrying out any maintenance on the tool.

Maintain your power tool. Check for misalignment or binding of moving parts, breakage of parts and any other condition that may affect the power tool's operation.

If damaged, have the power tool repaired by a qualified repair person before use. Many accidents are caused by poorly maintained power tools.

Keep cutting tools sharp and clean. Properly maintained cutting tools with sharp cutting edges are less likely to bind and are easier to control.

Regularly check external nuts and fixings to ensure vibration caused by normal use has not begun to loosen them. Store idle power tools out of reach of children and do not allow persons unfamiliar with the power tool or these instructions to operate the Breaker.

Locate the power tool out of reach of children, in a dry, locked unit.

Make sure that the cord is located so that it will not be stepped on, tripped over, or otherwise subjected to damage or stress.

Remove the plug from the mains socket / battery (where applicable) before carrying out any adjustment or maintenance.

Always store the power tool/machine in a dry place.

If the power cord is damaged, it must be replaced by a qualified service technician.
Keep the ventilation slots and motor housing as free of dirt and dust as possible (where applicable).
Clean the power tool/machine by rubbing it with a clean cloth and blow it clean using low-pressure compressed air is recommended

Ensure you have all the pieces listed. If you are missing any components, contact our customer services department at

hello@domu.co.uk (UK/EU)
usasupport@domubrand.com (US). DO NOT proceed with assembly if any components are missing.

HAND HELD DIE GRINDERS & SMALL ROTARY TOOL

Use clamps, or another practical way, to secure and support the workpiece to a stable platform. Holding the workpiece by hand or against your body leaves it unstable and may lead to loss of control.
Make sure there are no nails or foreign objects in the path of the workpiece to be cut or sanded.
Be aware of hidden hazards. Before cutting into walls, floors or ceilings, check for the location of wiring and pipes. When cutting pipe or conduit, make sure that they are free from water, electrical wiring, etc.
Keep hands away from cutting area. Never reach underneath the workpiece for any reason. Do not insert fingers or thumb into the vicinity of the blades/ sanding attachments. The blade will continue to move after releasing the switch. Always switch the tool off and wait for the blade to come to a complete standstill before putting the tool down.
Do not touch the workpiece or the blade immediately after operating the tool. They can become very hot.

TECHNICAL SPECIFICATION

Rated Voltage 220V-240V ~
Rated Power 135W
Rated Frequency 50Hz

DECLARATION OF CONFORMITY

We

DOMU Brands Ltd
5th Floor The Tower
Deva City Office Park
Manchester
M3 7BF

Declare under our sole responsibility the product:

SKU
3515258

Description

35W Rotary Multitool with 40pc Accessory Set

Complies with the essential requirements of the following directives:

2006/42/EC

2014/30/EU
2011/65/EU


And the Standards

BS EN 60745-1:2009+A11:2010, BS EN 60725-2-23:2013, EN 55014 1:2006+A1+A2, EN 55014-2:2015, EN 61000-3-2:2014, EN 61000-3-3:2013

Authorised Signatory on behalf of DOMU Brands Ltd.


A handwritten signature in black ink, consisting of several loops and a long horizontal stroke, followed by a solid horizontal line.

COMPONENT LIST





1. Spindle Lock Button
2. Carbon Brush Cover
3. Speed Adjustment Wheel
4. Storage Hook
5. Power Cable
6. On/Off Rocker Switch
7. Collet Chuck
8. Collet
9. Collar
10. Flexi Drive (3515258)
11. Telescopic Stand (3515258)
12. Clamp (3515258)


COMPONENTS




SANDING DRUMS






OPERATION




SPEED ADJUSTMENT



INSTALLING FLEXI DRIVE



USING THE STAND



DISPOSAL INFORMATION

Please recycle where facilities exist. Check with your local authority for recycling advice.



CUSTOMER SERVICE

If you are having difficulty using this product and require support, please contact hello@domu.co.uk (UK/EU)

WARRANTY

To register your product and find out if you qualify for a free extended warranty please go to www.vonhaus.com/warranty. Please retain a proof of purchase receipt or statement as proof of the purchase date. The warranty only applies if the product is used solely in the manner indicated in the warnings page of this manual, and all other instructions have been followed accurately. Any abuse of the product or the manner in which it is used will invalidate the warranty. Returned goods will not be accepted unless re-packaged in its original packaging and accompanied by a relevant and completed returns form. This does not affect your statutory rights. No rights are given under this warranty to a person acquiring the appliance second-hand or for commercial or communal use.

COPYRIGHT

All material in this instruction manual are copyrighted by DOMU Brands. Any unauthorised use may violate worldwide copyright, trademark, and other laws.

THANK YOU

Thank you for purchasing your product/appliance.

Should you require further assistance with your purchase, you can contact us at


hello@domu.co.uk (UK/EU)

usasupport@domubrand.com (US)

VonHaus is a registered trademark of DOMU Brands Ltd. Made in China for DOMU Brands. M24 2RW.



Documents / Resources

 <p>3515065 / 3515258</p>	<p>VonHaus 3515258 135w Multi Tool with 40pc Accessory Set WM [pdf] Instruction Manual 3515258 135w Multi Tool with 40pc Accessory Set WM, 3515258, 3515258, 135w Multi Tool with 40pc Accessory Set WM, Tool with 40pc Accessory Set WM, 40pc Accessory Set WM, Accessory Set WM, Set WM</p>
--	---