



vtech 2008232 KidiCom Advance 3.0 Smart Device User Guide

[Home](#) » [vtech](#) » vtech 2008232 KidiCom Advance 3.0 Smart Device User Guide 



Parents' Guide

The full KidiCom® Advance Parents' Guide can be found online at

Contents

- [1 2008232 KidiCom Advance 3.0 Smart Device](#)
- [2 Getting Started](#)
- [3 Key Features](#)
- [4 Parent Settings](#)
- [5 Additional Information](#)
- [6 Care & Maintenance](#)
- [7 END USER LICENSE AGREEMENT](#)
- [8 CONSUMER SERVICES](#)
- [9 PRODUCT WARRANTY/ CONSUMER GUARANTEES](#)
- [10 Documents / Resources](#)
 - [10.1 References](#)
- [11 Related Posts](#)

2008232 KidiCom Advance 3.0 Smart Device

V Tech understands that a child's needs and abilities change as they grow and with that in mind we develop our toys to teach and entertain at just the right level...



To learn more about this and other VTech® products, visit www.vtech.co.uk

Getting Started

Register your KidiCom® Advance 3.0 device to access:

- The full collection of educational games that come with this device
- 20 FREE apps from Learning Lodge™, a VTech® online store 1
- Kid-friendly messaging with the KidiCom Chat™ app
- Access to parent settings where you can manage your child's apps, set time limits, and more

1. **CHARGE** your KidiCom ® Advance 3.0 device using either the included power adapter plugged in to the wall, or the included USB cord plugged into a computer. Do not use a third-party adapter. The Charging Indicator Light will turn red to indicate it is charging and will turn green when it is fully charged in about 3.5 hours. Please ensure the battery is fully charged before the first use or before attempting a system update.

2. **SET UP** the device by following the on-screen prompts to connect to Wi-Fi 2 , set your time zone, and register with a Learning Lodge™ account.
3. **UNLOCK** the KidiCom Chat™ app after system registration and install the app on your mobile device.
4. **ENJOY** fun learning games, silly photos, kid-friendly messaging and more!

1 For first-time registration and designated content only

2 Supports Wi-Fi 802.11 b/g/n only

Key Features



Parent Settings

To enter Parent Settings, touch the Parents icon on the second page of your child's home screen. From Parent Settings, you can control the way your child plays by adding or removing apps, setting time limits, managing access to the Web, and adjusting device settings.

Adding or Removing Apps

Browse the Learning Lodge™ store for a selection of age-appropriate educational apps that have been approved by VTech® learning experts. If you're looking for common Android apps from outside of the VTech® ecosystem, go to Device Settings and select Get More Apps to find instructions to install a third-party app store.



You can manage apps and content through the following options:

- Storage Manager—Manage your device's memory.
- VTech® App Manager—Download or uninstall any content purchased from Learning Lodge™. You can also uninstall some of the apps that are included with the system.
- App Settings—Give permission for third-party apps you download to appear on your child's home screen.

Setting Time Limits

Select Time Controls to limit the amount of time your child can play per day or to mark certain hours of the day as off limits.

Managing Web Access

The Web Browser is OFF until enabled through the passcode-protected App Settings. Although VTech® makes every effort to ensure a kid-friendly browsing environment, the content of individual websites may change without VTech's knowledge. Please be sure to monitor your child's online experience and keep your passcode secret.


If You Forget Your Parent Settings Passcode

If you forget your Parents passcode, go to the passcode screen and enter 9876543210. We'll send a message to the email address provided at registration.

Additional Information

Using the Mag Lens


- The MagLens can be used to help take close-up photos. To use it, first rotate the camera unit so it's pointing away from the screen, then slide the MagLens switch to position the MagLens over the camera.

- Be sure to only use the MagLens switch to move the MagLens to avoid accidentally smudging the camera lens or MagLens. When the MagLens is in position, open the Camera app and hold the device steady at a distance of approximately one to two inches away from your subject. When the MagLens is positioned over the camera, you'll see a special icon  in the Camera app to let you know.



Charging the Device

- To charge the device, first connect the included USB cable or power adapter to the KidiCom® Advance 3.0 device by inserting the smaller, micro-USB end into the micro-USB port on the device.
- If using the power adapter, plug it in to a power outlet. If using the micro-USB cable, plug it in to a computer's USB port (computer not included).
- This toy contains batteries that are non-replaceable.



Australia/New Zealand

WARNING! SAFETY INSTRUCTIONS, PLEASE READ THOROUGHLY BEFORE GIVING THIS PRODUCT TO A CHILD. KEEP AWAY FROM FIRE OR HEAT SOURCE. BATTERIES CANNOT BE REPLACED.

The batteries within this toy are permanently encased. Before giving this toy to a child make sure there are no signs of damage. Regularly check the toy and dispose of it immediately if there are any signs of damage.

Do not dispose of the toy in a fire, as the batteries may leak and explode.

Keep batteries safely out of children's reach before disposing of them via a safe disposal system.

Guidelines for Charging With Micro-USB Cable

Only charge this device using the included micro-USB cable connected to a computer or with the included adapter. Do not charge using a thirdparty adapter. Before use, inspect the cord to confirm that it is in good condition and that there are no breaks or exposed wires. Ensure there are no particles or liquid (water, juice, etc.) in either of the connectors before plugging in either end of the cable. The device should be completely dry with no debris in the cable connectors when charging. Plug in the cable securely, in the correct orientation. If the device is on when plugged in, a dialog box may open on your computer to allow you to access the device's drive. Never leave the device unattended while charging. Do not charge your device on soft surfaces, as they can trap heat around the device. Typical charging time is between 2-3 hours if the battery is fully depleted. Disconnect the device when it is fully charged. Do not leave the device charging for more than 4 hours.

Power Adapter Specifications

Output: 5V DC

WARNING: For the purposes of recharging the battery, only use the 5V DC adaptor VT05EUK05100 provided with this toy.

Warning! Not suitable for children under 36 months. Electric toy. Electric shock hazard.

WARNING:

All packing materials such as tape, plastic sheets, packaging locks, removable tags, cable ties, cords and packaging screws are not part of this toy, and should be discarded for your child's safety.

NOTE: Please keep this Parents' Guide as it contains important information.



Battery disposal/recycling

As a responsible distributor, VTech® is committed to ensuring the correct disposal and reducing the environmental damage they can cause.

VTech® offers a returns program for products with inaccessible batteries (i.e. built-in Lithium Polymer batteries). Please email consumer_services@vtech.com with the subject "battery disposal" to obtain a returns form.

Care & Maintenance

1. Keep your KidiCom® Advance 3.0 out of direct sunlight and away from direct sources of heat.
2. Turn off your KidiCom® Advance 3.0 when not using it for an extended period of time.
3. Avoid dropping your KidiCom® Advance 3.0 and NEVER try to dismantle it.
4. Always keep your KidiCom® Advance 3.0 away from water.
5. This toy contains batteries that are non-replaceable.
6. Do not leave the toy in extremely high temperatures such as close to fire or hot oven.
7. Keep the rubber cover of the micro-USB port closed tightly while it is not in use in order to prevent dust or water from getting into the microUSB port.

Cleaning the KidiCom® Advance 3.0 Touch Screen



- Slightly dampen a soft, lint-free cloth with a little water and wipe the screen to loosen dirt.
- Use a clean and dry cloth to wipe the screen dry. Repeat these two steps as needed.

Cleaning the KidiCom® Advance 3.0 Cabinet

- Keep your KidiCom® Advance 3.0 clean by wiping it with a slightly damp cloth. Never use solvents or abrasives.

Standard guidelines for adaptor toys and electrically operated products



- Use only the VTech® adaptor (AC/DC 5V) that complies with EN61558/ EN62368
- This toy shall be used with the power supply supplied, if the power supply is supplied with the toy.
- This toy shall only be used with a power supply for toys with output DC 5V.
- The power supply is not a toy.
- This toy is not intended for use by children under 3 years old.
- Do not connect the toy to more than the recommended number of power supplies.
- Never clean a plugged in toy with liquid.
- Please examine the power supply periodically for conditions that may result in the risk of fire, electric shock, or injury to persons (such as damage to the supply cord, output cord, plug, blades, housing, or other parts) and that, in the event of such conditions, the power supply should be appropriately disposed of.
- Power supplies for toys are not intended to be used as toys, and the use of these products by children shall be under the full supervision of parents.
- As with all electrical products, precautions should be used and observed during handling and use to prevent electric shock.
- Do not leave the toy plugged in for extended periods of time.
- If the pins of the plug are damaged, the plug-in power supply should be scrapped.
- If the USB cable is damaged, it cannot be used and must be replaced with a recommended cable. Please visit www.vtech.co.uk or contact our Customer Service hotline on 0330 678 0149 (from UK), or +44 330 678 0149 (outside UK) for more information and to purchase a replacement.
- The battery is recyclable, please follow your local recycling regulations.
- This toy is only to be connected to equipment bearing either of the following symbols:  or 

Avoid use in the following conditions:

- Extreme high or low temperatures during use, storage or transportation.
- Low air pressure at high altitude.
- Disposal of the product into fire or a hot oven, or mechanically crushing or cutting the battery, which can result in an explosion.
- Extremely high temperature and/or extremely low air pressure that can result in an explosion or the leakage of flammable liquid or gas.






The applied nameplate is located at the bottom of the product.

Important safeguards

Before use, please read this instruction carefully and use the adaptor strictly according to the instruction:

1. The output power taken from the supply must not exceed the rating given on the power supply.
2. The appliance is not intended to be repaired by service personnel in case of failure or component defect (unit can be thrown away).
3. The external flexible cable or cord of this power supply cannot be replaced; If the cord is damaged, the power supply should be scrapped.
4. The disconnection from line voltage is made by pulling the mains plug.
5. The socket-outlet shall be installed near the equipment and shall be easily accessible.
6. For indoor use only.
7. Instructions to parents: Transformers and power supplies for toys are not intended to be used as toys, and the use of these products by children shall be under the full supervision of parents.

The following is an explanation of the symbols on the transformer:

| | |
|---|---|
|  | short-circuit-proof safety isolating transformer |
|  | Class II equipment |
|  | For Indoor Use Only |
|  | Switch mode power supply unit |
|  | Transformers for toys (non-inherently short-circuit-proof transformers) |

Information for external power supplies:

| | |
|---------------------------------|--|
| Trade Mark | VTech® |
| Comercial Registration Number | 2178243 |
| Address | Napier Court, Abingdon Science Park, Abingdon, Oxon, OX14 3YT, U.K |
| Model Identifier | VT05EUK05100 |
| Input voltage/AC frequency | 100-240VAC 50-60Hz |
| Output voltage | 5VDC |
| Output current | 1A |
| Output power | 5W |
| Average active power efficiency | 73.80% |
| No load power consumption | 0.09W |

Disposal of batteries and product



The crossed-out wheeled bin symbols on products and batteries, or on their respective packaging, indicates they must not be disposed of in domestic waste as they contain substances that can be damaging to the environment and human health.



The chemical symbols Hg, Cd or Pb, where marked, indicate that the battery contains more than the specified value of mercury (Hg), cadmium (Cd) or lead (Pb) set out in the Batteries and Accumulators Regulation.

The solid bar indicates that the product was placed on the market after 13th August, 2005. Help protect the environment by disposing of your product or batteries responsibly.

VTech® cares for the planet.

Care for the environment and give your toy a second life by disposing of it at a small electricals collection point so all its materials can be recycled.

In the UK:

Visit www.recyclenow.com to see a list of collection points near you.

In Australia & New Zealand:

Check with your local council for kerbside collections.

WARNING

A very small percentage of the public, due to a pre-existing condition, may experience epileptic seizures or momentary loss of consciousness when viewing certain types of flashing colours or patterns, especially on screens. While the KidiCom® Advance 3.0 device does not contribute to any additional risks, we do recommend that parents supervise their children while they play video games. If your child experiences dizziness, altered vision, disorientation, or convulsions, discontinue use immediately and consult your doctor. Please note that focusing on an LCD screen at close range for a prolonged period of time may cause fatigue or discomfort. We recommend that children take a 15-minute break for every hour of play.

CAUTION

When you are not charging the battery or connected to a computer, close the USB port cover on the KidiCom® Advance 3.0 device for safety. Use the power adapter and micro-USB cable that came with this device to charge it. Please note: VTech® is the only service provider that is authorised to replace the battery on your KidiCom® Advance 3.0 device. Any attempt to remove or replace the battery by a third party or by yourself may damage your KidiCom® Advance 3.0 device and will void your warranty. If you feel your battery needs service, please contact the VTech® Customer Services Department.

NOTES

Static electricity may cause the KidiCom® Advance 3.0 device to malfunction. In some cases, the game play score stored in the device's memory may be lost. In cases where the KidiCom® Advance 3.0 device is malfunctioning due to static electricity, reset it by pressing and holding the Power Button for 10 seconds until the unit turns off. Then press and hold the Power Button for three seconds to turn the unit on again.

To prevent possible hearing damage, do not listen at high volume levels for long periods.

Note: Maximum output voltage 150mV.

This product is licensed under the AVC patent portfolio license for the personal use of a consumer or other uses in which it does not receive remuneration to: (i) encode video in compliance with the AVC standard ("AVC video") and/or (ii) decode AVC video that was encoded by a consumer engaged in a personal activity and/or was obtained from a video provider licensed to provide AVC video.

No license is granted or shall be implied for any other use. Additional information may be obtained from MPEG LA, L.L.C. See mpegla.com Hereby, VTech® Electronics Europe BV declares that the radio equipment type 5411 is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: www.vtech.com/re-directive. Radio Frequency Band: 2.4-2.483GHz, Maximum RF power: 50mW(17dBm) Hereby, VTech® Electronics Europe PLC declares that the radio equipment type 5411 is in compliance with The Radio Equipment Regulations 2017 (2017 No.1206). The full text of the Declaration of conformity is available at the following internet address: www.vtech.com/re-directive Frequency Band: 2.4-2.483GHz, Maximum RF power: 50mW(17dBm)

USB cable with ferrite must be used with this equipment to ensure compliance with the EMC Directive 2004/108/EC limits.

Disclaimer and Limitation of Liability

VTech® Electronics Europe PLC and its suppliers assume no responsibility for any damage or loss resulting from the use of this handbook. VTech® Electronics Europe PLC and its suppliers assume no responsibility for any loss or claims by third parties that may arise through the use of this software. VTech® Electronics Europe PLC and its suppliers assume no responsibility for any damage or loss caused by deletion of data as a result of malfunction, dead battery, or repairs. Be sure to make backup copies of important data on other media to protect against data loss.

Company: VTech® Electronics Europe PLC

Address: Napier Court, Abingdon Science Park, Abingdon, Oxon, OX14 3YT.

Phone : 0330 678 0149 (from UK), or +44 330 678 0149 (outside UK)

END USER LICENSE AGREEMENT

This is a legal agreement between you and VTech® Electronics Europe PLC ("VTech®"), stating the terms that govern your use of software for KidiCom® Advance 3.0 device or in connection with the application of software, ("software"). "Software" includes audio files for the KidiCom® Advance 3.0 device.

By activating, using, downloading or installing this software, you are agreeing to be bound by the terms of this agreement. Your right to use the software is conditional upon your agreement to these terms. If you determine that you are unwilling to agree to the terms of this license agreement, you have no right to use the software and you should promptly return the software to VTech or delete it.

If you are under the age of 18 or are otherwise considered a minor in your jurisdiction, you should review these terms and conditions with your parent or guardian (collectively, "parent") and make sure that your parent understands and agrees on your behalf to these terms and conditions.

Wherever this agreement refers to "you" or "your," it is meant to include both parent and children users, except where a child is not of sufficient legal age to enter into a binding contract (such as an e-commerce transaction) or provide any required consents (such as consent to data collection, processing, or transfers), in which case the parent of such child hereby acknowledges and agrees he/she is acting on the child's behalf to effectuate such contracts or consents and is fully liable for the actions or inactions of such child with respect to the use of the software and related services. 1. OWNERSHIP. The Software and Documentation (including all content contained within the Product) are owned by VTech®, or its licensors, and are protected by international copyright and other intellectual property laws. The Software and Documentation shall only be used by you in accordance with this Agreement. The Software and Documentation are licensed, not sold. Except as specifically set forth herein, VTech® and its licensors retain all right, title and interest, including all intellectual property rights, in and to the Software and Documentation.

2. LICENSE TERMS. VTech® grants to you, subject to the terms, conditions and limitations further defined in this Agreement, a non-exclusive, nonsublicenseable, non-transferable license for non-commercial use, and to use the Documentation in connection with such use of the Software. Any modifications, upgrades, error corrections, or other updates to the Software provided by VTech® to you shall be deemed part of the Software and use thereof shall be governed by the terms and conditions of this Agreement, unless the parties have entered into a separate, written agreement governing such modifications, upgrades, error corrections, or other updates.

3. RESTRICTIONS ON REVERSE ENGINEERING AND SECURITY. Except to the extent otherwise expressly and unambiguously authorised by VTech® or to the extent such restrictions are explicitly prohibited by applicable law, you shall NOT reverse engineer, decompile, disassemble, translate or attempt to learn the source code of the Software (ii) copy, modify, create derivative works of, distribute, sell, assign, pledge, sublicense, lease, loan, rent, timeshare, deliver or otherwise transfer the Software (iii) remove from the Software, or alter or add, any copyright, trademarks, trade names, logos, notices or markings (iv) violate, tamper with or circumvent any security system or measures implemented by VTech® which are designed to prevent unauthorised copying of the Software. Any such forbidden use shall immediately terminate your license to the Software without any prior notice.

4. LIMITED WARRANTY. VTech® warrants to you subject to your compliance with the terms herein that for a period of ninety (90) days from the date you purchase the Product, the Software will substantially conform to VTech's published specifications for the Software. Your sole and exclusive remedy under the foregoing warranty shall be for VTech®, at its choice, to use commercially reasonable efforts to correct any substantial non-conformity of the Software reported to VTech® in writing within the warranty period and/or provide a replacement copy of the Software. The foregoing warranty shall not apply to any non-conformity that is caused by (i) the use or operation of the Software with an application or in an environment other than that intended or recommended by

VTech®, (ii) modifications to the Software not made by VTech® or (iii) third party hardware or software provided by any third party.

VTech® makes no warranties that the software is error free or is suitable for your purposes. VTech® makes no warranties other than those set forth above, and hereby disclaims all other warranties, whether express, implied or statutory, with respect to the software or documentation, including, without limitation, any implied warranties of merchantability, fitness for a particular purpose, or noninfringement. No oral or written information or advice given by VTech®, its resellers, agents or employees shall create a warranty.

5. Limitation of liability. In no event shall VTech® be liable for any loss of profits, use of data, cost of replacement goods or hardware, or other indirect, incidental, special, or consequential damages arising out of your use or inability to use the software download or documentation, even if VTech® has been advised of the possibility of such damages, and notwithstanding the failure of essential purpose of any remedy. You agree that in no event will VTech's aggregate liability hereunder or related to your use of the software or documentation exceed the amount paid for the product and/or software.

6. TERMINATION. This License Agreement will automatically terminate if you fail to comply with any term thereof. No notice shall be required from VTech® to effect such termination.

Dear customer,

Please take a few moments to read our Privacy Policy to get full information regarding how your personal data is handled by VTech®. This Privacy Policy is available at https://www.vtech.co.uk/privacy_policy

CONSUMER SERVICES

Creating and developing VTech® products is accompanied by a responsibility that we at VTech® take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department with any problems and/or suggestions that you might have. A service representative will be happy to help you.

UK Customers:

Phone: 0330 678 0149 (from UK) or +44 330 678 0149 (outside UK) Website: www.vtech.co.uk/support

Australian Customers: Phone: 1800 862 155 Website: support.vtech.com.au

NZ Customers: Phone: 0800 400 785 Website: support.vtech.com.au

PRODUCT WARRANTY/ CONSUMER GUARANTEES

UK Customers: Read our complete warranty policy online at vtech.co.uk/warranty.

Australian Customers: VTECH ELECTRONICS (AUSTRALIA) PTY LIMITED CONSUMER GUARANTEES


Under the Australian Consumer Law, a number of consumer guarantees apply to goods and services supplied by VTech Electronics (Australia) Pty Limited. Please refer to vtech.com.au/consumerguarantees for further information.

Visit our website for more information about our products, downloads, resources and more.











www.vtech.co.uk

www.vtech.com.au



| | |
|---|--|
|  | <p>vtech 2008232 KidiCom Advance 3.0 Smart Device [pdf] User Guide 2008232, KidiCom Advance 3.0 Smart Device, 2008232 KidiCom Advance 3.0 Smart Device, Advance 3.0 Smart Device, Smart Device</p> |
|---|--|

References

-  [ViaLa – Empowering innovation worldwide](#)
-  [Support : VTech Electronics](#)
-  [Electronic Learning Toys | Best Learning Toys | VTech UK](#)
-  [vtech.com](#)
-  [Electronic Learning Toys | Best Learning Toys | VTech UK](#)
-  [Electronic Learning Toys | Best Learning Toys | VTech UK](#)
-  [VTech Toys Australia - Electronic Learning Toys - Best Learning Toys - VTech Australia and New Zealand](#)
-  [VTech | Product Support](#)
-  [vtech.co.uk/privacy_policy](#)
-  [Electronic Learning Toys | Best Learning Toys | VTech UK](#)