


WayCai GNCC Smart Bird Feeder with Camera Set Up With **Vicohome App User Guide**

Home » WayCai » WayCai GNCC Smart Bird Feeder with Camera Set Up With Vicohome App User Guide 🖺



WayCai GNCC Smart Bird Feeder with Camera Set Up With Vicohome App




Contents

- 1 Introduction
- 2 Pair the Camera to your Phone App
- 3 About Cloud Storage and Bird Fans Plan
- 4 Share the camera with others
- **5 Al Identification**
- 6 How to Connect charging cable and waterproof rubber stopper
- 7 Documents / Resources
 - 7.1 References
- **8 Related Posts**

Introduction

Download Vicohome App from App Store or Google Play. You can also download the App by scanning the QR code above with the QR code scanner in your smartphone.




Pair the Camera to your Phone App

Note: Before installing your bird feeder and camera, please setup your camera first.


Step 1:


Go to your App Store or Google Play on your smartphone, for "Vicohome "Or just scan the QR code below to download the app:




Then please sign up for a new account, please check the screenshot below for your reference:


- 1. Tap "Sign up for a new account"
- 2. Input your user name, your country "the United State", and your E-mail address. And then check on the "Agreement and Privacy policy Let's go to "Next Step".






- 3. You will receive the Verification Code from your E-mail, put it in and then go to "Next Step" .
- 4. Set password for your account, and then go to "Done".
- 5. Congratulations! You have already registered successfully. Let's the "+" icon to add the camera now!







Step 2:


Hold the power button to power up the camera, the indicator light will keep blue. And finally you will hear the pairing sound from the camera, which means that the camera is ready for connection.

- 1. If you hear the sound from the camera, please go to "Next Step".
- 2. The device is found, please tap the device at this page.





- 3. Connect WIFI to the camera, select your network and input your WIFI password.
- 4. Tap "Join", please.






- 5. Wait for a second, you will see this page and the camera would say "WIFI connected". You're almost done.
- 6. Seta name for the device and go to "Next Step" .

Connection succeeded

Set a name and location for the device




- 7. Check your WIFI signal strength, tap "Done".
- 8. Here we go! the "play" icon, you will see the camera image.


Please place the device where you need to install it and check the strength of the Wi-Fi signal.



Confirm your Wi-Fi signal strength: Medium

It's recommended to mount the device in the current location.






About Cloud Storage and Bird Fans Plan

How to get 30 days of free cloud storage

For new register we have 30 days free cloud storage

- 1. Please go to Vicohome app, then tap try it free.
- 2. Please go to "Bird Fans Plan" get it free.
- 3. After one month this service needs to be subscribed.



Share the camera with others

Step 1:

The invitee needs to download the APP on Vicohome her/his smartphone.


Step 2:


After installing and registering a new account to login, just go to the app homepage, tap on the "+" sign in the upper right corner, and then select "Add friend's device". Then please scan the QR code of device ad min.

How to find the device ad min QR code?

See the screenshot below. Just go to the administrator's Vicohome app. Go to the settings icon> Share> Device Sharing








Al Identification

A bird came to the bird feeder and triggered the camera recording and Al Identification.



How to Connect charging cable and waterproof rubber stopper

When you connect the camera to the solar panel, please confirm that the charging cable plug is in good contact with camera.

1. Prepare the solar panel with charging cable, take the rubber stopper out.



2. Thread the charging cable through the rubber plug.





3. Insert the charging cable and firm the rubber stopper.





PLEASE DON'T

insert the charging cable directly with the rubber on the plug.

Incorrect Connection



Q1: Why doesn't the Wi-Fi name appear when I connect to Wi-Fi?

A1: You need to turn on the "location permission" for the app in the system settings and change it to "allow when using"

Q2: Will the camera show red lights when night vision is activated?

A2: The built-in infrared lamp beads make the camera only show some dim red lights when night vision is activated, but the image quality is still clear under no light environment.

Q3: What are the requirements for Wi-Fi?

A3: Please use a 2.4GHz wireless network. The device does not support the 5GHzwireless network. Meanwhile, please set the Wi-Fi authentication method to wpa2-pskor other lower level of the security method. A password is required.

Q4: How far should the camera be placed from the router?

A4: After testing, the WiFi connection distance can normally reach up to 100 meters in the open area. However, the actual situation depends on the strength of Wi-Fi and its surrounding environment.

Q5: What is the maximum length of recording time?

A5: You can choose the recording time in the app, The camera record for a fixed time or "auto" mode, when depending on whether there is a person, the maximum length of a video is 3 minutes.

Q6: What should I do when the device is malfunctioning?

A6: Long press the power button to restart the camera.

Documents / Resources



WayCai GNCC Smart Bird Feeder with Camera Set Up With Vicohome App [pdf] User Guid

GNCC Smart Bird Feeder with Camera Set Up With Vicohome App, GNCC, Smart Bird Feeder with Camera Set Up With Vicohome App, Feeder with Camera Set Up With Vicohome App, Camera Set Up With Vicohome App, Vicohome App

References

• User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.