



Weego 22 Jump Starter User Guide

[Home](#) » [Weego](#) » Weego 22 Jump Starter User Guide 


Weego 22 Jump Starter User Guide



Contents

- [1 GETTING TO KNOW WEEGO 22](#)
- [2 JUMP STARTING](#)
- [3 TROUBLESHOOTING](#)
- [4 USB CHARGING](#)
- [5 LIGHTING](#)
- [6 Documents / Resources](#)
 - [6.1 References](#)
- [7 Related Posts](#)

GETTING TO KNOW WEEGO 22



CHARGE UP YOUR WEEGO 22

When you unpack your new Weego Jump Starter 22 for the first time, charge it up to 100% using the Micro USB Charging Cord or Car Charger provided. If using the micro USB cord, make sure you use a USB enabled wall adapter (like the one that comes with your smartphone or tablet) with an output of 2.1A or greater to charge as quickly as possible.

Indicator Lights Sequence:



POWERING ON/OFF

There's a Power ON/OFF Button on the back of your Weego 22. Make sure you turn OFF your Weego 22 after every use; leaving it on slowly drains the battery.

It takes 2.5 hrs. to fully charge using a 2.1A USB adapter and 1.5 hours to fully charge using the supplied 3A Car Charger. The indicator lights will flash one by one while the unit is charging. A solid light indicates a completed level of charge.

JUMP STARTING


BEFORE YOU JUMP

- Read all instructions and safety information prior to using this product. Improper use of this product will void your warranty and may result in product damage, excess heat, toxic fumes, re, and other unsafe conditions for which Weego is not responsible.
- Read vehicle owner's manual rst: it may have specic cautions and instructions about jumping your engine.
- This product is for use on 12V Lead-Acid batteries only! DO NOT use this product on any other voltage battery, such as 6V, 24V, etc. DO NOT use this product on lithium-ion batteries.
- Never jump or operate any engine in an enclosed area.
- Put your vehicle in PARK and engage the emergency brake (boats and powersports vehicles should be put in NEUTRAL).
- TURN OFF ALL ELECTRONICS! – air conditioner, radio, lights, etc.
- Remove any devices attached to your Weego 22.
- Never leave your Weego 22 connected to your engine's battery unless actively jumping.
- Always disconnect the Smarty Clamps® from your Weego 22 when not in use.

WEEGO CUSTOMER SUPPORT We are dedicated to providing the best possible service. To reach Weego Customer Support, visit myweego.com/support or email support@myweego.com.

JUMP STARTING YOUR ENGINE


1. Ensure your engine is completely OFF.



2. Securely connect the Smarty Clamps® to your Weego 22, then power ON.
3. Place your Weego 22 in a secure location or suspend using the provided hook & lanyard so it won't fall.



4. Attach BLACK clamp to your battery's negative (-) terminal, then the RED clamp to your battery's positive (+) terminal. Adjust your Smarty Clamps® to achieve MAXIMUM contact with the terminals. Poor connections will prevent you from starting your engine! Clear off any dirt or buildup with a wire brush or a dry towel before connecting your clamps.



5. Check your Smarty Clamps® lights. When you have a GREEN READY light, start your engine. If the engine doesn't start, check your Smarty Clamps® lights and wait a minute before trying again.



6. After a successful start, disconnect the Smarty Clamps® from your Weego 22.



7. Detach the Smarty Clamps® from the battery.

8. You're now good to go – be sure to run your engine for at least 15 minutes before shutting it off again so it has time to recharge your battery.



If you are having issues getting your engine started, see Troubleshooting section in your owner's manual for further details and assistance.

TROUBLESHOOTING

Visit www.myweego.com/support/ for FAQs and additional troubleshooting inquiries.

My unit won't power on/charge/charge past a few lights

If your unit won't power on, won't take a charge OR won't charge past a few lights then it's been over discharged. This can happen if the unit is left ON, or if an engine pulled the Weego battery past a certain limit during a jump start. If your unit won't power on, won't take a charge OR won't charge past a few lights then it's been over discharged. This can happen if the unit is left ON, or if an engine pulled the We ego battery past a certain limit during a jump start.

Please reach out to support@myweego.com to let them know about this issue – we'll receive and test the over discharged We ego, then determine if we can repair it or if it needs to be fully replaced.

The Weego won't jump start my vehicle

A few things can attribute to a failed jump start, which we listed below.

For more detail please visit our troubleshooting page at www.myweego.com/support


- Poor connection between the Weego clamps and vehicle battery: the better the connection, the more likely you are to have a successful jump
- Dirty battery terminals: build up prevents all the available power from reaching your battery

WARNING!

Exposed Metal Jaws May Be HOT After Use!

UNDERSTANDING YOUR Smarty Clamps®

Your Smarty Clamps® have a "smart" box that will help guide you through a jump with both sight and sound. It will let you know when it is safe to jump or if there is an error.



- **READY**

Solid green light, no Sound Smarty Clamps® detect that you have a good connection and you are ready to jump.

- **REVERSE +/- Flashing Green & Red Lights + Beeping**

You attached the Smarty Clamps® on the wrong terminals. Make sure the BLACK clamp is attached to the battery's NEGATIVE (-) terminal, and the RED clamp is attached to the battery's POSITIVE (+) terminal. If not attached properly, Weego 22 will not let you jump your engine.

- **COOL DOWN WAIT FOR Flashing Red Light + Beeping**

The Weego battery overheats after long cranks or excessive current draw. Detach the Smarty Clamps® from the battery and give the unit up to 3 minutes to cool down. Then, repeat steps 2-5 under Jump Starting Your Engine.

- **SEE REVERSE Solid Red Light, No Sound**

This means the vehicle's battery is too weak to even start, OR the system voltage of your vehicle is not compatible with your Weego 22 (for 12V vehicles ONLY).

- **SEE REVERSE Solid Red Light + Beeping**

There may be an engine size issue. If your engine is larger than what we recommend, it will try to pull more power than your Weego 22 is able to give. Please see Engine Compatibility in the owner's manual to determine if your engine size falls within the scope of Weego 22.

No Light

Either you have a poor connection, or your battery is so dead (nearly 0 volts) that your Weego clamps cannot register a connection.

- Vehicle-specific compatibility issues: occasionally we come across a vehicle that has unique power demands that a smaller model cannot fulfill, even though it's within our recommended engine range. In addition, vehicles with heavier electronics can sometimes create issues when jumping with a Weego; we mostly see this in push-to-start vehicles.
- Cold temperatures: Freezing temperatures create a lot of resistance in an engine which means it can require up to 3.5X the usual amount of power to get started; for example, an engine that usually needs 200A could need up to 700A in the extreme cold. In addition, if your Weego was stored in the cold temps it will make it harder for the Weego to deliver its full power.
- Low-Charged Weego: it's always best to work with full power on your Weego if you can. Our jump starters perform better at 100% charge than they do at 20% charge, especially when jumping larger engines.

USB CHARGING



USB Charging Port

Charge your phone, tablet and other portable devices with your Weego 22 using your own USB charging cord. Your Weego 22 comes equipped with Detect-o-Matic™ USB Charging. This intelligent charger communicates with your device to detect and deliver the fastest-possible charge.

To charge your devices, plug your charging cord into your Weego 22 USB port and connect to your device. Power on your Weego 22 and start charging!

LIGHTING



Flashlight Button

Your Weego 22 comes with a 250 lumen LED flashlight. Power on your Weego 22, then briefly press and release the flashlight button to initiate the following sequences:

- **1st click:** Normal
- **2nd click:** Strobe
- **3rd click:** SOS
- **4th click:** OFF

You can also skip directly to the OFF position by holding down the flashlight button.

Your Weego 22 will give you up to 7 hours of flashlight time and up to 14 hours of strobe & SOS light on a full charge.

© 2018. Weego is a division of Paris Corporation. Patented & Patents Pending. All Rights Reserved. Rev 10/18
myweego.com





[Weego 22 Jump Starter](#) [pdf] User Guide
22 Jump Starter, 22, Jump Starter, Starter

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.