

Weego N70 Portable Power User Guide

Home » Weego » Weego N70 Portable Power User Guide The second power User Guide The sec

Contents

- 1 Weego N70 Portable Power
- **2 GETTING TO KNOW WEEGO 70**
- **3 JUMP STARTING**
- **4 UNDERSTANDING YOUR Smarty**

Clamps

- **5 TROUBLESHOOTING**
- **6 USB-A & USB-C CHARGING**
- **7 LIGHTING**
- 8 Documents / Resources
 - 8.1 References
- 9 Related Posts



Weego N70 Portable Power



GETTING TO KNOW WEEGO 70



CHARGE UP YOUR WEEGO 70

- When you unpack your new Weego 70 for the first time, charge it up to 100% with either the wall or car charger and the included USB-C charging cord.
- Remember to recharge your Weego 70 every 6 months, even when you're not using it it will help extend its lifespan.

POWERING ON/OFF

- There's a Power ON/OFF Button on the back of your Weego 70. While powered "ON", the blue power button will remain illuminated.
- Make sure you turn OFF your Weego 70 after every use; leaving it on slowly drains the battery.



• It takes 3.5 hrs. to fully charge. The indicator lights will flash one by one while the unit is charging. A solid light indicates a completed level of charge.

JUMP STARTING

BEFORE YOU JUMP

- Read all instructions and safety information before using this product. Improper use of this product will void your
 warranty and may result in product damage, excess heat, toxic fumes, fire, and other unsafe conditions for
 which Weego is not responsible.
- Read the vehicle owner's manual first: it may have specific cautions and instructions about jumping your engine.
- This product is for use on 12V Lead-Acid batteries only! DO NOT use this product on any other voltage battery, such as 6V, 24V, etc. DO NOT use this product on lithium-ion batteries.
- Never jump an engine in an enclosed area.
- Put your vehicle in PARK and engage the emergency brake (boats and power sports vehicles should be put in NEUTRAL).
- TURN OFF ALL ELECTRONICS! air conditioner, radio, lights, etc.
- Remove any devices attached to your Weego 70.
- Never leave your Weego 70 connected to your engine's battery unless actively jumping.
- Always disconnect the Smarty Clamps® from yourWeego 70 when not in use.
- WEEGO CUSTOMER SUPPORT We are dedicated to providing the best possible service.
- To reach Weego Customer Support, visit myweego.com/support or email support@myweego.com.



Connect Clamps



Power ON



Attach Black (-), Then Red (+)



When You Have SOLID GREEN LIGHT On Your Smart Box, Start Your Engine



Once it Starts, Disconnect Clamps from Weego 70



Detach Clamps From Battery

JUMP-STARTING YOUR ENGINE

- 1. Ensure your engine is completely OFF.
- 2. Securely connect the Smarty Clamps® to yourWeego 70, then power it ON.
- 3. Attach the BLACK clamp to your battery's negative (-) terminal, then the RED clamp to your battery's positive (+) terminal. Adjust your Smarty Clamps® to achieve MAXIMUM contact with the terminals.
 - Poor connections will prevent you from starting your engine! Clear off any dirt or build-up with a wire brush or a dry towel before connecting your clamps.
- 4. Place your Weego 70 in a secure location or suspend using the provided hook & lanyard so it won't fall. Check your Smarty Clamps® lights.
- 5. When you have a SOLID GREEN READY light, start your engine. If the engine doesn't start, turn off your vehicle and check your Smarty Clamps® lights.
- 6. After a successful start, quickly disconnect the Smarty Clamps® from yourWeego 70.
- 7. Detach the Smarty Clamps® from the battery.

- 8. You're now good to go be sure to run your engine for at least 15 minutes before shutting it off again so it has time to recharge your battery.
 - If you are having issues getting your engine started, see the Troubleshooting section in your quick start guide, owner manual, or on myweego.com for further details and assistance.
 - WARNING! Exposed Metal Jaws May Be HOT After Use!

UNDERSTANDING YOUR Smarty Clamps

Your Smarty Clamps® have a "smart" box that will help guide you through a jump with both sight and sound. It will let you know when it is safe to jump or if there is an error.



TROUBLESHOOTING


- Visit <u>www.myweego.com/support</u> for FAQs and additional troubleshooting inquiries and details.
- My unit won't power on/ charge/ charge past a few lights
- If your unit won't power on, won't take a charge, OR won't charge past a few lights then it's been overdischarged. This can happen if the unit is left ON, or if an engine pulled the Weego battery past a certain limit during a jump start.
- Please reach out to <u>support@myweego.com</u> to let them know about this issue -we'll receive and test the
 over-discharged Weego, and then determine if we can repair it or if it needs to be fully replaced.

The Weego won't jump-start my vehicle

- We have listed below a few things that can cause a failed jump start.
- Poor connection between the Weego clamps and vehicle battery: the better the connection, the more likely you are to have a successful jump
- Dirty battery terminals: build up prevents all the available power from reaching your battery
- Vehicle-specific compatibility issues: occasionally we come across a vehicle that has unique power demands
 that a smaller model cannot fulfill, even though it's within our recommended engine range.
- In addition, vehicles with heavier electronics can sometimes create issues when jumping with a Weego; we mostly see this in push-to-start vehicles.
- Cold temperatures: Freezing temperatures create a lot of resistance in an engine which means it can require up to 3.5X the usual amount of power to get started; for example, an engine that usually needs 200A could need up to 700A in the extreme cold.
- In addition, if your Weego is stored in the cold temps it will make it harder for the Weego to deliver its full power.
- Low-Charged Weego: it's always best to work with full power on your Weego if you can. Our jump starters perform better at 100% charge than they do at 20% charge, especially when jumping larger engines.

USB-A & USB-C CHARGING

- Charge your phone, tablet, and other portable devices with yourWeego 70. Weego 70 comes equipped with Detect-o-Matic" USB Fast Charging.
- You can charge your USB-A devices by plugging in your own USB-A cord into your Weego 70 USB-A port OR by plugging your own USB-C to USB-C cord into your.
- Weego 70 USB-C input/output port. Connect to your device, power on Weego 70, and start charging!



LIGHTING

• YourWeego 70 comes with a 600-lumen LED flashlight. Power on your Weego 70, then briefly press and release the flashlight button to initiate the following sequences.



1st click: Normal2nd click: Strobe3rt click: SOS4th click: OFF

- YourWeego 70 will give you up to 15 hours of flashlight time and up to 30 hours of strobe & SOS light on a full charge.
- © 2021. Weego is a division of Paris Corporation.
- US Patent #9692155, #D823243.
- All Rights Reserved. Rev 05/21 myweego.com

Documents / Resources



<u>Weego N70 Portable Power</u> [pdf] User Guide N70, N70 Portable Power, N70, Portable Power, Power

References

User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.