

WESECUU
T-CP8040LF-W3M
WIFI Bulb Camera



WESECUU T-CP8040LF-W3M WIFI Bulb Camera Quick Guide

[Home](#) » [Support](#) » WESECUU T-CP8040LF-W3M WIFI Bulb Camera Quick Guide 

Contents

- [1 WESECUU T-CP8040LF-W3M WIFI Bulb Camera Quick Guide](#)
- [2 Interface description](#)
- [3 Installation and placement](#)
- [4 Software Installation](#)
- [5 Bluetooth adding process with network](#)
- [6 Or you can add a camera by WiFi configuration](#)
- [7 Troubleshooting](#)
- [8 After Service](#)
- [9 References](#)
- [10 Related Posts](#)

WESECUU

WESECUU T-CP8040LF-W3M WIFI Bulb Camera Quick Guide




Before operating this unit, please read these instructions carefully, and save them for future use.

Interface description

This manual is suitable for various types of cameras. (The appearance may be different due to different batches. The details are subject to the receipt. This manual is only for the installation instructions of this series of equipment)

WIFI Bulb camera




Description

1. Reset button
2. SD card slot
3. Power supply The working state of the device, long press 5 seconds to restore the factory settings, the camera will have a voice prompt broadcast. TF card, storage video and playback video.
Power input.

Installation and placement

WIFI Bulb camera



Connected to an E27 connector for AC110V-240V

Software Installation

APP Download and Installation

Users can search "EseeCloud(IP Pro, VR Cam)" on APP store or Google Play, or scan the QR code below to install the APP.

Note: For iOS system, it requires iOS 9.0 version or above. For Android, Android 5.1 or above.



EseeCloud APP



APP download

- **Step 1**


If you are prompted to open certain permissions (such as location, message notification, etc.) during APP installation, click Allow (agree).

- **Step 2**

Account register: Open the APP, click "Register", enter your email or phone number to create an account.

Account login: On the login interface, enter the account/ phone number/email, and the corresponding password, and click the "OK" button to log in.

Third-party login: APP supports third-party login. Click the third-party social software icon, jump to the APP to complete the authorization and log in.




The image shows the Eseecloud mobile application login and registration screen. At the top right, there is a link "Encounter problems" with a question mark icon. The main heading is "Eseecloud" in blue, followed by "Welcome to EseeCloud". Below this are three tabs: "Phone number", "Account" (which is selected and underlined), and "Quick login". Under the "Account" tab, there is a section labeled "Account" with a text input field "Enter phone number, email or username" and a dropdown arrow. Below this is a "Password" section with a text input field "Password" and a toggle icon for password visibility. To the left of the password field is a red arrow pointing to the "Register" link. To the right of the password field is a "Forget password" link. Below these links are two buttons: "Last login" (a dark grey button) and "Login" (a large blue button). At the bottom of the login section, there is a checkbox "Login to agree" followed by links to "User Agreement" and "Privacy Policy". At the very bottom, there is a section titled "More login methods" with icons for WeChat, Google, LINE, and a back arrow.

Bluetooth adding process with network

“Before adding a camera, please make sure that the Bluetooth function of the mobile phone has been turned on, and do not turn off the Bluetooth during the adding process. If a prompt box pops up during the adding process to enable Bluetooth or Bluetooth authorization, please follow the steps in the prompt to enable it;

1. Step 1



After the camera is powered on, open the “EseeCloud “APP Device Group and click the “+” icon in the upper right corner to enter the interface of adding devices.




(If the permission prompt pops up, click agree)

2. Step 2

The APP will automatically search for a new device and click the Add button when it finds the device.





(If you do not see the pop-up device box, please click “scan to add” to scan the QR code on the camera body).



3. Step 3

Enter the WIFI name and password on the distribution network screen.




4. Step 4

After the network is configured successfully, the system prompts you to enter the device name. Click Next.

5. Step 5

Users can choose to enable or disable message push according to your own preferences. (generally recommended to enable).




6. Step 6

Congratulations, you have successfully connected the device.

Or you can add a camera by WiFi configuration


1. Step 1

Open the APP, click the “+” icon in the middle of the interface to enter the scan code interface;




2. Step 2

Click the "Camera scan code add" method



3. Step 3

Check whether the camera light is blinking




4. **Step 4**

Select the WiFi that the camera needs to connect to, enter the password, and click Next;

5. **Step 4**

Select the WiFi that the camera needs to connect to, enter the password, and click Next;




6. **Step 5**

Point the camera at the QR code that appears on the screen of the phone.



7. Step 6


After the network configuration is successful, set a name for the camera.



Troubleshooting

Help FAQ

Q1: Why is the pairing network unsuccessful?



1. please make sure that the distance among the camera, the router and the mobile the phone should be close enough when configuring the network.
2. Please make sure that the WiFi signal connected to the mobile phone 2.4G Wifi and 5G WiFi are both ok.
3. Please check whether the WiFi name and password are correct.
4. Please long press the reset button for 5 seconds and try again after restoring the camera to the factory settings

Q2: Why is there no playback?

Local storage

Local storage space

Used capacity: 3%

In good
condition >

Download local video files >


Format the memory card >

1. Make sure that the TF card has been inserted into the camera and try to turn on/off the camera.
2. Enter the camera settings menu to check the storage status 'in good condition' (if the status is abnormal, click to "Format the memory card".)

Q3: Why is the camera offline?

1. It may caused by router WIFI signal interference or network reasons. Power off and restart the optical modem, router or camera.
2. The camera maybe too far away from the WIFI router, try to get the camera next to the WIFI router.
3. Whether the WIFI password has been changed, try to reset the camera and try pairing again.

Q4: Why my phone does not have an alarm push function or two way audio?



1. Check your mobile phone permission settings, and make sure that enable the notification permission of the “EseeCloud” App.
2. Open your phone’s Settings > Apps and Notifications, select Apps and Notification Management respectively, find the “EseeCloud” app, and turn on all permissions.

After Service

1. Thanks for your purchase and support, we appreciate all your valuable feedback.
2. If you have any questions about our products, please feel free to contact us.

Toll-Free: +1 888 971 6718

3. **Email:** primefocus2021@outlook.co

bulb camera uses Instructional video



Download this Manual: [WESECUU T-CP8040LF-W3M WIFI Bulb Camera Quick Guide](#)

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.