



# Wiznet WizFi360 Application Note SPI User Guide

[Home](#) » [WIZnet](#) » [Wiznet WizFi360 Application Note SPI User Guide](#) 

## Contents

- [1 Wiznet WizFi360 Application Note SPI](#)
- [2 Product Information](#)
- [3 Product Usage Instructions](#)
- [4 Introduction](#)
- [5 Pinout](#)
- [6 SPI pins are from PB13 to PB17 in the below Figure 1. WizFi360 Pinout.4 SPI Frame Format](#)
- [7 Operation](#)
- [8 Documents / Resources](#)
  - [8.1 References](#)



**Wiznet WizFi360 Application Note SPI**



## Product Information

Product Name: WizFi360

Version: 1.0.1

Manufacturer: WIZnet Co., Ltd.

Website: <http://www.wiznet.io/>

Copyright: 2022 WIZnet Co., Ltd. All rights reserved.

## Product Usage Instructions

### Introduction:

The WizFi360 operates in SPI slave mode and can be controlled via AT commands. To communicate with the MCU, the SPI pins must be connected, and the SPI\_EN(PB13) pin must be set to Low for SPI. Refer to Figure 1 in the WizFi360 Pinout section to locate the SPI pins. When the SPI\_INT(PB14) pin is set to low, the SPI master can read the received data.

### Pinout

The SPI pins are located from PB13 to PB17 as shown in Figure 1 in the WizFi360 Pinout section.

### SPI Frame Format

The WizFi360 is controlled by the SPI frame format sent from the SPI master. The SPI frame consists of the following frames:

- SPI Control Frame
- AT CMD Frame
- Data Frame

The Data Frame consists of RX DATA Frame and TX DATA Frame. During the control phase, users can select the default status, buffer save size, CMD, DATA SEND, and DATA RECEIVE.

### SPI Control Frame

Before writing or reading data into the WizFi360, the following information must be read from the SPI Control

Frame:

- TX BUFF AVAIL
- RX DATA LEN
- INT STATUS

The SPI Control Frame sends 1 byte of control byte and reads 2 bytes of status data.

### Document Revision History

Version	Date	Descriptions
Ver. 1.0.0	19NOV2019	Initial Release
Ver. 1.0.1	05APR2022	Modify Figure 1

### Introduction

WizFi360 operates in SPI slave mode and can be controlled via AT commands. In order to communicate with the MCU, the SPI pins must be connected and set the SPI\_EN(PB13) pin to Low for SPI. Refer to Figure 1. WizFi360 Pinout to locate the SPI pins. If the SPI\_INT(PB14) pin is set to low when WizFi360 has received data, the SPI master can read the data.

### Pinout

SPI pins are from PB13 to PB17 in the below Figure 1. WizFi360 Pinout.




Figure 1. WizFi360 Pinout

#### 4 SPI Frame Format

WizFi360 is controlled by the SPI frame format sent from the SPI master. The SPI frame is controlled by CSn and composed of SPI Control Frame, AT CMD Frame, and DATA Frame. DATA Frame composed RX DATA Frame and TX DATA Frame. Users can select the default status, buffer save size, CMD, DATA SEND, and DATA RECEIVE during the control phase.

##### SPI Control Frame

TX BUFF AVAIL, RX DATA LEN, and INT STATUS must be read before users write or read data into WizFi360. The SPI Control Frame sends 1Byte of control byte and reads 2Byte of status data.

- 0x03(TX BUFF AVAIL) : checks whether the peer buffer is ready to write data before transmission.
- 0x02(RX DATA LEN) : reads the data length accumulated in the peer buffer before the data is received.
- 0x06(INT STATUS) : reads the interrupt status of slave.




Figure 2 SPI Control Frame




Figure 3 SPI Timing Graph (SPI Control Frame)

### AT CMD Frame

The AT CMD frame reads the TX BUFF AVAIL from the SPI Control Frame and sets the Control Byte as 0x91 during the Control Phase if 0x0002 or bit 2 is high. Then the CMD length is set in units of 4bytes and AT CMD messages are included in the data for transmission. AT CMD reply uses the RX Data Frame method when receiving data. Please refer to the AT instruction set for more details on AT-CMD.




Figure 4 AT CMD Frame




Figure 5 SPI Timing Graph (AT CMD Frame)

### Data Frame

#### TX Data Frame

AT+CIPSEND, AT+CIPSENDEX, and AT+CIPSENDBUF must be transmitted from the AT CMD Frame and users must follow the next steps to prepare TCP or UDP data transmission in DATA trans mode.

The TX data frame reads the TX BUFF AVAIL from the SPI Control Frame and sets the Control Byte as 0x90 during the Control Phase if 0x0002 or bit 2 is high. Then the CMD length is set in units of 4bytes and DATA messages are included in the data for transmission. DATA reply uses the RX Data Frame method when receiving data.




Figure 6 TX DATA Frame




Figure 7 SPI Timing Graph (TX DATA Frame)

## RX Data Frame

When a reply or data is received after the AT CMD Frame is transmitted, check whether the interrupt pin is low or not. If the interrupt pin is low, users read the value of INT STATUS using the SPI Control Frame. If the value of INT STATUS is 0x0002 or bit 2 is high, users read the value of RX DATA LEN using the SPI Control Frame. And if the value of RX Data Len is not zero, users set the Control Byte as 0x10 during the control phase and read data. The total data count is the value of RX DATA LEN.




Figure 8 RX Data Frame




Figure 9 SPI Timing Graph (RX Data Frame)

## Operation

### AT CMD Operation

Use AT CMD to set WizFi360 or follow the steps below to set SEND mode and request data.




Figure 10 AT CMD Operation Flowchart

### DATA Operation

Data can be sent if AT+CIPSEND, AT+CIPSENDEX, OR AT+CIPSENDERBUF is entered in AT CMD or in DATA TRANS mode.




Figure 11 DATA Operation Flowchart

## Copyright Notice

Copyright 2022 WIZnet Co., Ltd. All Rights Reserved.

Technical Support: <https://forum.wiznet.io/>



Document: <https://docs.wiznet.io/>

Sales & Distribution: <mailto:sales@wiznet.io>





For more information, visit our website at <http://www.wiznet.io/>

## Documents / Resources



	<p><a href="#">Wiznet WizFi360 Application Note SPI</a> [pdf] User Guide</p> <p>WizFi360 Application Note SPI, WizFi360, Application Note SPI, Note SPI, SPI</p>
	<p><a href="#">WIZnet WizFi360 Application Note SPI</a> [pdf] User Guide</p> <p>WizFi360, WizFi360 Application Note SPI, Application Note SPI, Note SPI, SPI</p>

References

-  [WIZnet : Internet Offload Processor Provider](#)
-  [Products | WIZnet Document System](#)
-  [WIZnet Developer Forum](#)
-  [wizwiki.net](#)