

WARRANTY

WEN Products is committed to building tools that are dependable for years. Our warranties are consistent with this commitment and our dedication to quality.

LIMITED WARRANTY OF WEN PRODUCTS FOR HOME USE

GREAT LAKES TECHNOLOGIES, LLC ("Seller") warrants to the original purchaser only, that all WEN consumer power tools will be free from defects in material or workmanship during personal use for a period of two (2) years from date of purchase or 500 hours of use; whichever comes first. Ninety days for all WEN products if the tool is used for professional or commercial use. Purchaser has 30 days from the date of purchase to report missing or damaged parts.

SELLER'S SOLE OBLIGATION AND YOUR EXCLUSIVE REMEDY under this Limited Warranty and, to the extent permitted by law, any warranty or condition implied by law, shall be the replacement of parts, without charge, which are defective in material or workmanship and which have not been subjected to misuse, alteration, careless handling, misrepair, abuse, neglect, normal wear and tear, improper maintenance, or other conditions adversely affecting the Product or the component of the Product, whether by accident or intentionally, by persons other than Seller. To make a claim under this Limited Warranty, you must make sure to keep a copy of your proof of purchase that clearly defines the Date of Purchase (month and year) and the Place of Purchase. Place of Purchase must be a direct vendor of Great Lakes Technologies, LLC. Purchasing through third party vendors, including but not limited to garage sales, pawn shops, resale shops, or any other secondhand merchant, voids the warranty included with this product. Contact techsupport@wenproducts.com or 1-847-429-9263 with the following information to make arrangements: your shipping address, phone number, serial number, required part numbers, and proof of purchase. Damaged or defective parts and products may need to be sent to WEN before the replacements can be shipped out.

Upon the confirmation of a WEN representative, your product may qualify for repairs and service work. When returning a product for warranty service, the shipping charges must be prepaid by the purchaser. The product must be shipped in its original container (or an equivalent), properly packed to withstand the hazards of shipment. The product must be fully insured with a copy of the proof of purchase enclosed. There must also be a description of the problem in order to help our repairs department diagnose and fix the issue. Repairs will be made and the product will be returned and shipped back to the purchaser at no charge for addresses within the contiguous United States.

THIS LIMITED WARRANTY DOES NOT APPLY TO ITEMS THAT WEAR OUT FROM REGULAR USAGE OVER TIME, INCLUDING BELTS, BRUSHES, BLADES, BATTERIES, ETC. ANY IMPLIED WARRANTIES SHALL BE LIMITED IN DURATION TO TWO (2) YEARS FROM DATE OF PURCHASE. SOME STATES IN THE U.S. AND SOME CANADIAN PROVINCES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU.

IN NO EVENT SHALL SELLER BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES (INCLUDING BUT NOT LIMITED TO LIABILITY FOR LOSS OF PROFITS) ARISING FROM THE SALE OR USE OF THIS PRODUCT. SOME STATES IN THE U.S. AND SOME CANADIAN PROVINCES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATION OR EXCLUSION MAY NOT APPLY TO YOU.

THIS LIMITED WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS WHICH VARY FROM STATE TO STATE IN THE U.S., PROVINCE TO PROVINCE IN CANADA AND FROM COUNTRY TO COUNTRY.

THIS LIMITED WARRANTY APPLIES ONLY TO ITEMS SOLD WITHIN THE UNITED STATES OF AMERICA, CANADA AND THE COMMONWEALTH OF PUERTO RICO. FOR WARRANTY COVERAGE WITHIN OTHER COUNTRIES, CONTACT THE WEN CUSTOMER SUPPORT LINE. FOR WARRANTY PARTS OR PRODUCTS REPAIRED UNDER WARRANTY SHIPPING TO ADDRESSES OUTSIDE OF THE CONTIGUOUS UNITED STATES, ADDITIONAL SHIPPING CHARGES MAY APPLY.

V. 2024.02.28


INSTRUCTION MANUAL



MODEL 10764

IP54 DIGITAL CALIPER

KNOW YOUR CALIPER



TO INSTALL THE BATTERY

Remove the battery tray from the back of the unit (you may need a small flat-head screwdriver). Set the included battery in the tray, with the positive (+) side facing upward. Reinstall the battery tray.

SPECIFICATIONS

Model Number	10764
Measuring Range	0 - 150 mm / 0 - 6 Inches
Resolution	0.01 mm / 0.0005 in. / 1/128 in.
Power	1 x CR2032 3V Battery
Maximum Humidity	Up to 80% Non-Condensing
Operating Temperature	0 - 40°C (32 - 104°F)
Storage Temperature	-10 - 60°C (14 - 140°F)
IP Rating	67

INSTRUCTION MANUAL

SAFETY PRECAUTIONS

Follow the safety precautions below to reduce the risk of damaging your caliper.

- Avoid exposure to any liquids and excessive humidity.
- Avoid exposure to electromagnetic fields.
- Do not expose the instrument to direct sunlight.
- Do not attempt to disassemble the instrument.

BATTERY REPLACEMENT & WARNINGS

Flashing of the digits on the LCD display indicates the battery power is low. Remove the battery cover and replace with identical battery (positive side facing upward).

⚠ WARNING! Follow the safety instructions below for handling and maintaining batteries.

- Do not short circuit batteries.
- Do not keep batteries near fire, sources of heat, or use in direct sunlight.
- Remove batteries from tool when not being used for an extended period of time.
- Never handle leaked batteries. Do not dismantle batteries.
- Recycle used tool and batteries at your local recycling facility.

PLEASE READ THE FOLLOWING CAREFULLY:

1. Remove and immediately recycle or dispose of used batteries according to local regulations and keep away from children. Do NOT dispose of batteries in household trash or incinerate.
2. Even used batteries may cause severe injury or death.
3. Call a local poison control center for treatment information.
4. The compatible battery type is CR2032 and the nominal battery voltage is 3V.
5. Non-rechargeable batteries are not to be recharged.
6. Do not force discharge, recharge, disassemble, heat above 158°F, or incinerate. Doing so may result in injury due to venting, leakage or explosion resulting in chemical burns.

⚠ WARNING


- **INGESTION HAZARD:** This product contains a button cell or coin battery.
- **DEATH** or serious injury can occur if ingested.
- A swallowed button cell or coin battery can cause **Internal Chemical Burns** in as little as **2 hours**.
- **KEEP** new and used batteries **OUT OF THE REACH** of **CHILDREN**.
- **Seek immediate medical attention** if a battery is suspected to be swallowed or inserted inside any part of the body.




INSTRUCTION MANUAL

OPERATION - 4 WAY MEASUREMENT


NOTE: When taking measurements, do not touch the measuring faces of the caliper. The small amount of oil on your hands can affect the accuracy of your readings.




1. INNER DISTANCE MEASUREMENT



2. OUTER DISTANCE MEASUREMENT



3. STEP DISTANCE MEASUREMENT



4. DEPTH MEASUREMENT

CLEANING

After each use, wipe clean the caliper with a soft cloth. DO NOT use any type of solvent. DO NOT immerse the caliper in liquid.

Water damage may cause the display to fail. Wipe off the liquid and make sure the area between the slider and the beam has completely dried out. Reset the caliper by removing the battery for 30 seconds. Reinstall the battery and then turn the tool ON.

If the tool fails to work, please contact our customer service at **1-847-429-9263**, M-F 8-5 CST or email us at techsupport@wenproducts.com

TROUBLESHOOTING GUIDE

PROBLEM	SOLUTION
1. No Display.	1. Check battery contacts or replace the battery.
2. Digits do not display correctly.	2. Reset the caliper: Remove the battery for 30 seconds, then reinstall the battery and turn ON the tool.
3. Digits Flashing	3. Battery power is low. Replace with new battery.

NEED HELP? CONTACT US!

Have product questions? Need technical support? Please feel free to contact us:



1-847-429-9263 (M-F 8AM-5PM CST) |



TECHSUPPORT@WENPRODUCTS.COM