


N12 Smart Label Printer Quick Start Guide


Quick Start Guide


Smart Label Printer


N12




01 Package Contents

Smart Label Printer *1


Label Paper Roll *1

USB Type-C Cable *1


Quick Start Guide *1

02 Installation

01 Slide left to open the lid.




02 Insert the print paper into the compartment with the printed side facing down, and ensure the first label paper extends out of the tear-off opening.


Tear-off Blade
Print Side
Note: The printed content is below the label


Danger ! Beware of shape blade when the paper compartment is open.


03 App Download

01 Before using the printer, please install the "Nada Print" app from Google Play or the App Store.

Download on the App Store

Get it on Google Play


Nada Print

Nada Print


Scan the QR code to download and install the "Nada Print" App for printing.

04 Connecting and Printing


01 Turn on bluetooth on your phone.




02 Long press the power button to start the machine.




03 Open the "Nada Print" app.




04 Tap [Start Connecting].




05 Grant permissions.




06 Waiting for the printer to be connected.




07 In the searched printer list, click N12 to connect.



08 Connected.




08 Edit your first label, and tap [Print] after you finish editing.



The default label size for the first edit is 14mm * 40mm.

09 Print Successfully.



05 Basic Functions

| Function | Operation |
|-------------------|---|
| Switch on | Hold down the Power button for 3 seconds. |
| Switch off | Hold down the Power button for 3 seconds when the device is on. |
| Print | Press the Power button once when the device is on. |
| Print a test page | Double-press the Power button when the device is on. |

06 Specifications

| Product | Label Printer | Model | N12 |
|---------------------|-----------------|-----------------------|------------------|
| Dimensions | 109 x 77 x 32mm | Weight | 135g |
| Charging Time | 2-3 hours | Input | 5V DC, 2A |
| Battery Capacity | 1200mAh | Printing Method | Thermal printing |
| Printing Resolution | 203dpi | Printing Width | 12mm |
| Connectivity | Bluetooth | Charge | Type-C |
| Transmit Power | 4dBm(Maximum) | Operating Temperature | 0°C-45°C |

07 Safety Precautions

Please read all the instructions and warnings in this manual carefully before using this product to ensure the proper functioning of the device and your safety.

*Warnings

Don't disassemble the product without authorization. Disassembled products can not be returned or exchanged.

Do not wipe the product with corrosive chemicals or cleaning agents.

Do not use the product near places with flammable products such as gas stations or fuel depots.

08 Related Statements

FCC Statement

This device complies with part 15 of the FCC Rules.Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Notice:

If the device cannot be turned on, please charge for one hour

Zhuhai Jiuyin Technology Co., Ltd

Support Email : admin@zhuhaijiuyin.com

Official Website : www.ndyin.com

Address :
Room 302, Building 2, No.90 Chuangzhi Road, Tangjiawan Town, High-tech Zone, Zhuhai