

## WyreStorm SW-740-TX 4-Input Desk-Mounted 4K/60 HD BaseT **Presentation Switcher User Guide**

Home » WyreStorm » WyreStorm SW-740-TX 4-Input Desk-Mounted 4K/60 HD BaseT Presentation Switcher User Guide 🏗



4-input Desk-mounted 4K/60 HDBaseT Presentation Switcher with DSC Compression, Scaling & USB Host SW-740-TX **Quickstart Guide** 

WyreStorm recommends reading through this document in its entirety to become familiar with the product's features before beginning the installation process.

















#### **IMPORTANT! Installation Requirements**

- Read through the Wiring and Connections section for important wiring guidelines before creating or choosing premade cables.
- While this product supports CEC, WyreStorm cannot guarantee compatibility with all forms of CEC communication.
- · Visit the product page to download the latest firmware, document version, additional documentation, and configuration tools.

# **Contents** 1 In the Box 3 Control

- 2 Basic Wiring Diagram

Communication

- 4 Troubleshooting
- **5 Specifications**
- 6 Documents /

**Resources** 

- **6.1 References**
- **7 Related Posts**

#### In the Box

1x SW-740-TX Presentation Switcher

2x 5-pin Terminal Block

3x 4-pin Terminal Block

1x 24V DC 5A Power Supply (US/UK/EU/AU)

2x Mounting Brackets


1x Quickstart Guide (This Document)

#### Information and Parts Required for Installation

This transmitter requires connection via RS-232 or Ethernet in order to configure functions such as EDID. Ensure that the following items are on hand before proceeding with the installation.

- PC or Mac
- Telnet and Terminal software such as PuTTY
- USB COM Port Adapter (Not Included)
- WyreStorm Part: CAB-USB-3PIN
- · Network router and/or switch if using IP telnet for configuration.
- The latest version of the SW-740-TX API for advanced configuration is not covered in this document.

### **Basic Wiring Diagram**



WyreStorm recommends that all wiring for the installation is run and terminated prior to making connections to the switcher. Read through this section in its entirety before running or terminating any wires to ensure proper operation and to avoid damaging the equipment.



#### **IMPORTANT!** Wiring Guidelines

- The use of patch panels, wall plates, cable transmitters, kinks in cables, and electrical or environmental interference will have an adverse effect on the signal transmission which may limit performance. Steps should be taken to minimize or remove these factors completely during installation for best results.
- WyreStorm recommends using pre-terminated VGA, HDMI, and USB cables due to the complexity of these
  connector types. Using pre-terminated cables will ensure that these connections are accurate and will not
  interfere with the performance of the product.
- This product contains a USB-C connection that can be used as an audio/ video input. When using this connection verify that the USB-C cable used supports audio/video functionality as not all USB-C cables support this requirement.

Cat6 Cable Performance Guide


0m	10m	20m	30m	40m	50m	60m	70m	80m	90m	100m
0ft	32ft	65ft	98ft	131ft	164ft	197ft	230ft	262ft	295ft	328ft
4	<b>K/HD</b> Tra	nsmissio	n							

WyreStorm recommends the use of shielded cable to minimize signal noise and interference

## **Audio Connections**


#### Audio In

The audio connections use a 3.5mm (1/8in) TRS Stereo Jack.



#### **Audio Out**

The audio connections use a 3.5mm (1/8in) TRS Stereo Jack.




#### **Control Communication**

#### **RS-232 Wiring**

The SW-740-TX uses a 4-pin RS-232 with no hardware flow control. Most control systems and computers are


DTE where pin 3 is RX, this can vary from device to device. Refer to the documentation for the connected device for pin functionally to ensure that the correct connections can be made.



WyreS	torm Connector		3rd Party Device
Pin 1 12V DC Out		No Connection	Reserved
Pin 2	TX (Transmit)	> To>	RX (Receive)
Pin 3 RX (Receive)		> To>	TX (Transmit)
Pin 4	G (Ground)	> To>	G (Ground)

#### **IR Wiring**


The 4-pin IR connector can be used to either transmit or receive IR signals, based on the type of cable and pinout you use. The IR emitter or receiver being used must support 5v for proper operation.



WyreS	torm Connector		3rd Party Device
Pin 1	5V DC Out	No Connection	Reserved
Pin 2	IR (Receive)	> To>	IR (Transmit)
Pin 3	IR (Transmit)	> To>	IR (Receive)
Pin 4 G (Ground)		> To>	G (Ground)

#### Contact In/Tally Out


Contact connections are provided to allow for switching sources and feedback to a contact closure button on a desk or wall plate.



WyreS	torm Connector		3rd Party Device
Pin 1 VGA IN 1		> To>	Source 1
Pin 2	HDMI IN 2	> To>	Source 2
Pin 3	HDMI IN 3	> To>	Source 3
Pin 4	USB-C IN 4	> To>	Source 4
Pin 5	G (Ground)	> To>	G (Ground)

#### **PIR Sensor**

Contact connections are provided to allow for automatic triggering of input switching or display power.



WyreS	Storm Connector		3rd Party Sensor
Pin 1	12V DC Out	> To>	12v of Sensor
Pin 2	G (Ground)	> To>	G (Ground)
Pin 3 NC		> To>	NC of Sensor
Pin 4 COM (Common)		> To>	COM (Common)

#### **Setup and Configuration**

The SW-740-TX is configured using RS-232 or IP commands for Output Resolution, and EDID. Follow these steps to properly configure the transmitter based on the system requirement.

**Note:** The steps and information provided in this QSG are for the basic operation of the transmitter out of the box. Refer to the SW-740-TX API for full configuration settings.

- 1. Assign a Static IP Address to ensure proper communication on an IP Network.
- 2. Set EDIDs to be used at each input of the device. See Configuring Input EDIDs

#### **Communication Settings**

The SW-740-TX contains a web UI that can be accessed by connecting to a network and entering the IP address. We recommend that the IP address be changed from default before accessing the web UI for the first time.

RS-232 and IP Settings		
Baud rate:	115200	
Data Bits:	8bits	
Parity:	None	
Stop Bits:	1 bit	
Flow Control:	None	
Default IP Address	DHCP	
Default IP Port	23	

#### **Configuring Input EDIDs**

#### **Set Input EDID**

SET EDID [Input] [Prm]
Example: SET EDID in1 1
Response: EDID SET in1 1

#### **Query Input EDID**

GET EDID [Input] Example: GET EDID in1 Response: EDID in1 1

 $[Input]= in1 \sim in4$ 

[Prm]={Below tables based on connection}

VGA EDID	HDMI/USB-C EDIDs
8: 1024×768@60Hz 2CH	8: 1600×900@60Hz 2CH
7: 1280×768©60Hz 2CH	7: 1600×1200@60Hz 2CH
6: 1360×768@60Hz 2CH	6: 1680×1050@60Hz 2CH
5: 1440×900@60Hz 2CH	5: 1920×1200@60Hz 2CH
4: 1600×900©60Hz 2CH	4: 1280×720©60Hz 2CH
3: 1680×1050®60Hz 2CH	3: 1920×1080@60Hz 2CH
2: 1920×1080®60Hz 2CH	2: 3840×2160@30Hz 2CH
1: 1920×1200®60Hz 2CH	1: 3840×2160®60Hz 2CH

#### **Troubleshooting**

#### No or Poor Quality Picture (snow or noisy image)

• Verify that power is being supplied to the transmitter and receiving device.

- · Verify that all HDMI and HDBaseT connections are not loose and are
- · functioning properly.
- Verify that the HDBaseT cable is properly terminated following EIA568B
- standard.
- Verify that the output resolution of the source and display is supported by
- · this transmitter.
- Configure EDID Settings to a lower resolution.
- If transmitting 3D or 4K, verify that the HDMI cables used are 3D or 4K rated.

#### No or Intermittent 3rd party Device Control

 Verify that the IR, RS-232, and Ethernet cables are properly terminated following the Wiring and Connections section.

#### **Relays Not Functioning**

· Verify the polarity of the relay connections.



• WyreStorm recommends using a cable tester or connecting the cable to other devices to verify functionality.

#### **Specifications**

Audio and Video					
Inputs	1x VGA In 15-pin VGA 1x USB-C 2x HDMI In 19-pin type A Ix Audio In: 3.5mm (1/8in) TRS Stereo				
Outputs	Ix HDMI Out: 19-pin type A Ix Audio Out: 3.5mm (1/8in) TRS Stereo Ix HDBT Out: 8-pin RJ-45 Female				
Output Video Encodi ng	HDBaseT Class C				
Encoding Data Rate	ding Data Rate 9.2Gbps				
End to End Latency ( Max)	10ps (microseconds)				
Audio Formats	2ch and multi-channel LPCM	1			
	Video Resolution	НОМІ	Cat6	Cat6a/7	
	1920x1080p @60Hz 8bit	15m/49ft	100m/328ft	100m/328ft	
	1920x1080p @60Hz 16bit	7m/22ft	100m/328ft	100m/328ft	
Video Resolutions ( Max)	3840x2160p @60Hz 8bit 4: 4:4	7m/22ft	100m/328f1	100m/328ft	
	4096x2160p 60Hz 8bit 4:4:	3m/10ft	100m/328ft	100m/328ft	
	Note: WyreStorm recommends us lof shielded category cable to minimize signal noise and interference				
Supported Standards	OCI I RGB				
Maximum Pixel Clock	600MHz				

Communication and Control					
HDMI	1 HDMI I HDCP 2.21 EDID I CEC I DVI/D supported with adapter (not included)				
HDBaseT	HDMI I HDCP 2.21 EDID I CEC12ch audiolUSB1Serial				
RS-232	Ix 4-pin Phoenix (Control)				
Ethernet	1 x 8-pin RJ-45 female I Bidirectional over HDBaseT				
IR	Ix 4-pin Phoenix (Pass-through)				
USB	Ix USB-C: USB 3.1 Ix USB Host: USB-B Data Rate: 190Mbps				
CEC	Auto, Manual Display Power through HDMI & HDBT Output				
Other	PIR Sensor 1 x 4-pin Phoenix Contact Input: 1 x 5-pin Phoenix Tally Output: 1 x 5-pin Phoenix				
Power					
Power Supply	24V DC 5A				
Max Power Consum ption	Standard: 45W1 With USB Charging: 90W				
USB-C	Up to 45-watt charging				
Environmental					
Operating Temperature	0 — +45°C (32 — +113 °F), 10% — 90%, non-condensing				
Storage Temperature	-20 — +70°C (-4 — +158 °F), 10% — 90%. non-condensing				
Maximum BTU/hr	Standard: 153.51 With USB Charging: 310				
Dimensions and Wei	ght				
Rack Units/Wall Box	< 1U				
Height	30mm/1.18in				
Width	240mm/9.44in				
Depth	200.2mm/7.88in				
Weight 1.34kg/2.96lbs					
Regulatory	Regulatory				
Safety and Emissio n	I CE I FCC I RoHS I EAC I RCM				

**Note:** WyreStorm reserves the right to change product specification, appearance, or dimensions of this product at any time without prior notice.

#### **Warranty Information**

WyreStorm Technologies LLC warrants that its products be free from defects in material and workmanship under normal use for a period of five (5) years from the date of purchase. Refer to the Product Warranty page on wyrestorm.com for more details on our limited product warranty.



Copyright © 2020 WyreStorm Technologies | wyrestorm.com SW-740-TX Quickstart Guide | 200928

UK: +44 (0) 1793 230 343 | ROW: 844.280.WYRE (9973)

support@wyrestorm.com

#### **Documents / Resources**



<u>WyreStorm SW-740-TX 4-Input Desk-Mounted 4K/60 HD BaseT Presentation Switcher</u> [pd f] User Guide

SW-740-TX, 4-Input Desk-Mounted 4K 60 HD BaseT Presentation Switcher

#### References

<u>WyreStorm - Professional Audio Visual Solution Provider</u>

Manuals+,