**Manuals+** — User Manuals Simplified.



# Xiamen P2 IMachine Smart Desktop Terminal User Manual

## Contents

**Xiamen P2 IMachine Smart Desktop Terminal**

## Specifications

- Compliance: Part 15 of FCC Rules
- RF Exposure Requirement: General RF exposure requirement met
- Minimum Distance from Body: 20 cm

## Product Information

Main Display

**Power on**: Under shut down state, short press, then it would start up.
**Shutdown** Windows Android system device in the boot state long press the power button until the shutdown prompt appears, click to shutdown; Windows system device in the boot state click the WIN icon, then click the power button to shutdown.
**Reboot Android**: Android system device in the boot state, long press the power button until the reboot prompt appears, click to reboot; Windows system device in the boot state, click the Windows N icon, then click the power button to reboot

**Screen off**: Under the normal working state, tap the power button, then the screen will be
**Hibernate**: Under the normal working state, setting the system to hibernate.
**Wake up**: Under the hibernation state, light press on the power button, then the device will wake up.
**Forced**: Under the power-on state, long press the power button for 8 seconds+, the device is forced to shut down.

## Package Content



## Installation



1. Insert the interface of the standard power adapter into the power port, and the other end into the AC power socket.
2. Connect the peripheral, network, USB, serial, etc. to the corresponding interface according to the actual demand.

## FCC STATEMENT

1. The operating system only supports official upgrades, and users are responsible for any security risks and losses caused by brushing into unofficial systems on their own.
2. The users are responsible for any loss caused by the use and maintenance beyond this guide or using accessories purchased through unofficial channels.
3. The contents of this manual are subject to amendment without prior notice, and the specific configuration shall prevail in kind.

This device complies with part 15 of the FCC Rules. To ensure proper operation, please adhere to the following guidelines:

- This device should not cause harmful interference.
- The device must accept any interference received, including undesired operation.

**RF Exposure Guidelines**

To maintain compliance with FCC's RF exposure guidelines, ensure the following:

- Keep a minimum distance of at least 20 cm between the radiator of the device and your body.
- Ensure proper operating and installation practices are followed.

**Safety Warning**

1. Please read the instructions carefully before using the product to ensure proper and safe use.
2. Please use the accessories approved by the manufacturer and matched with this model of device, the use of power supply not approved by the manufacturer may cause fire, explosion or other hazards.
3. Please use the device under the specified operating temperature, when the ambient temperature is too high or too low, it may cause equipment failure.
4. Please do not disassemble the product or its accessories by yourself. If the device or any of its parts do not work properly, you should promptly consult our after-sales service, or send it to the after-sales service network for testing and repair.
5. Please unplug the power adapter and stop using it immediately if it is found to have abnormalities such as odor, overheating, discoloration, deformation, etc. during use or storage.
6. Please do not install or use during lightning, otherwise, there will be the risk
7. Using the machine with potential explosive gas is strictly prohibited.

**Warranty**
Welcome to use the smart terminal series products. Under normal use of the products you have purchased, the company is responsible for free maintenance within one year from the date of purchase for any quality problems caused by raw materials or the production process. Where the damage is caused by the user's installation, disassembly or incorrect use without following the requirements of this operation guide, the company can provide maintenance, but charge for the corresponding service and parts.

1. Under normal circumstances, the host warranty period is 12 months (three months for spare parts), (the specific circumstances of the sales contract shall prevail).
2. During the warranty period, under normal use (as determined by the company's technical staff), the warranty parts of the damage or failure are free of charge.

3. During the warranty period, the equipment that breaks down can be sent to our maintenance point for repair, and the shipping cost will be borne by the sender.
4. During the warranty period, the product has been repaired, disassembled or changed by maintenance personnel outside our company, or the failure caused by improper installation, improper use, broken serial number, accidental events or natural calamities is not covered by the warranty.
5. Please show the equipment SN and proof of purchase when repairing, our company reserves the right to explain the above.

## FAQs

**Q: What happens if the minimum distance between the device and my body is not maintained?**
Failure to maintain the minimum distance may result in increased RF exposure, which could potentially exceed regulatory limits.

**Q: Can I make modifications to the device?**
No, any changes or modifications not expressly approved by the responsible party for compliance may void your authority to operate the equipment.

## Documents / Resources



**Xiamen P2 IMachine Smart Desktop Terminal** [pdf] User Manual
P2, P2 IMachine Smart Desktop Terminal, IMachine Smart Desktop Terminal, Smart Desktop Terminal, Desktop Terminal, Terminal

## References

- **User Manual**