



Yale Y2S Smart Camera Instruction Manual

July 18,
2025

Contents [[hide](#)]

- [1 Yale Y2S Smart Camera Instruction Manual](#)
- [2 Product introduction](#)
- [3 Product parameters](#)
- [4 Parts list](#)
- [5 Device connection](#)
- [6 APP operation instructions](#)
- [7 Use and Precautions](#)
- [8 Documents / Resources](#)
 - [8.1 References](#)

Yale Y2S Smart Camera Instruction Manual



Product introduction



Product parameters

| | | | |
|-------------|---------------------------------|------------------|-----------|
| Name | IP camera | Video Encoding | MJPEG |
| Model | Y2 | Motion Detection | Support |
| Storage | Micro SD card; FAT32 | Link method | Bluetooth |
| temperature | -20~60 ℃ | Working humidity | ≤85 % |
| Wireless | Wi-Fi IEEE 802.11a/b/g/n 2.4GHz | | |

Parts list

| Number | Name | Quantity | Remark |
|--------|--------------------|----------|--------|
| 1 | Camera | 1 | |
| 2 | Charging line | 1 | |
| 3 | Instruction Manual | 1 | |
| 4 | Camera Bracket | 1 | |

Device connection

Device binding


1. Download client

Scan the QR code, download and install the “V720” APP, Or search “V720” in the app store, download and install the “V720” APP



2. Power on and reset the device

Plug the power cable into the Micro USB power interface on the back of the camera. The camera will automatically turn on and wait for the motor. Self-test completed.



*Do not manually twist the head of the camera to force it to rotate after turning it on.

3. Reset the device

(1) According to the guidance in the picture below, turn the lens upward to reveal the

position of the reset button. Press and hold the reset button with your finger. Until you hear a beep, the reset is successful.



4. Connect to the Internet

(1) Open the “V720” APP, wait for the New Device Found window to pop up click Add Device, Then add the device according to the APP prompts



*If no prompt box pops up, please click the “+” in the upper right corner of the APP and choose to add a device

*When connecting, ensure that the network is open and the camera is turned on normally.



*After successful connection, the device will restart

5. Connect to AP mode

1. After resetting the device according to the third point, open the phone settings and find “WLAN” or “Wireless LAN” device hotspot starting with “NAX_” and connect.




*When the mobile phone prompts "The current WLAN cannot access the Internet" or "The wireless LAN is not connected to the Internet", Please click "Continue trying to use wireless LAN"



2. Return to the "V720" APP and pull down to refresh the page. If the device comes out, it means the AP mode connection is successful.



APP operation instructions



Use and Precautions

Install SD card

Make sure the camera is powered off and flip the lens upward to reveal the microSD card slot. Insert the microSD card into the card slot in the correct direction.

*To install or remove the microSD card, you need to cut off the power of the camera before operating. Please use products produced by regular manufacturers microSD card (only supports FAT32 format, it is recommended that the microSD card read and write speed is not lower than U1/Class10)

Live

Find this device in the home page list and select it for real-time preview. Through the camera's control screen, operations such as camera picture interception and definition adjustment can be performed.

Play back

In the real-time screen, click the playback button to enter the playback interface, and drag the timeline to select the corresponding time period.

Precautions

1. The applicable working temperature of this product is -20°C~60°C. Please do not use this product in an environment where the temperature is too high or too low.
2. This product is a precision electronic product. Please do not use this product in an environment that is excessively humid or may cause water to enter the product, so as not to affect normal use.
3. In order to better use this product, the front and side of the lens should be kept away from glass, white walls and other reflective objects, so as not to cause the picture to be bright near, dark or white in the distance.
4. Please ensure that this product is installed within the coverage of Wi-Fi signal, and try to place it in a location with better Wi-Fi signal; try to install it as far away from microwave ovens and other places that may affect the signal.
5. If this product requires maintenance, please contact relevant personnel.

FCC Requirement

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. this device may not cause harmful interference, and
2. this device must accept any interference received, including interference that may

cause undesired operation.


Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator & your body. This transmitter must not be colocated or operating in conjunction with any other antenna or transmitter.

Read More About This Manual & Download PDF:

Documents / Resources

| | |
|--|---|
|  <p>Y2 Instruction Manual</p> | <p>Yale Y2S Smart Camera [pdf] Instruction Manual</p> <p>2BMNV-Y2S, 2BMNVY2S, Y2, Y2S Smart Camera, Y2S, Smart Camera, Camera</p> |
|--|---|

References

- [User Manual](#)

🔑 2BMNV-Y2S, 2BMNVY2S, camera, Smart Camera, Y2, Y2S, Y2S Smart Camera,

📁 Yale Yale

Leave a comment

Your email address will not be published. Required fields are marked *

Comment *

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

e.g. whirlpool wrf535swhz

Search

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.