



ZHEJIANG

# PE 5200 Series Button Transmitter



## ZHEJIANG PE 5200 Series Button Transmitter Instructions


[Home](#) » [ZHEJIANG](#) » ZHEJIANG PE 5200 Series Button Transmitter Instructions 

### Contents


- [1 ZHEJIANG PE 5200 Series Button Transmitter](#)
- [2 Product introduction](#)
- [3 Technical data](#)
- [4 Maximum channel latch](#)
- [5 Release the maximum channel latch](#)
- [6 Battery replacement](#)
- [7 FCC STATEMENT](#)
- [8 Documents / Resources](#)
  - [8.1 References](#)
- [9 Related Posts](#)

ZHEJIANG


**ZHEJIANG PE 5200 Series Button Transmitter**




## Product introduction



## Technical data




- Power Supply: CR2430
- Working Temperature: -20~+60°C
- Frequency: 433.92MHz
- Working Current: ≤20mA
- Standby Current: ≤1uA
- Operating Distance: ≥100m




- Power Supply: CR2430
- Working Temperature: -20~+60°C
- Frequency: 433.92MHz
- Working Current: ≤20mA
- Standby Current: ≤1uA
- Operating Distance: ≥80m

## Maximum channel latch



Use the "+" or "-" channel button to select the maximum channel (except the teamwork channel "00").




Hold down the "+" and "-" channel buttons at the same time, the screen will start flashing the current channel until 'AA' is displayed.



The screen displays "AA" as successful

## Release the maximum channel latch



Except for the teamwork channel "00", hold down the "+" and "-" channel buttons.



The display starts flashing the current channel and let go until "15" is displayed




When "15" is displayed, the operation succeeds.


## Battery replacement



① Loosen the rear cover screws, and slide down to open the battery compartment.



② Remove the old batteries and properly dispose of the used ones.



③ Place the battery right side up in the battery compartment



④ After sliding into the back cover, tighten the screws.

## Warning

1. Keep the transmitter away from moisture and impact to extend the service life.
2. If it is found that transmitter needs to be closely controlled or the button is not too sensitive and the indicator light blinks and darkens, the battery needs to be replaced.
3. Press any button for more than 10 seconds, the transmitter will stop sending wireless signals.

4. Please dispose of used batteries properly.
5. The 00 channel can control all channels,and the code matching function cannot be realized when using this channel.

FCC STATEMENT

Any changes or modifications not expressly approved by the party responsible for compliance could void the user’s authority to operate the equipment.  
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:



1. this device may not cause harmful interference, and
2. this device must accept any interference received, including interference that may cause undesired operation.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**Manufacturer Company Name:** Zhejiang General Light Curtain Co.,LTD.  
**Manufacturer Company Address:** Xin Tang Tou Village, Xin Jie Town, Xiao Shan District, Hang Zhou City, Zhe Jiang Province, China

Documents / Resources

	<a href="#">ZHEJIANG PE 5200 Series Button Transmitter</a> [pdf] Instructions PE 5200 Series, PE 5200 Series Button Transmitter, Button Transmitter, Transmitter
	<a href="#">Zhejiang PE 5200 Series Button Transmitter</a> [pdf] Instructions PE 5200 Series Button Transmitter, PE 5200 Series, Button Transmitter, Transmitter

References

- [User Manual](#)

## **Manuals+. Privacy Policy**

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.