


ZKC TCT TPMS Configuration Tool User Guide

Home » ZKC » ZKC TCT TPMS Configuration Tool User Guide 🖺

ZKC TCT TPMS Configuration Tool



Contents

- 1 SPECIFICATIONS
- **2 FCC Statement**
- 3 Documents /

Resources

3.1 References

SPECIFICATIONS

CPU: 32-bit micro MCU{Ultra low power)

Bluetooth: 5 Wi-Fi: 802.11 b/g/n; 802.11 n (2.4 GHz)

433MHz receiver sensitivity: -120dBm@ 2.0kbps,FRF=433.92

LF: 125KHz

LF range: 30~100CM Keys: Power-ON/START Battery: 3.7V/5800mAh Interface: TEYP-C Size: 168*51 *27mm

IP level: IP67

Operating Temperature: -10 to 45°C (14 to 113°F) Storage Temperature: -20 to 60°C (-4 to 140°F)

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- · Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules.

Operation is subject to the following two conditions (1)this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Documents / Resources



ZKC TCT TPMS Configuration Tool [pdf] User Guide
TCT TPMS Configuration Tool, TPMS Configuration Tool, Configuration Tool, Tool

References

• User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.